


Register your new Bosch now: www.bosch-home.com/welcome









en Installation and operating instructions

### Your new tumble dryer

You have opted for a tumble dryer manufactured by Bosch.

Please take a few minutes to read and become familiar with the advantages of your tumble dryer.

To meet the high quality demands required by Bosch, every tumble dryer that leaves our factory is carefully checked to ensure that it functions correctly and is in perfect condition.

For more information on our products, accessories, replacement parts and services, see our website www.boschhome.com or contact our Customer Service centres.

If the operating and installation instructions describe different models, any differences will be pointed out at the relevant points in the text.



Read these operating and installation instructions before operating the tumble dryer.

### **Display rules**

### ▲ Warning!

This combination of symbol and signal word indicates a possibly dangerous situation. Not heeding the warning can cause death or injuries.

#### Caution!

This signal word indicates a possibly dangerous situation. Not heeding the caution can cause property and/or environmental damage.

### Note/tip

Information about the optimum use of the appliance/any other useful information.

#### 1. 2. 3. / a) b) c)

The steps are represented by numbers or letters.

#### / -

Lists are represented by a small box or a dash.

### Contents

Sevent Intended use	4
Safety instructions           Children/people/pets           Installation           Operation           Cleaning/Maintenance	4 5 7 . 10
Environmental protection Packaging/old appliance Coolant Energy-saving tips.	. 11 . 11
Scope of delivery Installing and connecting the dryer. Changing the condensation drain Optional accessories Transport and frost protection	. 12 . 12 . 14 . 16
The main points in brief	.17
Getting to know your appliance Dryer Control panel Display panel	. 18 . 19
Preparing the laundry	. 21
Programmes and buttons Programmes	. 22
Section 2 Sectio	.25
Loading laundry and switching on the dryer	. 25 . 25

Changing the programme or adding laundry20 Cancelling the programme20 Programme end20 Removing laundry and switching	6
off the dryer	6
Clean the fluff filter	7 8
Signal setting2	9
Noises	0
Cleaning	0
Cleaning the dryer and the control panel	1
Faults and what to do about them	3
Consumption values3	5
Consumption values table	5
for cotton fabrics	5
Technical data	6
After-sales service	7

### <sup>§</sup> Intended use

- This appliance is intended for private domestic use only.
- Do not install or operate this appliance anywhere that is liable to experience frost and/or outdoor conditions. There is a risk that the appliance will be damaged if residual water in it freezes. If hoses freeze up, they may crack/burst.
- This appliance must only be used for drying and freshening up domestic laundry, consisting of items that have been washed with water and are suitable for tumble drying (see label on item). Using the appliance for any other purpose is outside of the scope of its intended application and is forbidden.
- This appliance is intended for use up to a maximum height of 4000 metres above sea level.

### Before you switch on the appliance:

Check that there is no visible damage to the appliance. Do not operate the appliance if it is damaged. Should you have any problems, please contact your specialist dealer or our customer service.

Read and follow the operating and installation instructions and all other information provided with this appliance.

Retain the documents for subsequent use or for subsequent owners.

### ▲ Safety instructions

The following safety information and warnings are provided to protect you from injury and to prevent material damage to your surroundings.

It is nevertheless important to take the necessary precautions and to proceed with care when installing, maintaining, cleaning and operating the appliance.

### Children/people/pets

# A Warning Risk of death!

Children and other people who are unable to assess the risks involved when using the appliance may injure themselves or may find themselves in life-threatening situations. Therefore please note:

- The appliance may be used by children over the age of 8 years and by persons with reduced physical, sensory or mental capacity or by persons with a lack of experience or knowledge as long as they are supervised or have received instruction on how to use the appliance safely and they have understood the potential risks of using the appliance.
- Children must not play with this appliance.

- Do not allow children to clean or maintain this appliance unsupervised.
- Keep children under 3 years and pets away from this appliance.
- Do not leave the appliance unattended when children or other people who are unable to assess the risks are in the vicinity.

### ▲ Warning Risk of death!

Children may lock themselves inside appliances and find themselves in a life-threatening situation.

- Do not position the appliance behind a door, as this may obstruct the appliance door or prevent it from opening completely.
- Once an appliance has reached the end of its life, pull the mains plug from the socket **before** severing the mains cable, and then destroy the lock on the appliance door.

### ▲ Warning Risk of suffocation!

If allowed to play with the packaging/plastic film or packing components, children may become caught in these or pull them over their heads and suffocate. Keep packaging, plastic film and packing components away from children.

### ▲ Warning Risk of poisoning!

Detergents and care products may result in poisoning if consumed. If accidentally swallowed, seek

medical advice. Keep detergents and care products out of the reach of children.

# Marning Eye/skin irritation!

Contact with detergents or care products may cause eye/skin irritation.

Rinse eyes/skin thoroughly if they/it come(s) into contact with detergents or care products. Keep detergents and care products out of the reach of children.

### Installation

### \Lambda Warning

### Risk of electric shock/fire/ material damage/damage to the appliance!

If the appliance is not installed properly, this may lead to a dangerous situation. Make sure that:

- The mains voltage on your power socket matches the rated voltage specified on the appliance (identification plate). The connected loads and the required fuse protection are specified on the identification plate.
- The appliance is only connected to a source of alternating current via a nationally recognized and grounded outlet that has been correctly installed.
- The mains plug and the grounded socket match and the earthing system has been correctly installed.
- The cross section of the cable is sufficiently large enough.
- The mains plug is accessible at all times.
- If using a residual current circuit breaker, only use one that bears the following mark: A line presence of this mark is the only way to be sure that it fulfils all the applicable regulations.

### \Lambda Warning

### Risk of electric shock/fire/ material damage/damage to the appliance!

If the appliance's mains cable is altered or damaged, this may result in electric shock, short circuiting or fire due to overheating.

The mains cable must not be kinked, crushed or altered, and

must not come into contact with any heat sources.

### Warning Risk of fire/material damage/ damage to the appliance!

The use of extension cords or power strips may result in fire due to overheating or short circuiting.

Connect the appliance directly to an earthed socket that has been correctly installed. Do not use extension cords, power strips or multi-way couplers.

### Warning Risk of injury/material damage/damage to the appliance!

 The appliance may vibrate or move when in operation, potentially resulting in injury or material damage.
 Place the appliance on a clean, even, solid surface and, using a spirit level to guide you, level it with the screw-in feet.  Incorrectly placing (stacking) this appliance on top of a washing machine may result in injury, material damage and/or damage to the appliance.

If this appliance is to be placed on top of a washing machine, the washing machine must be of at least the same depth and width as the appliance, and it must be secured in place with the appropriate connection set if available  $\rightarrow$  Page 16. The appliance MUST be secured with this connection set. Stacking the appliance in any other way is forbidden.

 If you take hold of any of the appliance's protruding parts (e.g. the appliance door) in order to lift or move it, these parts may break off and cause injury.

Do not take hold of any of the appliance's protruding parts in order to move the appliance.

# **≜** Warning Risk of injury!

 The appliance is very heavy. Lifting it may result in injury. Do not lift the appliance on your own.

- The appliance has sharp edges on which you could cut your hands.
   Do not take hold of the appliance by its sharp edges. Wear protective gloves to lift it.
- If the hoses and mains cables are not correctly routed, they may constitute a tripping hazard, which may result in injury.
   Route hoses and cables such that they do not constitute a tripping hazard.

### Operation

# Marning Risk of explosions/fire!

Laundry that has come into contact with solvents, oil, wax, wax remover, paint, grease or stain remover may ignite when dried in the machine, or even cause the appliance to explode. Therefore please note:

- Rinse the laundry thoroughly with warm water and detergent before drying it in the machine.
- Do not place laundry in this appliance to be dried if the laundry has not been washed first.
- Do not use the appliance if industrial chemicals have been used to clean the laundry.

# Marning Risk of explosions/fire!

 If there is any residual material left in the fluff filter, this may ignite when drying is in progress, or even cause the appliance to catch fire or explode.

Clean out the fluff filter each time the appliance is used to dry laundry.

- Certain objects may ignite when drying is in progress, or even cause the appliance to catch fire or explode. Remove any lighters or matches from pockets on items of clothing.
- If there is coal dust or flour in the air around the appliance, this may cause an explosion. Make sure that the area around the appliance is kept clean when it is in operation.

### **M**Warning

### Risk of fire/material damage/ damage to the appliance!

If a program is terminated before the drying cycle has finished, this prevents the laundry from cooling down sufficiently and may cause the laundry to ignite, or may result in material damage or damage to the appliance.

- During the last part of the drying cycle, the laundry in the drum is not heated (cooling cycle). This is to ensure that it remains at a temperature at which it will not be damaged.
- Do not switch off the appliance before the drying cycle has finished unless you remove all items of laundry from the drum immediately and spread them out (to dissipate the heat).

### Warning Risk of poisoning/material damage!

Condensation water is not suitable for drinking and may be contaminated with lint. Contaminated condensation water may be hazardous to health and may cause material damage.

Do not drink or reuse.

### ▲ Warning Risk of poisoning!

Poisonous fumes may be given off by cleaning agents that contain solvents, e.g. cleaning solvent.

Do not use cleaning agents that contain solvents.

### ⚠ Warning Risk of injury!

 If you support your weight/sit on the appliance door when it is open, the appliance may tip over, which may result in injury.

Do not support your weight on the appliance door when it is open.

 If you climb onto the appliance, the worktop may break, which may result in injury.

Do not climb onto the appliance.

 If you reach into the drum while it is still rotating, you risk injuring your hands. Wait until the drum has stopped rotating.

### **Caution!**

# Material damage/damage to the appliance

If the amount of laundry in the appliance exceeds its maximum load capacity, it may not be able to operate properly, or this may result in material damage or damage to the appliance.

Do not exceed the maximum load capacity of dry laundry. Make sure you comply with the maximum load capacities specified for each of the programs  $\rightarrow$  Page 22.

- If you operate the appliance without a fluff filter, or if the fluff filter is defective, this may result in damage to the appliance.
   Do not operate the appliance without a fluff filter, or with a fluff filter that is defective.
- Light objects such as hair and lint may be sucked into the air inlet when the appliance is in operation. Keep these away from the appliance.
- Foam and foam rubber may deform or melt if dried in the appliance.

Do not dry laundry items that contain foam or foam rubber in the appliance.

 If you pour the wrong quantity of detergent or cleaning agent into the appliance, this may result in material damage or damage to the appliance. Use detergents/care products/cleaning agents and softeners in accordance with the manufacturers' instructions.  If the appliance overheats, it may not be able to operate properly, or this may result in material damage or damage to the appliance.
 Make sure that the appliance's air inlet is never obstructed when the appliance is in operation, and that the area around the appliance is adequately ventilated.

### Cleaning/Maintenance

# ▲ Warning Danger of death!

The appliance is powered by electricity. There is a risk of electric shock if you come into contact with live components. Therefore please note:

- Switch off the appliance. Disconnect the appliance from the power supply (pull out the plug).
- Never take hold of the mains plug with wet hands.
- When removing the mains plug from the socket, always take hold of the plug itself and never the mains cable, otherwise this may damage the mains cable.
- Do not make any technical modifications to the appliance or its features.

- Repairs and any other work on the appliance must only be conducted by our customer service or by an electrician. The same applies for replacing the mains cable (when necessary).
- Spare mains cables can be ordered from our customer service.

### ▲ Warning Risk of poisoning!

Poisonous fumes may be given off by cleaning agents that contain solvents, e.g. cleaning solvent.

Do not use cleaning agents that contain solvents.

### **M**Warning

# Risk of electric shock/material damage/damage to the appliance!

If moisture penetrates the appliance, this may cause it to short circuit.

Do not use a pressure washer or steam cleaner to clean your appliance.

### A Warning Risk of injury/material damage/damage to the appliance!

The use of spare parts and accessories supplied by other brands is dangerous and may result in injury, material damage or damage to the appliance. For safety reasons, use genuine spare parts and accessories only.

### **Caution!**

# Material damage/damage to the appliance

Cleaning agents and agents for pretreating laundry (e.g. stain removers, prewash sprays, etc.) may cause damage if they come into contact with the surfaces of the appliance. Therefore please note:

- Do not allow these agents to come into contact with the surfaces of the appliance.
- Clean the appliance with nothing but water and a soft, damp cloth.
- Remove any detergent, spray or other residues immediately.

# Environmental protection

### Packaging/old appliance

 Dispose of packaging in an environmentally-responsible manner.
 This appliance is labelled in accordance with European Directive 2012/19/EU

concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the

framework for the return and recycling of used appliances as applicable throughout the EU.

### Coolant

The dryer's heat exchanger contains fluorinated greenhouse gas in a hermetically sealed unit.

Greenhouse gas:	R134a
Filling quantity (kg):	0.215
Total GWP (tCO <sub>2</sub> ):	0.307

Dispose of the dryer properly.

### **Energy-saving tips**

- Spin the laundry before drying. The drier the laundry, the shorter the drying time will be, thus consuming less energy.
- Load the dryer with the maximum load.

**Note:** Do not exceed the maximum load for the programs, as this prolongs the drying time and increases energy consumption.

- Ventilate the room and keep the air inlet on the dryer free to ensure air exchange.
- Clean the fluff filter after each drying cycle. If the fluff filter is dirty, the drying time is prolonged and energy consumption is increased.
- Energy saving mode: If the dryer is not operated for a prolonged period, it automatically switches off before the program starts and when the program has ended to save energy. The display panel and indicator lamps go off after a few minutes and the Start button flashes. To activate the lighting, press any button, open or close the dryer door or turn the program selector.

# Installation and connection

### Scope of delivery

- Dryer
- Installation and operating instructions
- Basket for woollens\*
- Condensation drain\*

# Installing and connecting the dryer

# Warning Risk of death!

There is a risk of electric shock as the dryer is operated with electricity.

- Check the dryer for visible damage. You must not operate the dryer if it is damaged.
- Before connecting the dryer to the power supply, ensure that the electric voltage specified on the rating plate matches the voltage of your socket.
- Only use residual current circuit breakers with the following symbol:
   C
- Ensure that the mains cable is not kinked or trapped and that it does not come into contact with heat sources or sharp edges.

\* Depending on the model

### **M**Warning

## Children could lock themselves in the dryer, putting their lives at risk!

Do not set up the dryer behind a door or sliding door as this may obstruct the dryer door or prevent it from opening.

#### Caution! Risk of injury

- As the dryer is heavy, you could injure yourself by trying to lift it. Do not lift the dryer on your own.
- You could cut your hands on the sharp edges of the dryer. Do not hold the dryer by the sharp edges.
- Protruding parts on the dryer may break off when it is lifted or pushed. Do not move the dryer by holding on to protruding parts.

### **Caution!**


# Risk of material damage to the dryer or fabrics

- Check the dryer for damage caused during transportation. Never operate a dryer if it is damaged.
- Any residual water in the dryer may freeze and damage the dryer. Do not install the dryer in rooms that are at risk of frost.

During installation ensure that:

- The dryer is placed on a clean, level and firm surface,
- The mains plug can be accessed at all times,
- The air inlet on the dryer is kept clear and there is sufficient ventilation,
- The area around the dryer is kept clean and
- The dryer is levelled using the threaded feet.

**Note:** Check the alignment of the appliance with a spirit level and correct if necessary. Change the height by turning the appliance feet. All appliance feet must stand firmly on the ground.



Incorrect alignment may cause high noise levels, vibrations and improper movement of the drum.


**Note:** If in doubt, have the appliance connected by a specialist.

# Changing the condensation drain

**Note:** The condensation from the dryer can either be discharged into the condensation container or drained off via a connection to the waste-water system. By default, the condensation from the dryer is discharged into the condensation container.


Proceed as follows to change the condensation drain:

1. Remove the accessories from the dryer drum.




2. When the dryer is delivered from the factory, the hose for discharging the condensation into the condensation container is fastened to the connecting piece.


 Disconnect the hose from the connecting piece and put it in the "parked" position.



 Take the drain hose from the accessories and secure it to the free connecting piece. Push the drain hose into the hose guide.



**5.** Fasten the other end of the drain hose with the remaining accessories, depending on the connection situation (A, B or C).



#### Caution!

### Accumulated water can be drawn back into the dryer and may cause material damage.

Check that the water drains away from the wash basin quickly. The drain must not be sealed or blocked.

#### Caution!

#### Material damage due to leaks or draining water.

Secure the drain hose so that it cannot slip out.Do not kink the drain hose. Observe a height difference between the installation surface and the drain of max. 100 cm and min. 80 cm for a drain into a siphon.

#### Note:

If you want to change the condensation drain back to the condensation container, carry out all these steps in reverse order.

### **Optional accessories**

Order optional accessories<sup>\*</sup> from the after-sales service:

#### Washer-dryer stack connection set:

To save space, the dryer can be placed on top of a suitable washing machine of the same width and depth.

The dryer must be fastened to the washing machine using this connection set.

Order number with pull-out worktop: **WTZ11400**;

Order number without pull-out worktop: **WTZ20410**.

#### Platform:

For easier loading and unloading, raise your dryer with a platform. Transport laundry with the clothes basket integrated into the platform drawer.

Order number: WMZ20500.

#### Basket for woollens:

Dry individual woollen items, sports shoes and soft toys in the basket for woollens.

Order number: WMZ20600.

### **Transport and frost protection**

- 1. Empty the condensate container.
- 2. Select any programme using the programme selector.
- 3. Press the Start button.
- 4. Wait for 5 minutes. Note: The condensation is drained.
- 5. Empty the condensate container again.
- 6. Switch off the dryer.

**Note:** Despite draining, there will always be some residual water in the dryer.

#### **Caution!**

## Any residual water may leak out and cause material damage.

Transport the dryer in an upright position.

#### **Caution!**

## The dryer contains coolant and may be damaged.


Allow the dryer to rest for two hours before initial use.

\* Depending on the model

### The main points in brief

1			Õ	⇒>	
	Load the laundry and close the door.		Switch the dryer on by turning the programme selector to the required programme.		Press the Start button.
2	End			\$	
	End of the programme.		Remove the laundry.		Switch the dryer off.
3		>		A A	
	Empty the condensate container.		Clean the fluff filter.		
4					
	When 🛞 appears in the display panel, remove the EasyClean filter.		Clean and dry the EasyClean filter.		Re-insert the EasyClean filter.


### Getting to know your appliance **Dryer**



- 1 Condensate container
- Control and display panelDrum interior light\*

  - 4 Dryer door
  - 5 Air inlet
  - 6 Fluff filter
- 7 EasyClean filter
- \* depending on the model

### **Control panel**



**Programme selector** for switching the dryer on/off and selecting the programme.

2	
3	
4	
5	

**Programmes**  $\rightarrow$  Page 22.


**Start button** for starting or interrupting the programme  $\rightarrow$  *Page 24*.

**Buttons** for applying default programme settings  $\rightarrow$  Page 24.

**Display panel**  $\rightarrow$  *Page 20.* 

### **Display panel**

### Buttons on the display panel



3 Anti-crease.

For a detailed description of all buttons, see  $\rightarrow$  Page 24onwards.

### **Display panel**



- $\stackrel{\text{\tiny left}}{\longrightarrow} \text{ Empty the condensate container} \\ \xrightarrow{} Page 27.$
- Iclean the EasyClean filter  $\rightarrow Page 31.$
- M D B Q P End : Programme progress for Dry, Iron Dry, Cupboard Dry, Anti-crease, Pause and End of programme.
- $\Theta^*$  Anti-Crease selected.
- 举 Drying level selected.
- **1:27** Expected programme duration in hours and minutes.
- **3 h** Programme will end in 3 h/hours with the "Ready in" time selected.

### Laundry

### Preparing the laundry

#### Warning Risk of explosion/fire!

Remove any cigarette lighters and matches from pockets.

#### **Caution!**

## The dryer drum and fabrics could be damaged.

Remove all objects from pockets and observe the following information:

- Tie cloth belts, apron strings, etc. together or use a laundry bag.
- Close zips, hooks and eyelets and buttons. Button up large items of laundry, such as covers.
- Remove any metal objects, such as paper clips, from pockets.
- To ensure a consistent drying result, sort laundry by fabric type and drying programme.
- Always dry very small items of laundry, e.g. babies' socks, together with large items such as towels.
- Knitted fabrics such as T-shirts and jerseys often shrink the first time they are tumble-dried. Use a gentle programme.
- Do not overdry easy-care laundry. This increases creasing of the laundry.
- Use timed programmes for single garments.
- Some detergents and care products, e.g. starch or softeners, contain particles which may be deposited on the moisture sensor. This may impair the sensor function and in consequence the drying result.
   Notes
  - When washing laundry to be tumble-dried, use the correct amount of detergent and care products as specified in the manufacturer's instructions.

Clean the moisture sensor regularly → Page 31.

### Sorting washing according to:

- C Suitable for tumble drying
- Dry at normal temperature
- Dry at low temperature
- Do not tumble-dry

**Note:** Do not load laundry from the washing machine directly into the tumble dryer. Sort the spun laundry before placing it in the dryer drum.

If you dry thin, thick and multi-layer fabrics together, they will dry to differing degrees. To achieve an even drying result, you should therefore only dry together laundry of the same type of fabric and structure. If you feel that the laundry is still too damp, you can select a timed programme for subsequent drying  $\rightarrow$  Page 22.

### Caution!

Possibility of material damage to the dryer or laundry.

## Do not tumble-dry the following fabrics:

- Laundry contaminated with oil.
- Unwashed fabrics.
- Non-breathable fabrics (e.g. rubbercoated).
- Easily damaged fabrics such as silk, synthetic curtains.

## Programmes and buttons

### **Programmes**

Programme and fabrics	Maximum load and programme settings/info
Name of the programme Which fabrics is the programme suitable for?	The maximum load is based on the dry weight of the fabrics
	Possible programme settings
Cottons Cupboard Dry Plus	8 kg
Hard-wearing, heat-resistant fabrics that are made of more than one layer of cotton or linen and do not dry readily.	
Cottons Cupboard Dry	8 kg
Normal, hard-wearing and heat-resistant fabrics made of a single layer of cotton or linen.	
Cottons Iron Dry	8 kg
Normal, hard-wearing and heat-resistant fabrics made of a single layer of cotton or linen that need to be damp after drying and are suit- able for ironing or hanging up.	
Easy-Care Cupboard Dry Plus	3.5 kg
Synthetic or blended fabrics that are made of more than one layer and do not dry readily.	
Easy-Care Cupboard Dry	3.5 kg
Normal synthetic or blended fabrics made of a single layer.	
Easy-Care Iron Dry	3.5 kg
Normal synthetic or blended fabrics made of a single layer that need to be damp after drying and are suitable for ironing or hanging up.	
Outdoor	1.5 kg
Weatherproof and outdoor clothing with a membrane coating and water-repellent fabrics.	
Towels	6 kg
Hard-wearing towels made of cotton.	
Mixed Load	3 kg
Mixed load consisting of cotton and synthetic fabrics.	

3 kg
3 kg
1.5 kg
1 kg
1.5 kg
3 kg

### **Buttons**

Explanations and notes
and their functions can be selected in all programmes.
If your laundry is too damp after drying, you can adjust the drying settings, e.g. Cup- board Dry, using the drying level button. The drying setting can be increased in three stages from 1 to 3 using the drying level button.
Once you have adjusted the drying level, this setting will be retained even after the dryer has been switched off.
Note: The higher the degree of dryness, the longer the programme duration.
The programme will end in 1-24 hrs. Set the "Ready in" time in increments of one hour to delay the start of the programme. The required number of hours after the programme ends is displayed in the display panel.
Activate or deactivate the childproof lock by pressing and holding the drying level button and the "Ready-in" time button at the same time for three seconds.
The drum moves the laundry at regular intervals after drying to prevent creasing. You can extend the automatic Anti-Crease function by 60 minutes after any programme has finished.
Starts or pauses the programme.

### Operating the appliance

Loading laundry and switching on the dryer

**Note:** The dryer must be correctly positioned and connected,  $\rightarrow$  *Page 12*.

- 1. Place the laundry in the drum.
- 2. Turn the programme selector to any programme to switch the dryer on.
- **3.** Close the dryer door.

### Caution!


## Possibility of material damage to the dryer or laundry.

Take care not to trap any laundry in the door.

### Setting a programme

**Note:** If you have activated the childproof lock, you must deactivate it before you can set a programme, see  $\rightarrow$  Page 24.

- Select the required programme; detailed information on the programmes can be found on → Page 22 onwards.
- 2. Use the programme selector to set the required programme. The default programme settings for the selected programme appear in the display panel.



**Note:** Default programme settings are standard settings that are already defined when a programme is selected. After selecting a programme, you can see the default programme settings in the display panel.

 If required, adjust the default programme settings. You can find detailed information on this on → Page 24 onwards.

### Starting the programme

Press the Start button.

**Note:** If you want to lock the programme to prevent it from being adjusted inadvertently, you can select the childproof lock, see  $\rightarrow$  Page 24.

### Programme sequence

The programme status is indicated in the display field.

- e.g. Expected programme duration
- **1:27** in hours and minutes.

**Note:** When a programme is selected, the expected drying time for the recommended load is displayed. During drying moisture sensors detect the remaining moisture in the load and adjust the programme length (except timed programmes). This is visible via the time remaining leaping forward.

- <u>∭</u> Dry
- ව Iron Dry
- Cupboard Dry
- AntiCrease
- P Pause
- End End

# Changing the programme or adding laundry

You can remove or add laundry and change or alter the programme at any time during drying.

- 1. To pause the programme, open the dryer door or press the Start button.
- 2. Add or remove laundry.
- 3. Select another programme or an additional function, if required.
- 4. Close the dryer door.
- 5. Press the Start button.

**Note:** The programme duration in the display panel is updated depending on the load and residual moisture in the laundry. The values displayed may change after the programme is changed or the load is adapted.

### Cancelling the programme

The programme can be interrupted at any time; to pause, open the dryer door or press the Start button.

### **Caution!**

#### Risk of fire. Laundry may catch fire.


If you cancel the programme, you must remove the laundry items and spread them out so that the heat can disperse.

### **Programme end**

End appears in the display panel.

# Removing laundry and switching off the dryer

- **1.** Remove the laundry.
- 2. Turn the programme selector to the "off" position.



# Emptying the condensate container

#### Notes


- You can drain off the condensation into the waste-water system using an optional condensation drain<sup>\*</sup>. For installation, see → Page 14.
- If you drain the condensation using an optional condensation drain, you do not have to empty the condensate container.

**Note:** After each drying cycle, empty the condensate container; otherwise the next drying programme may be cancelled as a result of the condensate container being full.

1. Pull out the condensate container horizontally.



2. Pour out the condensation water.



#### **Caution!**

#### Dirty condensation water may be harmful to your health and cause material damage.

Condensation water is not suitable for drinking and may be contaminated with fluff. Do not drink the condensation water or reuse it.

**3.** Push in the condensate container until you feel it lock back into place in the dryer.



\* Depending on the model

### **Clean the fluff filter**

**Note:** During drying, fluff and hair from the laundry is trapped by the fluff filter. If the fluff filter is blocked or dirty, this reduces the flow of air, which prevents the dryer from achieving its maximum performance. Clean fluff filters also reduce energy consumption and the drying time.

Clean the fluff filter **after each** drying cycle:

- 1. Open the dryer door and remove all fluff from the door.
- 2. Pull out the two-part fluff filter.




**3.** Remove the fluff from the recess in the fluff filter.



Note: Ensure that no fluff falls into the open shaft.

4. Pull apart the two-part fluff filter.




5. Open both filters and remove all the fluff.



6. Rinse away the fluff under warm, running water.



7. Dry the fluff filter, close it and reinsert the two-part fluff filter.



### Caution! The dryer may be damaged.


Do not operate the dryer without a fluff filter or if the fluff filter is defective.

### Signal setting

You can change the following settings:

- The spin speed that is used for spinning your laundry before it is dried.
- The volume of the audible signal at the end of the programme,
- The volume of the audible button signals.

You will need to activate the setting mode in order to change these settings.



### Activating setting mode

- Switch the dryer on.
   Select the "Cottons" programme in position 1 and wait for 5 seconds. Setting mode is now activated. The symbols go out on the display panel and the programme duration is displayed.
- **1.** Press and hold the Start button and. at the same time, turn the programme selector clockwise to position 2.
- 2. The spin speed is shown on the display.
- 3. Press the "Ready in" time button to change the spin speed.
- 4. Turn the programme selector clockwise to position 3.

5. The volume for the audible signal at the end of the programme is shown on the display.



0 = off, 1 = quiet, 2 = medium,

- 3 = loud, 4 = very loud
- 6. Press the "Ready in" time button to change the volume.
- 7. Turn the programme selector clockwise to position 4.
- 8. The volume for the audible button signal is shown on the display.



0 = off, 1 = quiet, 2 = medium,

- 3 =loud, 4 =very loud
- 9. Press the "Ready in" time button to change the volume.

Note: You can select other positions with the programme selector; however, you will be unable to change these settings.


#### Exiting setting mode

Turn the programme selector to the "Off" position once you have set the required spin speed and the volume. The settings have now been saved.


### Noises

**Note:** During drying, particularly in the initial phase, operation of the appliance results in noise from the compressor and pump. This is perfectly normal and does not impair proper functioning of the appliance.


From time to time, the compressor in the dryer generates a humming noise. However, the volume may vary depending on the programme and progress of the drying process.



Every now and then, the compressor is ventilated. This creates a whirring noise.



The condensation is pumped into the condensate container by a pump. This generates pumping noises.



### Cleaning

# Cleaning the dryer and the control panel

# Warning Risk of death!

There is a risk of electric shock as the dryer is operated with electricity. Disconnect the dryer from the mains before cleaning.

Clean the dryer using only water and a soft, damp cloth.

Remove all detergent residue, spray residue or other residues immediately. Do not use cleaning agents or agents for pre-treating laundry (e.g. prewash sprays, stain removers). Do not use high-pressure cleaners or steam jet cleaners to clean your appliance.

### Cleaning the moisture sensor

**Note:** The dryer is equipped with a stainless-steel moisture sensor. The moisture sensor measures how damp the laundry is.

After long periods of usage the moisture sensor may become covered by a fine layer of limescale or residues of detergents and care products. Such residues must be removed regularly as the sensor function and in consequence the drying result may be impaired.

Open the door and clean the moisture sensor with a coarse sponge.



#### Caution! Moisture sensor may be damaged.

Do not clean moisture sensors with abrasives and steel wool.

### Cleaning the EasyClean filter

When (appears in the display panel, clean the EasyClean filter as follows:


The appliance must be switched on.

- **1.** First clean the fluff filter  $\rightarrow$  Page 28.
- 2. Close the door of the dryer.
- 3. Open the maintenance flap on the heat exchanger.
- 4. Release the levers on the EasyClean filter.

5. Use the grip handle to pull the EasyClean filter out.




- 6. Now take off the filter mat.
- Wash out the filter mat by hand using clean water.
   Notes
  - If the filter mat is covered with stubborn dirt, you can also remove this carefully using a vacuum cleaner.
  - Do not use cleaning agents.



 Dry the filter mat by squeezing the water out.
 Note: Only use the filter mat if it is

Note: Only use the filter mat if it is clean and dry.


9. Put the filter mat back on.



**Note:** Ensure that the filter mat is not misshapen, torn or clogged. Position the filter mat as shown above.

#### en Cleaning

**10.** Check how dirty the dryer's heat exchanger is before putting the EasyClean filter back in. If it is very dirty, use a vacuum cleaner with a brush attachment to clean it carefully from top to bottom.




**Note:** Take care not to bend or damage the fins on the heat exchanger when cleaning it. **Caution!** 

#### Risk of injury.

You could cut yourself on the fins of the heat exchanger.

Do not touch these with your hands.

- **11.** Slide the EasyClean filter in and make sure it clicks into place.
- **12.** Close the maintenance flap.



**13.**Switch the dryer off.

You have now cleaned the EasyClean filter.

**Note:** If your filter mat is damaged, you can order a new one from the after-sales service using part number: 12007650.

Contact information for all countries can be found on the enclosed after-sales service list.

### Faults and what to do about them

Faults	Cause/remedy
➡ on the display panel and drying has been inter- rupted.	<ul> <li>Empty the condensate container and press the Start button.</li> <li>If the optional condensation drain has been installed, the drain hose may be blocked or kinked. Check the hose for deposits and flush the hose out. Make sure that the hose does not have any kinks when it is in place.</li> </ul>
on the display panel.	Clean the fluff filter $\rightarrow$ Page 28 and the EasyClean filter $\rightarrow$ Page 31.
on the display panel even though the fluff filter and the EasyClean filter have been cleaned.	It is important to proceed in the order set out in the section entitled $\rightarrow$ Page 31. Note: The appliance must be switched on when it is cleaned.
Dryer will not start.	<ul> <li>Start button selected?</li> <li>Mains plug plugged in or fuse checked?</li> <li>Programme selected? Select a programme.</li> <li>Dryer door open? Close the door.</li> <li>Is the childproof lock activated? Deactivate the childproof lock.</li> <li>"Ready in" time selected? Programme starts after a delay.</li> </ul>
Creasing.	<ul> <li>Creasing occurs when you have exceeded the maximum permitted load or selected the wrong programme for the type of fabric. All the required information can be found in the programme table.</li> <li>Remove clothes immediately after drying; creasing may occur if they are left in the drum.</li> </ul>
Water is leaking out.	Not a fault; the dryer may be positioned on an incline. Level the dryer.
Change in the pro- gramme duration dis- played during drying.	Not a fault. The moisture sensors detect the remaining moisture in the load and adjust the programme length (except timed programmes).
* Depending on the model	

Faults	Cause/remedy
Laundry is not dried prop- erly or is still too damp.	<ul> <li>After the programme has ended, warm laundry feels damper than it actually is. Spread the laundry out and allow the heat to disperse.</li> <li>Finely adjust the dryness level - this extends the drying time but does not increase the temperature. Your laundry will become drier → Page 24.</li> <li>Select a programme with a longer drying time or increase the dryness level. This does not increase the temperature.</li> <li>Select a timed programme to add extra drying time for laundry that is still damp → Page 22.</li> <li>If you have exceeded the maximum permitted load for the programme, the laundry may not be dried properly.</li> <li>Clean the moisture sensor in the drum. The sensor may become covered by a fine layer of limescale or residues of detergents and care products which then impair its function. Your laundry is not being dried correctly → Page 31.</li> <li>Drying has been interrupted as a result of a power cut, because the condensate container is full or because the maximum permitted drying time has been exceeded.</li> </ul>
Drying time too long?	<ul> <li>The fluff filter or the EasyClean filter may be dirty, which will make the drying time longer. Clean the fluff filter or the EasyClean filter.</li> <li>If the air inlet on the dryer is blocked or not freely accessible, this may increase the drying time. Make sure that the air inlet remains unobstructed.</li> <li>The optimum ambient temperature for drying is between 15 °C and 30 °C. Outside of this range, the drying time may increase the drying time. Ventilate the room.</li> </ul>
Display panel goes off and Start button flashes.	Not a fault. Energy-saving mode is active $\rightarrow$ Page 11.
Humidity in the room increases.	Not a fault. Make sure the room is sufficiently ventilated.
Power cut.	The drying programme is interrupted. Remove the laundry and spread it out, or restart the programme.
Unusual noises when dry- ing.	Not a fault; see also $\longrightarrow$ Page 30.
The dryer feels cold despite drying.	Not a fault. The dryer can dry efficiently at low temperatures using a heat pump.
* Depending on the model	

**Note:** If you cannot rectify the fault yourself by turning the dryer off and then on again, please contact our after-sales service.

### Consumption values

### **Consumption values table**

Programme	Spin speed used for spinning the laundry	Dura	Duration** Energy consumption		sumption**
Cottons		8 kg	4 kg	8 kg	4 kg
Cupboard Dry*	1400 rpm	201 min	111 min	2.06 kWh	1.15 kWh
	1000 rpm	224 min	130 min	2.22 kWh	1.25 kWh
	800 rpm	247 min	157 min	2.46 kWh	1.46 kWh
Iron Dry*	1400 rpm	154 min	93 min	1.50 kWh	0.90 kWh
	1000 rpm	177 min	107 min	1.85 kWh	1.12 kWh
	800 rpm	200 min	120 min	2.13 kWh	1.28 kWh
Easy-Care		3.5 kg		3.5 kg	
Cupboard Dry*	800 rpm	66 min		0.55 kWh	
	600 rpm	78 min		0.64 kWh	

\* Programme setting for testing in accordance with the applicable EN 61121 standard.

\*\* The values may differ from those specified, depending on the type of fabric, composition of laundry to be dried, residual moisture in the fabric, the degree of dryness that has been set, the amount of laundry being loaded and the environmental conditions.

### Most efficient programme for cotton fabrics

The following "standard cottons programme" (identified with  $\bigcirc$ ) is suitable for drying normal, wet cotton laundry and is most efficient in terms of its combined energy consumption for drying wet cotton laundry.

Standard programmes for cottons in accordance with current EU regulation 932/2012						
Programme Load Energy consumption Programme length						
Cottons Cupboard Dry	8 kg/4 kg	2.22 kWh/1.25 kWh	224 min./130 min.			
Programme setting for testing and energy labelling in accordance with Directive 2010/30/EU.						

### Technical data

### Dimensions:

85 x 60 x 60 cm Height x width x depth

### Weight:

Approx. 48 kg

#### Maximum load:

8 kg

Condensate container:

4.8 I

Connected voltage:

220 - 240 V

### Connected load:

Max. 600 W

### Fuse:

10 A

Drum interior light\*

### Ambient temperature:

5 - 35 °C

Power consumption when switched off:

0.10 W

Power consumption when ready for use (left-on mode):

0.50 W

\* Depending on the model

### After-sales service

#### After-sales service

If you cannot rectify the fault yourself (faults, what to do?), please contact our after-sales service. We will always find an appropriate solution to avoid unnecessary visits by engineers.

The contact information for your nearest after-sales service can be found here or in the enclosed after-sales service directory.

Please provide after-sales service with the dryer's product number (E-no.) and production number (FD).

E-Nr	FD

You can find this information on the inside of the dryer door or on the rear of the dryer.

### Trust the expertise of the manufacturer.

Contact us. You can therefore be sure that the repair is carried out by trained service technicians who carry original spare parts.

	D.
	$\overline{n}$
В	IJ,

	D.
	$\overline{n}$
В	IJ,

### Advice and repair order in the event of faults

GB 0344 892 8979 (Calls charged at local or mobile rate.)

IE 01450 2655 (0.03 € per minute at peak. Off peak 0.0088 € per minute.)

You can find the contact information for all countries in the attached after-sales service directory.

Robert Bosch Hausgeräte GmbH Carl-Wery-Straße 34 81739 München, GERMANY

