



Washer dryer WVH28422GB



en Instruction Manual and Installation Instructions

## Your new washer dryer

You have chosen a Bosch washer dryer.

Please take a few minutes to read and become familiar with the advantages of your washer dryer.

To meet the high quality demands required by Bosch, every washer dryer that leaves our factory is carefully checked to ensure that it functions correctly and is in perfect condition.

For more information on our products, accessories, replacement parts and services, see our website www.boschhome.comor contact our after-sales service centres.

If the operating and installation instructions describe different models, any differences will be pointed out at the relevant points in the text.



Read these operating and installation instructions before switching on the washer dryer.

### Display rules

### 

This combination of symbol and signal word indicates a possibly dangerous situation. Not heeding the warning can cause death or injuries.

#### Caution!

This signal word indicates a possibly dangerous situation. Not heeding the caution can cause property and/or environmental damage.

#### Note/tip

Information about the optimum use of the appliance/any other useful information.

#### 1. 2. 3. / a) b) c)

The steps are represented by numbers or letters.

\_ / -

Lists are represented by a small box or a dash.

## **Contents**

Intended use4	Drying tal Starching
⚠ Safety instructions5	Dyeing/B Soaking.
Electrical safety	P+ Char
Protection of the environment 6 Packaging/old appliance 6 Hints and tips 6	°C (Temp ⑤ (Finish ⑥ (Spin s 蕊 (Drying
The main points in brief7	P <sup>+</sup> Sele
Getting to know your appliance .8  Washer dryer	(Spe
Preparing laundry for washing 12 Preparing laundry for drying 13	Setti Clea Machine
Operating the appliance	Drum Descaling Cleaning Drain pur Drainage blocked. Filter in th blocked. Air filter b  Faul then Emergene failure ocu Informatic Faults and
Programme on the programme selector	

Drying tableStarchingDyeing/BleachingSoaking	24 24
Changing programme default settings.  °C (Temperature)  (Finish in)  (Spin speed)  (Drying).	24 25 25
Selecting additional functions.  (SpeedPerfect)	26 26 26
Setting the signal	27
Cleaning and maintenance  Machine housing/Control panel  Drum  Descaling  Cleaning the detergent dispenser  Drain pump blocked  Drainage hose on the siphon blocked  Filter in the water inlet hose blocked  Air filter blocked  Faults and what to do about them  Emergency release, e.g. if a power failure occurs	28 28 28 28 29 29 30
Information on the display panel Faults and what to do about them	

#### Intended use en

Customer service	35
Technical specifications	35
Consumption values	36
Installation and connection	
Standard accessories	37
Installation	37
Secure installation	37
Installation area	38
Installing the appliance on a base	
or on a wooden joist ceiling	38
Installing the appliance under/	
between kitchen units	38
Removing the transportation	
protection devices	39
Hose and cable lengths	39
Connecting the water	40
Water supply	40
Water drainage	41
Drainage into a wash basin	41
Drainage into a siphon	41
Drainage into a plastic pipe with	
rubber sleeve or into a gully	41
Alignment	42
Electrical connection	42
Before washing/drying for the	
Ffirst time	
Transportation	13

## Intended use

- For private domestic use only.
- The washer dryer is suitable for washing machine-washable textiles or hand-washable wool in washing water and for drying these textiles.
- The appliance is suitable for operation with cold mains water and commercially available detergents and care products which are suitable for use in a washer dryer.
- Always follow the manufacturer's instructions when dosing all detergents, cleaning aids, cleaning products and cleaning agents.
- The washer dryer may be operated by children from 8 years of age, by persons who have limited physical, sensory or mental abilities and by persons who have inadequate experience or knowledge, provided they are supervised or have been **instructed** by a responsible person.
- Children must not perform any cleaning or maintenance work without supervision.
- Keep pets away from the washer drver.
- Install and operate the washer dryer in a room which has an outflow.

Read and follow the operating and installation instructions and all other information enclosed with the washer

Retain documents for subsequent use.

## **⚠** Safety instructions

## **Electrical safety**

## Warning Danger of death!

Danger of death if live parts are touched.

- When disconnecting the mains plug, always pull the plug itself and not the cable, otherwise the cable could be damaged.
- Never touch or hold the mains plug with wet hands.

## Risk of injury

## Risk of injury!

- If the washer dryer is lifted using projecting parts (e.g. the washer dryer door), these components may break off and cause injuries.
  - Do not lift the washer dryer by its projecting parts.
- If you climb onto the washer dryer, the worktop may break and cause injuries. Do not climb onto the washer dryer.
- If you lean/support yourself on the open door, the washer dryer may overturn and cause injuries.

Do not lean on the open washer dryer door.

If you reach into the rotating drum, you may injure your hands.

Do not grip the rotating drum. Wait until the drum stops rotating.

## 🔼 Warning Risk of scalding!

- When washing at high temperatures, you may be scalded if you touch the hot washing water (e.g. if draining hot washing water into a washbasin). Do not touch the hot washing
  - water.
- If a drying programme was interrupted, the washer dryer and laundry may be very hot. Select Intensive Dry 🔅 or Gentle Dry A and select 15 min drying time to cool down the washing and then remove.

## Safety for children

## Warning Danger of death!

If children play on the washer dryer, they may place themselves in life-threatening situations or injure themselves.

- Do not leave children unsupervised near the washer dryer.
- Do not let children play with the washer dryer.

## **Marning** Danger of death!

Children may lock themselves inside appliances and suffocate. On redundant appliances:

- Pull out the mains plug.
- Sever the power cord and discard together with the plug.
- Destroy the lock on the door of the washer dryer.

## 

When playing, children may become entangled in the packaging/film and packaging parts or pull them over their heads and suffocate.

Keep packaging, plastic film and packaging parts out of the reach of children.

## 

Detergents and care products may be poisonous if consumed. Keep detergents and care products out of the reach of children.

## **⚠** Warning Eye / skin irritation!

Detergents and care products may cause irritation if they come into contact with the eyes or skin. Keep detergents and care products out of the reach of children.

## ⚠ Warning Risk of injury!

When washing at high temperatures, the glass part of the door becomes hot. Prevent children from touching the hot door.



## Packaging/old appliance




Dispose of packaging in an environmentally friendly manner.

This appliance has been identified in accordance with the European Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE). The Directive specifies the framework for an EU-wide valid return and recycling of waste appliances.

## Hints and tips

- Utilise the maximum amount of washing for the particular programme. Overview of programmes → Page 20
- Wash normally soiled laundry without prewash.
- The selectable temperatures apply to the care labels on the textiles. The temperatures in the machine may deviate from this so that you get the optimum mix of energy-saving and washing results.
- If the laundry is then dried in the appliance, select the maximal possible spin speed. The less water the laundry contains, the less time and energy are required for drying. Do not dry dripping wet laundry.
- Ventilate the installation room well and clean the air inlet filter regularly. Cleaning and maintenance→ Page 28 and Installation and connection→ Page 37


# The main points in brief



#### en

# Getting to know your appliance


## Washer dryer



- 1 Hot air outlet
- 2 Operating/display panel
- 3 Door with handle

- 3a Open the door
- 3b Close the door
- 4 Service flap and cool air inlet

## **Control panel**




Change the default settings for the selected programme and select additional functions:

- 3 Select a programme. Can be rotated in either direction. To switch off the washer dryer, set the programme selector to Off.

- 4 Start programme. Select the **▷ Start/ Reload** button to start, interrupt (e.g. reload the laundry) and cancel the programme. → Page 16
- 5 Display panel for settings and information.

## Display panel



1: Temperature for washing programme.	<b>※</b> (cold) − <b>90°C</b>	Temperature in °C
2: Programme information.		
Time:	1:50*	Programme duration after programme selection in h:min (hours:minutes)
	1 – 24 h	Finish in time in h (h=hour)
Capacity:	7.0 kg*	Max. load for selected programmes
Programme status:	<b>-0-</b>	Programme end
	PAUS	Programme interrupted
		End of programme using Rinse stop
Door open information:	OPEn	The door can be opened if programme interrupted
	A:02	The door cannot be opened
Further information:	E:*	Fault display
	0	Setting the signal $\longrightarrow$ Page 27
Drying mode and drying time:	Aut 1	Auto-Dry mode 1, Cupboard dry
	Aut 2	Auto-Dry mode 2, Extra dry
	120*	Selected drying time
	OFF	The drying function is deactivated

3: Spin speed	<b>─</b> - <b>1400</b> *	Spin speed in revolutions per minute;
4: Programme progress sym-	<del></del>	Washing
bols		Rinsing
	©	Draining/Spinning
	*	Drying
5: Programme information symbols	Auto	On if auto drying programme is selected
	*	On if drying programme is selected.
Automatic load detection function:	ប ជួស្	Detects the load when the water has run in and sets the remaining time accordingly. The symbols indicate a small, medium and large load which was determined by means of the recommended maximum load ** for the selected programme.  ** Automatic display of the detected load only for washing programmes with a recommended maximum load of more than 3 kg, with the exception of <b>Spin</b> ③, <b>Rinse</b> and ( <b>Rinse plus</b> ). Different types of textiles with different degrees of water absorption may influence the load display
Тар	즉 lights up	Water pressure too low. This extends the programme duration
	♣ flashes	The tap has not been turned on or there is no water pressure
Door	(3) lights up	When the door can be opened
	① flashes	When the programme has started: the door is not closed properly
Overdosage	<b>&amp;</b>	On if too much foam detected, one rinse cycle switched on
Childproof lock	<b>o</b> lights up	The childproof lock is activated
	<b>o</b> flashes	The childproof lock is actived, and if the programme selector has been adjusted or the buttons have been pressed
* Depends on selected programmes,	/additional functions.	



## Preparing laundry for washing

#### Sorting laundry according to:

Sort your laundry according to the care instructions and specifications of the manufacturer on the care labels:

- Type of fabric/fibre
- Colour

**Note:** Laundry can discolour or not be cleaned correctly. Wash white and coloured items separately. Wash new bright fabrics separately the first time you wash them.

- Soiling
  - light

do not prewash; if necessary select the = (SpeedPerfect) additional function.

normal

Select programme with prewash. If required, pretreat stains.

- heavy
  - Load less washing. Select programme with prewash. If required, pretreat stains.
- Stains: Remove/pretreat stains while they are fresh. Firstly, dab with a soap water; do not rub. Then select the appropriate programme and wash the items. Stubborn or dried-in stains can sometimes only be removed by washing several times.

### Care label specifications:

Cottons 95 °C, 90 °C
Coloureds 60 °C, 40 °C,
30 °C
Coloureds 60 °C, 40 °C,

™ ™ ™ Easy-Care 60 °C, 40 °C, 30 °C

Delicates 40 °C, 30 °C

₩ <u>₩</u> <u>₩</u>

Hand and machinewashable silk and woollens cold, 40 °C,

30 °C

1000

Do not wash laundry in the washing machine.

## Protecting your laundry and washer dryer:


#### Caution!

### Damage to the appliance/textiles

Foreign objects (e.g. coins, paper clips, needles, nails) may damage the washing or components of the washer dryer.

The following instructions must be observed when preparing your laundry:

- Always follow the manufacturer's instructions when dosing all detergents, cleaning aids, care products and cleaning agents.
- Do not exceed maximum load. Overfilling will impair the washing result.
- Keep detergents and agents for the pretreatment of laundry (e.g. stain remover, prewash sprays, etc.) away from the surfaces of the washer dryer. Using a damp cloth, immediately remove any fine spray residue and other residue or droplets.
- Empty any pockets. Remove any foreign objects.



Remove metal parts (paper clips, etc.).

- Trousers, knitwear and knitted textiles, e.g. jersey garments, T-shirts or sweatshirts, should be turned inside out.
- Ensure that underwired bras are machine-washable.
- Wash delicates in a net or bag (tights, underwired bras, etc).
- Close zips, button up covers.
- Brush sand out of pockets and collars.
- Remove curtain fittings or include in the net/bag.

## Preparing laundry for drying

**Note:** To ensure an even drying result, sort the laundry according to the:

- Type of fabric
- Drying programme
- Care symbols which are indicated on the care labels.

Only dry laundry which is labelled "dryer-proof" or which has the following care symbols:

- □ = Dry at normal temperature (Intensive Dry ※)
- ☐ = Dry at low temperature (Gentle Dry ☼ )

The following textiles must not be dried:

- ⊠ = care symbol "Do not dry"
- Wool or textiles containing wool.
- Delicates (silk, synthetic curtains).
- Textiles which contain foam rubber or similar materials.
- Textiles which were treated with flammable liquids, e.g. with stain remover, petroleum ether, thinners. Risk of explosion!
- Textiles which still contain hairspray or similar substances.

#### Notes

 Before drying, hand-washed textiles must be spun at the appropriate spin speed.

- Before drying, spin at the optimum speed. A spin speed of more than 1000 rpm is recommended for cotton, more than 800 rpm for easycare textiles.
- Do not iron washing immediately after drying. It is recommended to roll the washing up first to distribute residual moisture evenly.
- To ensure a good drying performance, quilts, terry cloths and other large textiles should be dried separately. Do not dry more than four terry cloths (or 3 kg).
- Do not exceed maximum load.



## Operating the appliance

### Preparing the washer dryer


The washer dryer was tested before delivery. To remove residual water from the test procedure, the first wash cycle should be run without laundry using the **Drum Clean** ® programme.

Before washing/drying for the first time → Page 42

#### Note:

- Never switch on a damaged washer
- Inform your customer service! → Page 35
- 1. Insert mains plug.
- 2. Turn the tap on.

The end of the drying programme is followed by an automatic fluff cleaning cycle. The tap must be turned on even when selecting a drying programme.



#### Note:

- Always provide good ventilation in the room where the washer dryer is located so that air produced during the drying phase can be evacuated.
- Always keep the inlets and outlets for the cooling air clear.
- 3. Open the door.






## Selecting the programme/ Switching on the appliance

#### Note:

If you have activated the childproof lock, you must deactivate it before you can set a programme.

Select the required programme with the programme selector. Can be rotated in either direction.

The washer drver is switched on.



The following figures are indicated continuously on the display panel for the selected programme:

- the programme duration (when door is closed),
- the preset temperature.
- the preset spin speed and
- the maximum load (when door is opened),

### Adjusting the washing programme

You can use the displayed default settings or adjust the selected programme optimally to the laundry items by changing the default settings or selecting additional functions. The selectable settings and additional

functions depend on selected washing/drying programme.

Overview of programmes → Page 20

#### **Notes**

- Options can be selected, deselected or changed depending on the progress of the programme.
- The buttons are sensitive, they only need to be touched gently. If the button °C (Temperature), ⊚ (Spin speed), ⊕ (Finish in) is held down, the setting options are automatically scrolled through.

# Changing default settings for a washing programme, e. g. washing temperature:

Touch the °C (Temperature) button to set desired washing temperature.



# Changing the additional functions for a washing programme, e.g. select =ℂ (SpeedPerfect):

■ Touch the =♥ (SpeedPerfect)
button; the indicator light comes on
and the additional function is
selected. To deselect the additional
function, touch the
=♥ (SpeedPerfect) button again,

and the indicator light goes off.



#### Note:

After changing the programme default settings and/or additional functions, the programme duration may change.

## Adjusting the drying programme

#### Note:

If an individual drying programme or washing and drying without interruption is selected, you can change the default settings for the drying programme if required.

Overview of programmes → Page 20

## Changing the defaut settings for a drying programme:

■ Touch the ☼ (Drying) button to set the desired drying mode or drying time (only for an individual drying programme).



#### Note:

After changing the default settings for the drying programme, the programme duration may change.

## Loading the laundry

## 

Laundry items pretreated with solventbased detergents, e.g. stain remover/ petroleum ether, may cause an explosion if loaded into the washer dryer.

Thoroughly rinse laundry items by hand before washing.

### Notes

en

- Mix large and small items. Laundry items of different sizes distribute themselves better during the spin cycle. Individual laundry items may cause an unbalanced load.
- Observe the indicated maximum load. Overfilling adversely affects the washing result and promotes creasing.
- 1. Unfold presorted laundry items and place in the drum.
- Ensure that no laundry items are trapped between the door and rubber seal.





3. Close the door.

Note: The indicator light on the DII Start/Reload button flashes and the default settings for the programme appear continuously on the display panel. Changes may be made to the default settings.

## Dosing and adding detergent and care product

## Caution! Damage to the appliance

Detergents and agents for the pretreatment of laundry (e.g. stain remover, prewash sprays, etc.) may damage the surfaces of the washer dryer.

Keep these agents away from the surfaces of the washer dryer. Using a damp cloth, immediately remove any fine spray residue and other residue/droplets.

#### Dosing

Dose the detergents and care products according to:

- water hardness (ask your water supply company),
- the manufacturer's specifications on the packaging,
- the amount of laundry,
- soiling.

#### Filling the dispensers


1. Pull out the detergent drawer.



#### Eye / skin irritation!

If the detergent drawer is opened while the appliance is running, detergent/care product may run out. Carefully open the drawer. If detergent/care product comes into contact with eyes or skin, rinse thoroughly. If accidentally swallowed, seek

medical advice.Pour in detergent and/or cleaning product.



Dispenser I Detergent for prewash.

Dispenser Softener, starch. Do not exceed the maximum load.

Dispenser **II** Detergent for main wash, water softener, bleach, stain remover.

Dispenser **A** For dosing liquid detergent.

#### **Notes**

 Always follow the manufacturer's instructions when dosing all detergents, cleaning aids, care products and cleaning agents.


- Dilute viscous fabric softener and fabric conditioner with water. This will prevent blockages.
- Be careful when opening the detergent drawer while the appliance is running.
- If an individual drying programme is selected, please do not add detergent and/or care product in the appliance.

#### Measuring aid\* for liquid detergent

\*depending on the model

Position the measuring aid for measuring the correct amount of liquid detergent:

- Pull out the detergent drawer. Press down the insert and fully remove the drawer.
- 2. Slide the measuring aid forwards, fold it down and click it into place.
- 3. Reinsert the drawer.



**Note:** Do not use the measuring aid for gel detergents and washing powder, or for programmes with prewash or when "Finish in" time is selected.

For models without a measuring aid, pour the liquid detergent into the appropriate dispenser and place it in the drum.

## Starting the programme

Select **Start**/Reload. The indicator lamp is lit and the programme starts.

**Note:** If you want to secure the programme to prevent it from being adjusted inadvertently, select the childproof lock.

The display panel shows the Finished in time while the programme is running or the programme duration and the programme progress symbols when the washing programme has started.

Display panel → Page 10

## Childproof lock

You can secure the washer dryer to prevent the set functions from being changed inadvertently. To do this, activate the childproof lock when the programme has started.

Activating/deactivating: Touch and hold the button ⊕ (**Finish in**) for approx. 5 seconds. The symbol ←o is indicated in the display. If the button signal is activated, an acoustic signal sounds.

- o lights up: The childproof lock is activated.
- → flashes: The childproof lock is active and the programme selector has been adjusted. To prevent the programme from terminating, reset the programme selector to the initial programme. The symbol lights up again.

#### Note:

The childproof lock may remain activated until the next programme starts, even after the washer dryer has been switched off. If this is the case, deactivate the childproof lock before the programme starts and, if required, reactivate after the programme starts.

## Reloading the laundry

When the programme has started, the laundry can be reloaded or taken out as required.

Select **N** Start/**Reload**. The washer dryer checks whether a reloading is possible.

#### **Notes**

- If there is a high water level, high temperature or if the drum is rotating, the door remains locked for safety reasons and reloading is not possible.
  - If the following is indicated on the display panel:
  - **A:02** + **PAUS** → Reloading is not possible. To continue the programme, select the **N** Start/ Reload button.
  - 0 + **OPEn** are lit  $\longrightarrow$  Reloading is possible.
- Do not open the door until both the symbols ① + OPEn are lit.
- Do not leave door open for a prolonged period - water could run out of the laundry.
- The reloading function cannot be activated during the drying phase.

## Changing the programme

If you have started the wrong programme by mistake, you can change the programme as follows:

- Select ▷ Start/Reload.
- 2. Select another programme. If required, adjust the default settings and/or select additional functions.
- 3. Select DI Start/Reload. The new programme starts from the beginning.

## Interrupting or ending the programme

For programmes at high temperature:

- Select D Start/Reload.
- 2. To cool down laundry: Select Rinse .
- 3. Select M Start/Reload.

For programmes at low temperature:

- Select ▷ Start/Reload.
- Select Spin ⑤/Drain ᇴ.
   Select ▷ Start/Reload.

For drying programmes:

- 1. Select Intensive Dry programme or Gentle Dry ☆.
- 2. Touch button (Drying) and set drying time to 15 minutes.
- 3. Select DI Start/Reload.

## End of the programme

-0 - or --- (Rinse stop = without final drain/spin cycle) is indicated in the display and acoustic signal sounds.

Setting the signal  $\rightarrow$  Page 27

If  $\Box$  (**Rinse stop** = without final drain/ spin cycle) was selected, press DM Start/Reload button to start the final drain/spin cycle.

#### **Notes**

- The programme continues by pumping out the water and spinning the laundry (the standard spin speed can be changed beforehand).
- If only the water is to be pumped out, approx. 1 minute after the programme starts, touch the Start/**Reload** button before the spin cycle starts, then turn the programme selector to • Off. The programme is interrupted and the door lock is released. The laundry can be removed.
- If **hot** flashes in the display before the drying programme ends, the temperature in the drum is high. The programme for cooling the drum runs until the temperature in the drum has dropped.

## After washing/drying

- 1. Open the door and remove the laundry.
- 2. Turn the programme selector to • Off. The appliance is switched off.
- 3. Turn off the tap.


Not required for Aqua-Stop models.

 $\rightarrow$  Page 37



#### **Notes**

- Do not leave any items of laundry in the drum. In the next wash they may shrink or discolour another item.
- Remove any foreign objects from the drum and the rubber seal – risk of rust.



- Leave the detergent drawer and door open so that residual water can evaporate.
- Always remove the laundry.
- Always wait until the programme ends, as the appliance could still be locked. Then switch the appliance on and wait for the unlocking device.
- When the display panel has gone out at the end of the programme, energy-saving mode is active. To activate, select any button.



## Programme on the programme selector

Programme/Type of washing	Options/Information
Name of the programme Brief explanation of the programme and which textiles it is suitable	maximum load according to EN50229
for.	maximum load for washing/
	maximum load for drying
	selectable temperature in °C
	selectable spin speeds in rpm
	possible additional functions for washing
	possible settings for drying
Cottons 🏠	max. 7(4)* kg/4 kg
Standard washing program for hard-wearing textiles made of cotton	<b>※</b> (cold) – 90 °C
or linen. Note:	<b>─</b> – <b>1400</b> rpm
* Reduced load for = additional functions.	=Ü, @, ₩, <u>Z</u>
	Aut 1, Aut 2
+ Prewash <b></b>	max. 7(4)* kg/4 kg
Energy-intensive program for heavily soiled hard-wearing textiles	<b>※</b> (cold) – 90 °C
made of cotton or linen.  Note:	<b>─</b> – <b>1400</b> rpm
* Reduced load for = additional functions.	=Ü, ®, ₩, <u>Z</u>
	Aut 1, Aut 2
Easy-Care ☆	max. 3.5 kg/2.5 kg
Textiles made of synthetic materials or blended fabrics.	<b>※</b> (cold) – 60 °C
	<b>─</b> – <b>1000</b> rpm
	=Ü, ®, ₩, <u>Z</u>
	Aut 1, Aut 2
Mixed Load ☎A	max. 3.5 kg/2.5 kg
Mixed load consisting of textiles made of cotton and synthetics.	<b>※</b> (cold) − 60 °C
	<b>─</b> - <b>1400</b> rpm
	=Ü, ®, ₩, <u>Z</u>
	Aut 1, Aut 2

Programme/Type of washing	Options/Information	
Delicate/Silk 🖔	max. 2 kg	
For delicate, washable textiles, e.g.made of silk, satin, synthetic	★ (cold) – 40 °C	
fibres or blended fabrics.	<b>─</b> – <b>800</b> rpm	
Note: Use a detergent suitable for machine washable delicate fabrics or	=U, ₩, <u>2</u>	
silk.	-	
₩ Wool 8	max. 2 kg	
Hand and machine-washable fabrics made of wool or wool blend;	<b></b> (cold) − 40 °C	
particularly gentle wash programme to prevent shrinkage of laundry, with longer programme breaks (soaking garments in the deter-	<b>─</b> – <b>800</b> rpm	
gent solution).	-	
Note:	-	
<ul><li>Wool is of animal origin, e.g.: Angora, alpaca, llama, sheep.</li><li>Use a detergent suitable for machine washable wool.</li></ul>		
Rinse w	max. 7 kg	
Washable textiles, Extra rinse with spin.	-	
	── - 1400 rpm	
	<b>₩</b> , <u></u>	
	-	
Spin ⑥ / Drain ∜	max. 7 kg	
Single spinning program with selectable spin speed.	-	
To select the <b>Drain</b> F programme, touch the <b>O II Start</b> /Reload but-	<b>400</b> – <b>1400</b> rpm	
ton to start programme. After approx. 1 minute before the spin cycle starts, touch the <b>D M</b> Start/ <b>Reload</b> .	2	
otality, rough and grant of the state of the	-	
SuperQuick 15' <sup>™</sup> /Wash&Dry 60' <sup>™</sup>	max. 3.5(2.0)* kg/1 kg	
For small amount (≤1kg) lightly soiled garments made of cotton,	<b>※</b> (cold) – 40 °C	
linen, synthetic or blended fabrics. Approx. 15 mins for washing. If drying function is selected, it's followed by another approx. 45 mins	<b>─</b> - <b>1000</b> rpm	
drying process.	=₩, ₩	
Note:  * Reduced load for =♥ additional functions.	Aut 1	
HygieneCare ♂	max.4 kg/4 kg	
An innovative program, pretreat dry laundry by hot air (up to 70°C)	★ (cold) - 40 °C	
to for increased hygienic demands, followed by a low temperature	<b>─</b> - <b>1400</b> rpm	
washing cycle. Achieves both hygiene effect and fabric care. Suitable for most non-delicate textile.	( ) ( ) ( ) ( ) ( ) ( ) ( ) ( ) ( ) ( )	
SIG TOT THOSE TOT GOTTOUT CONTINUE	Aut 1, Aut 2	
	. ,	

## **en** Overview of programmes

Programme/Type of washing	Options/Information
Allergy+ ⊕	max. 7(4)* kg/4 kg
Hardwearing textiles made of cotton or linen.	<b>※</b> (cold) – 60 °C
Notes	<b>─</b> – <b>1400</b> rpm
<ul> <li>Especially suitable for increased hygienic demands or particularly sensitive skin on account of prolonged washing at a</li> </ul>	=U, @, ₩, <u>Z</u>
defined temperature, with a higher water level and longer rins-	Aut 1, Aut 2
ing cycle.	
■ * Reduced load for = ① additional functions.	
Drum Clean	-
Special program for drum hygiene or fluff removal:	★ (cold), 40, 90 °C
90 °C = antibacterial program, do not use detergent.	<b>400</b> – <b>1400</b> rpm
40 °C = antibacterial program; special drum cleaning detergent can	-
be used.  ** (acid) = ringing programme for the removal of fluff which has call.	-
★ (cold)= rinsing programme for the removal of fluff which has collected in the washer drum during the drying phase.	
Refresh ∜	max. 1 kg
Odour removal and wrinkle reduction program, suitable for wool,	-
linen, suits, etc. which do not need frequent washing.	-
	-
	-
Gentle Dry 🌣	max. 2.5 kg
Single gentle dry programme for drying garments with lower tem-	-
perature,	-
<ul> <li>by selecting Aut1 to achieve automatic cupboard dry result,</li> <li>by selecting Aut2 to achieve automatic extra dry result,</li> </ul>	-
- self-defined drying time selectable from 30, 60, 90 to 120 mins	Aut 1, Aut 2, Time dry**
Note:	7 (at 1,7 (at 2, 1111) ary
** 15 min drying time is for cooling down the laundry and machine	
after drying process.  Intensive Dry 🌣	max. 4 kg
Single normal dry program for drying garments with higher tempera-	IIIax. 4 Ng
ture.,	
- by selecting Aut1 to achieve automatic cupboard dry result,	
<ul> <li>by selecting Aut2 to achieve automatic extra dry result,</li> <li>self-defined drying time selectable from 30, 60, 90 to 120 mins.</li> </ul>	-
Note:	Aut 1, Aut 2, Time dry**
** 15 min drying time is for cooling down the laundry and machine	
after drying process.	

## **Drying table**

kitchen towels)									
Dry weight	in kg	0,5 ~1,0	1,0 ~ 2,0	2,0 ~ 3,0	3,0 ~,0	~ 0,5	~ 1,0	~ 2,0	~ 2,5
		E	stimated dr	ying time in ı	min	Adjusta	able dry	ng time	in min
Cupboard dry	Aut1	< 60	60 ~ 85	85~120	120 ~ 160	30	60	90	120
Extra dry	Aut2	< 65	65 ~ 100	100 ~140	140~170				
Recommen programme			Intensive	<b>Dry</b> 淡 (Auto)		Inte	nsive Di	<b>'y</b> 淡 (Ti	me)
Quilt/terry		rger or thick ans~, work o		e of cotton suc	ch as terry clot	hs, bed s	sheets, ta	ble cloth	IS,
Dry weight	in kg	0,5 ~1,0	1,0 ~ 2,0	2,0 ~3 ,0	3,0 ~ 4,0	~ 0,5	~ 1,0	~ 1,5	~ 2,0
		E	stimated dr	ying time in ı	min	Adjusta	able dryi	ng time	in min
Cupboard dry	Aut1	< 70	70~95	95 ~ 13	130 ~ 170	30	60	90	120
Extra dry	Aut2	< 75	75 ~ 110	110 ~ 150	150 ~ 180				
Recommen programme		Intensive Dry 🌣 (Auto) Intensive Dry 🌣 (Time)			me)				
Easy-care (Textiles made of synthetic or blended fabrics such as shirts, sportswear, delicate items)									
Dry weight	in kg	0,5 ~1,0	1,0 ~ 2,0	2,0 ~ 2,5		~ 0,5	~ 1,0	~ 1,5	~ 2,0
	Estimated drying time in min Adjustable drying time in min				in min				
Cupboard dry	Aut1	< 55	55 ~ 95	95 ~ 130		30	60	90	120
Extra dry	Aut2	< 65	65 ~ 130	130 ~160					
Recommen programme			Gentle D	<b>ry</b> -☆- (Auto)		Ge	entle Dry	∕-¦∴ (Tim	ie)
$ \begin{array}{ll} \textbf{i} & \text{The times are approximate and refer to a normal load, standard spin programme and room temperature.} \\ \textbf{i} & \text{The maximum selectable drying time is } 120 \text{ min. If the laundry weighs more than } 2.5 \text{ kg, select automat-} \\ \end{array} $									

Cottons/coloureds (textiles made of cotton or linen such as underwear, T-shirts, sweaters, trousers,

The times are approximate and refer to a normal load, standard spirit programme and room temperature.
The maximum selectable drying time is 120 min. If the laundry weighs more than 2.5 kg, select automatic drying. This function is recommended to ensure good drying results and save energy. The 15-minute drying programme is used to cool the laundry.

#### en

## **Starching**

**Note:** The laundry should not be treated with fabric softener.

Liquid starch can be used in all wash programmes. Pour starch into the dispenser & according to manufacturer's specifications (if required, clean beforehand).

## **Dyeing/Bleaching**

Dye in household quantities only. Salt may attack stainless steel! Observe specifications of the dye manufacturer! **Do not** bleach laundry in the washer dryer!

## Soaking

- Pour soaking agent/detergent into dispenser II according to the manufacturer's instructions.
- 2. Set the programme selector to Cottons ② 60°C and select D Start/Reload.
- 3. After approximately 10 minutes select **∑** Start/**Reload**.
- 4. After the required soaking time, reselect DII Start/Reload if the programme is to be continued or change the programme.

#### Note:

Load laundry of the same colour. No additional detergent is required, the soaking solution is used for washing.

# Changing programme default settings

You can change the default settings for selected programmes. The settings can be changed even while the selected programme is running. The effects depend on the progress of the programme.



## °C (Temperature)

The indicated washing temperature can be changed. The maximum selectable washing temperature varies depending on the selected programme.

Overview of programmes → Page 20

## (Finish in)

2: Delays the Finish in time (end of programme).

#### Note:

The respective programme duration is displayed by selecting the programme. The programme duration is automatically adjusted while the programme is running if the programme duration needs to be changed, e.g. due to changes in the programme default settings.

Before the programme starts, the end of the programme can be preselected in hourly increments up to a maximum of **24h**.

When the programme has started, the preselected time is displayed e.g.8h

and counts down until the programme starts. Then the programme duration is displayed, e.g. **2:30**.

When the programme has started, the preselected time can be changed as follows:

- Select D Start/Reload.
- 2. Select the () (Finish in) button and change the Finish in time.
- 3. Select M Start/Reload.

## (Spin speed)

3: The spin speed can be changed before and during the programme (in rpm, revolutions per minute) depending on the progress of the programme. Setting  $\Box$  (Rinse stop = without final drain/spin cycle), laundry remains in the water after the last rinse cycle. The maximum spin speed depends on the programme and model.

Overview of programmes → Page 20

## (Drying)

4: The drying function can be activated, deactivated and set with this button. Washing and drying without interruption is possible in automatic mode only. If the programme for individual drying is selected, automatic drying or timed drying with a required drying duration is available.

#### **Notes**

Programme selection in Intensive **Dry** ☼ or **Gentle Dry** ☼ position to select an individual drying programme. Overview of programmes → Page 20 The standard drying mode is **Aut1**. In this mode the drying time is automatically set according to the amount of laundry to be dried. The result is cupboard-dry laundry. Drying mode can be set to Aut2 in order to obtain an extra dry result; or preselect the drying time which can be specified by selecting the 🌣 (**Drying**) button.

Cupboard dry (Aut1): For singlelayer fabrics. Garments can be folded or hung up in a cupboard. Extra dry (Aut2): For fabrics made of thick, multilayered items of clothing, which need to be dried longer. Garments can be folded or hung up in a cupboard. Laundry more dry than Cupboard dry.

- Programme selection in washing programmes and if washing and drying is required without interruption (only for Cottons ⑫, +Prewash Ϣ, Easy-Care 鼑, Mixed Load ⑫씨, SuperQuick 15' ஂ and Allergy+ ⑭).
- 1. Touch button (Drying) and activate the function Aut1 or Aut2.
- Do not exceed the maximum loads for drying.
   Overview of programmes → Page 20
- Maximum spin speed for the washing programme will be selected automatically to obtain a good drying result.

#### en

# P\* Selecting additional functions

You can select your desired additional functions by touching the respective buttons.



## = (SpeedPerfect)

1: For a shorter wash time with a comparable washing effect to the standard programme.

**Note:** Do not exceed maximum load. Overview of programmes → *Page 20* 

## @ (EcoPerfect)

2: Energy-optimised washing by reducing the temperature while achieving a consistent washing result.

**Note:** The washing temperature is lower than the selected temperature. For special hygiene requirements, the **Allergy+** Programme is recommended.


## (Rinse plus)


3: Additional rinse cycle. For areas with very soft water or for an even better rinsing result.


## 

4: Special spin sequence with subsequent fluffing. Gentle final spin – residual moisture in the laundry increased slightly.

## Setting the signal







## Cleaning and maintenance

### 🗥 Warning

#### Risk of electric shock!

Danger of death if live parts are touched.

Switch off the appliance and disconnect at the mains plug.



### **M** Warning Risk of poisoning!

Solvent-based cleaning agents, e.g. petroleum ether, in the washer dryer may cause toxic vapours.

Do not use solvent-based cleaning agents.

### Caution!

#### Damage to the appliance

Solvent-based cleaning agents, e.g. petroleum ether, may damage the surfaces and components of the washer drver.

Do not use solvent-based cleaning agents.

## Machine housing/Control panel

- Immediately remove washing and cleaning agent residue.
- Wipe with a soft, damp cloth.
- Do not use abrasive cloths, sponges or detergents (stainless steel cleaner).
- Do not clean the appliance with a water iet.

### Drum

Use chlorine-free cleaning agents, do not use steel wool.

1. Turn the tap off to prevent more water from flowing in and to ensure


### **Descaling**

Not required if detergent dosed correctly. However, if this does occur, follow the instructions of the descaling agent manufacturer. Suitable descalers can be purchased on our website or from customer service.  $\rightarrow$  Page 35

## Cleaning the detergent dispenser

If it contains detergent or fabric softener residue:

- 1. Pull out the detergent drawer. Depress the insert and remove the drawer completely.
- 2. Take out insert: using your finger, press insert upwards.



- 3. Clean the detergent dispenser and insert with water and a brush and
- 4. Attach the insert and lock into position (push the cylinder onto the guide pin).
- Insert detergent drawer.

**Note:** Leave the detergent drawer open so that residual water can evaporate.

## **Drain pump blocked**




### Marning ( Risk of scalding!

Washing water is hot when washing at high temperatures. You may be scalded if you touch the hot washing water. Allow the washing water to cool down.

that it is drained via the detergent solution pump.

- Turn the programme selector toOff. Pull out the mains plug.
- 3. Open the service flap.
- **4.** Take the drainage hose out of the holder.






Remove the cover flap, draining the washing water into a suitable container. Press on the cover flap and insert the drainage hose into the holder.

Note: Residual water may run out.

- Carefully unscrew the pump cover. Clean the interior, pump cover thread and pump housing (the fan impeller in the detergent-solution pump must be able to rotate).
- Reinsert and screw on the pump cover. Handle should be vertical.






 Close the service flap. If required, engage the disengaged service flap beforehand.

Note: To prevent unused detergent from flowing into the outlet during the next wash: Pour 1 litre of water into dispenser II and start the Spin © / Drain \( \).

## Drainage hose on the siphon blocked

Turn the programme selector to
 Off. Pull out the mains plug.

- Loosen hose clip, carefully remove drainage hose. Residual water may run out.
- 3. Clean drainage hose and siphon spigot.



**4.** Re-attach the drainage hose and secure the connection point with the hose clip.

## Filter in the water inlet hose blocked


## 

Do not immerse the Aqua-Stop safety device in water (it contains an electric valve).

First, reduce the water pressure in the supply hose:

- 1. Turn off the tap.
- 2. Select any programme (except **Spin** ⑤/**Drain** ③).
- Select **N** Start/Reload . Allow the programme to run for approx. 40 s.
- 4. Turn the programme selector toOff. Pull out the mains plug.
- Clean the filter on the tap: Disconnect the hose from the water tap.

Clean the filter with a small brush.




**6.** Clean the filter on the back of the appliance:

en

Remove the hose from the rear of the appliance.


Take out the filter with pliers and clean it.



7. Connect the hose and check for leaks.


#### Air filter blocked

- 1. Turn the programme selector to • Off. Pull out the mains plug.
- 2. Open and remove the service flap.
- 3. Take out the air filter.



- 4. Rinse fluff off the air filter using a brush under running water.
- 5. Re-insert the air filter.
- 6. Re-insert and close the service flap.





## **?** Faults and what to do about them

## Emergency release, e.g. if a power failure occurs

The programme continues running when the power supply is restored. If the washing is still to be removed, the door can be opened as described below:

### **Warning**

### Risk of scalding!

When washing at high temperatures, you may be scalded if you touch hot washing water or the laundry. If required, leave to cool down.

## 🔼 Warning

### Risk of injury!


If you reach into the rotating drum, you may injure your hands.

Do not reach into the rotating drum. Wait until the drum stops rotating.

#### Caution! Water damage

Leaking water may cause damage. Do not open the door if you can still see water through the glass.

- 1. Turn the programme selector to • Off. Pull out the mains plug.
- 2. Drain the detergent solution.
- 3. Pull down emergency release with a tool and release. Door can then be opened.



# Information on the display panel

Display	Cause/Remedy
A:01	Close the door immediately because of the rising water level. If an interruption occurs, <b>A:01</b> and <b>OPEn</b> are displayed alternately.
A:02	The door is locked for safety reasons (water level and/or temperature too high).  ■ Washing programme: In pause mode A:02 and PAUS are displayed alternately. If you have to open the door, wait until the temperature has dropped slightly or pump out the water (select e.g. Spin ③ / Drain ❤).  ■ Drying programme: If you have to open the door, wait until the temperature has dropped slightly or set the drying programme to 15 min to cool down the laundry.
	If <b>A:02</b> is frequently displayed at the end of the drying programme:  ■ Clean the air filter. → Page 30  ■ Run the <b>Drum Clean</b> ® ★ (cold) programme without laundry.
A:03	Door cannot be locked/unlocked due to high temperature. Leave the washer dryer switched on for about 1 min. The washer dryer can then be locked/unlocked again.
hot	The door cannot be opened after the drying programme due to the high temperature. The cooling process continues until the display disappears, after which the door can be opened.
<u>~</u>	■ Flashes (no water supply): Tap turned on? Water inlet filter blocked? Clean the water inlet filter. → Page 29 Water hose kinked or blocked?
	■ <b>Lights up</b> (low water pressure): For information only. This will not affect the programme progress. The programme duration is extended.
E:18	Drain pump blocked; clean the drain pump. Clean the drainage hose on the siphon.
===	<ul> <li>Hold down button ☼ (<b>Drying</b>) for 3 seconds to delete the display.</li> <li>Clean the air filter. → Page 30</li> <li>Run the <b>Drum Clean</b> ® ★ (cold) programme without laundry.</li> </ul>
LO kg, HI kg	Laundry amount information. On when drying phase finished. <b>LO kg</b> : Signals a small load for drying, <b>HI kg</b> : Signals a very high load for drying.
Other displays	Turn the programme selector to • Off. The appliance is switched off. Wait 5 s and switch on again. If the display is indicated again, call customer service.

## Faults and what to do about them

Faults	Cause/Remedy
Water is running out.	<ul><li>Correctly attach/replace drainage hose.</li><li>Tighten screw-fitting on the supply hose.</li></ul>
Water not flowing in. Detergent not dispensed.	<ul> <li>D  Start/Reload not selected?</li> <li>Tap not open?</li> <li>Filter blocked? Clean the filter → Page 29</li> <li>Supply hose kinked or jammed?</li> </ul>
The washing machine door cannot be opened.	<ul> <li>Safety function active. Stop programme?</li> <li></li></ul>
Programme does not start.	<ul> <li>Dil Start/Reload or (Finish in) selected?</li> <li>Door closed?</li> </ul>
Detergent solution is not drained.	<ul> <li>□ (Rinse stop = without final drain/spin) selected?</li> <li>□ Clean the drain pump. → Page 28</li> <li>□ Clean outlet pipe and/or drainage hose.</li> </ul>
Water not visible in the drum.	Not a fault – water below the visible area.
Spin result not satisfactory. Laundry wet/too damp.	<ul> <li>Not a fault – unbalanced load detection system has stopped the spin cycle, washing unevenly distributed. Distribute small and large items of washing in the drum.</li> <li>Too low speed selected?</li> </ul>
Spin cycle activated several times.	Not a fault – unbalanced load detection system adjusts imbalance.
Residual water in the dispenser for care product.	<ul> <li>Not a fault – effect of the care product not impaired.</li> <li>If required, remove the insert. Clean the detergent drawer and re-insert it.</li> </ul>
Compartment & is not rinsed out completely.	Remove the insert. Clean the detergent drawer and reinsert it.
Odour formation in the washer dryer.	<ul> <li>Run the <b>Drum Clean ©° 90°C</b> programme without laundry.</li> <li>Use standard detergent.</li> </ul>
Status display 🕾 flashes. Foam may come out of the detergent drawer.	<ul> <li>Too much detergent used?</li> <li>Mix 1 tablespoon of fabric softener with ½ litre of water and pour into dispenser II. (Not for outdoor, sports and down-filled textiles!)</li> <li>Reduce detergent dosage for the next wash cycle.</li> <li>Use commercially available low foam detergent and care products which are suitable for washer dryers.</li> </ul>
Excessive noise, vibrations and "wandering" during the spin cycle.	<ul> <li>■ Appliance aligned? Align the appliance. → Page 42</li> <li>■ Appliance feet fixed? Secure appliance feet. → Page 42</li> <li>■ Transportation protection devices removed? Removing the transportation protection devices → Page 39</li> </ul>

Faults	Cause/Remedy
Display panel/indicator lights do not function while the appliance is running.	<ul> <li>■ Power failure?</li> <li>■ Fuse tripped? Switch on/replace fuse.</li> <li>■ If the fault occurs repeatedly, call customer service. → Page 35</li> </ul>
The programme duration changes during the wash cycle.	<ul> <li>Not a fault – unbalanced load detection system adjusts imbalance.</li> <li>Not a fault – foam detection function active. Additional rinse cycle.</li> </ul>
Detergent residue on the washing.	<ul> <li>Occasionally phosphate-free detergents contain water-insoluble residue.</li> <li>Select Rinse w or brush items when the laundry is dry.</li> </ul>
Spin noise during the drying phase.	This is an innovative process known as thermal spinning used to reduce energy consumption during the drying phase.
Different coloured fluff from the previous drying cycle is deposited on the laundry during the subse- quent wash cycle.	Run the <b>Drum Clean *</b> (cold) programme without laundry to remove fluff which has collected in the washer drum during the drying phase.
Water inlet noise during the drying phase, the tap symbol flashes during the drying phase.	The washer dryer runs a self-cleaning cycle to remove fluff which was deposited by the laundry during the drying phase. This requires a little water. Therefore, the tap must be turned on even during the drying phase.
Drying duration extended.	<ul> <li>According to the air cooling principle, a higher ambient temperature will result in poor drying performance, so the drying time will be extended. Ensure good ventilation to allow surplus heat to escape.</li> <li>Air filter blocked? Clean the air filter → Page 30</li> <li>Run the Drum Clean  (cold) programme to remove fluff which has collected in the washer drum during the drying phase.</li> </ul>
Drying programme does not start.	<ul> <li>■ Drying programme not selected? Overview of programmes → Page 20</li> <li>■ Door not closed properly?</li> <li>■ Pump blocked? Clean the drain pump → Page 28</li> </ul>

#### en Faults and what to do about them

Faults	Cause/Remedy
The drying result is not satisfactory (laundry is not dry enough).	<ul> <li>Excessively high ambient temperature (above 30 °C) or inadequate ventilation in the room in which the washer dryer is situated. Ensure adequate ventilation to allow surplus heat to escape.</li> <li>The laundry has not been spun well enough before drying. Always set the highest selectable spin speed for the particular washing programme.</li> <li>Washer dryer overloaded: Observe the recommendations for the maximum load in the programme table and on the load display. Do not overload the washer dryer, as the maximum load for the drying phase is less than the maximum load for the wash cycle. Unload the washer dryer after washing with the maximum load and divide the laundry into two drying cycles.</li> <li>The power supply voltage is too low (below 200 V) – provide a suitable power supply.</li> <li>Air filter blocked? Clean the air filter → Page 30</li> <li>Thick multilayered textiles or textiles with thick fillings dry easily on the surface, but not inside. This equalisation process may take longer. For these types of textiles, select the timed drying programmes.</li> </ul>
When the door is opened, you will notice that a small amount of water drips onto the dried laundry.	<ul> <li>The drying time is reduced for a smaller load. Some residual moisture may remain in the dryer system. If the door is opened quickly, a suction effect is generated which causes the moisture to drip out of the dryer system.</li> <li>Open the door slowly. Avoid wrenching the door open.</li> </ul>

If a fault cannot be rectified (switching the machine on and off) or a repair is required:

- Set the programme selector to Off and pull out the mains plug.
- Turn off the tap and call customer service.  $\longrightarrow$  Page 35

## **Customer service**

If you cannot correct the fault yourself, see section, Faults and what to do about them  $\rightarrow$  Page 32

Please contact our customer service. We will always find a suitable solution and aim to avoid unnecessary visits by technicians

Please give customer service the product number (E-Nr.) and the production number (FD) of the appliance.



You can find this information on: the inside of the door \*/opened service flap \* and the back of the appliance.

\*depending on model

## Rely on the competence of the manufacturer.

Contact us. You can therefore be sure that the repair is carried out by trained service technicians who carry original spare parts.



Dimensions (width x depth x height)	60 x 59 x 84,5 cm		
Weight	83 kg		
Mains connection	Nominal voltage 220-240 V, 50 Hz		
	Maximal current 10 A		
	Maximal washing power 2400 W		
	Maximal drying power 1900 W		
Water pressure	100-1000 kPa (1-10 bar)		
Drain height	60-100 cm		

## **Consumption values**

Programme	Option	Load (kg)	Energy consumption *** (kWh)	Water Consumption ** * (liter)	Programme duration *** (hours)
Cottons 😭 20 °C *		7,0	0,23	73	2 3/4
Cottons 🏗 40 °C *		7,0	1,02	73	2 3/4
Cottons 🏗 60 °C		7,0	1,10	73	2 3/4
Cottons 😭 90 °C		7,0	2,05	83	2 3/4
Easy-Care ☆ 40 °C *	@ (EcoPerfect)	3,5	0,56	60	1 3/4
Mixed Load 😘 40 °C		3,5	0,45	53	1
Delicate/Silk \$\mathcal{L}_{90}\$ 30 °C		2,0	0,15	29	3/4
<b>8</b> Wool <b>3</b> 30 °C		2,0	0,18	40	3/4
Intensive Dry 🌣		4,0	2,47	3,0	2 ½
Gentle Dry -¤-		2,5	1,46	3,0	2
Cottons 🏗 60 °C **	(EcoPerfect)	7,0	0,70	51	4
Cottons <b>1</b> 60 °C + Intensive Dry ***	@ (EcoPerfect)	7,0/4,0	4,76	57	8 ½

Programme setting for tests according to currently valid EU standard EN60456. For comparison test, please test the programs with specified load and maximum spin speed.

<sup>\*\*</sup> EU energy label wasing performance tests according to EN50229, are conducted using specified load on **Cottons ?** 60 °C + **(EcoPerfect)**.


<sup>\*\*</sup> EU energy label drying performance tests are conducted according to EN50229. Maximum washing load is divided into 2 drying cycles and each drying load is dried by using **Intensive Dry** \* + **Aut1** option.

<sup>\*\*\*</sup> The values may deviate from the stated values depending on the following factors: water pressure and hardness, inlet temperature, ambient temperature, type and amount of laundry, type and amount of detergent used, fluctuation of power supply and additional functions selected.

# Installation and connection

#### Standard accessories

**Note:** Check the washer dryer for damage sustained in transit. Do not switch on a damaged washer dryer. If you have any complaints, contact the dealer where you purchased the appliance or our customer service.



#### Depending on the model:

A Aqua-Stop

3 Water drainage hose

B Aqua-Secure

4 Operating and installation instructions

C Standard

5 Elbow for fixing the water drainage hose

1 Water supply

6 Covers

2 Power cord

#### Note:

A hose clip  $\emptyset$  24–40 mm (specialist store) is also required for connection to a siphon.

Connecting the water → Page 40

#### **Useful tools:**

- Spirit level for alignment → Page 42
- Size 13 socket wrench: for loosening the transportation protection devices → Page 39 and size 17: for aligning the appliance feet → Page 42

#### Installation

**Note:** Humidity in the drum is caused by the final inspection.

#### Secure installation

## **⚠** Warning Risk of injury!

- The washer dryer is heavy. Take care when lifting it.
- When lifting the washer dryer by its projecting parts (e.g. washer dryer door), the parts may break off and cause injuries. Do not lift the washer dryer by its

Do not lift the washer dryer by its projecting parts.

If the hoses and power cables are

installed incorrectly, there is a risk of stumbling and injury.
Lay hoses and cables in such a way that there is no risk of stumbling.

## Caution! Damage to the appliance

- Frozen hoses may tear or burst. Do not install the washer dryer outdoors and/or in an area where there is a risk of frost.
- When lifting the washer dryer by its projecting parts (e.g. washer dryer door), the parts may break off and cause injuries.

Do not lift the washer dryer by its projecting parts.

#### Installation area

**Note:** Stability is important to prevent the washer dryer from wandering!

- The installation area must be firm and level.
- Soft floors and floor coverings are not suitable.
- To ensure good drying results, ensure that the room is well ventilated.

# Installing the appliance on a base or on a wooden joist ceiling

## Caution! Damage to the appliance

The washer dryer may wander during the spin cycle and topple or fall off its base.

Always secure the washer dryer feet with holding brackets. Holding brackets: order no.

WMZ 2200, WX 975600, CZ 110600, Z 7080X0.

**Note:** If installing on a wooden joist ceiling:

- If possible, install the washer dryer in a corner.
- Screw water-resistant wooden board (min. 30 mm thick) to the floor.


## Installing the appliance under/between kitchen units



#### Risk of electric shock!

Danger of death if live parts are touched.

Do not remove the appliance cover. Build under/build in before connection to the power supply.



During the drying phase, warm air is emitted at a temperature of up to 60 °C.

#### Notes

- Required dimensions:
  - a = 650 mm
  - b = 620 mm
  - c = 850 mm




- Only install the washer dryer under a continuous worktop connected firmly to the adjacent cupboards.
- Ventilate the installation area well, otherwise the optimum drying results will not be achieved. Dimensions of the ventilation openings (to be provided on one side, depending on the circumstances). Opening cross-section: d x e = 200 mm x 100 mm. Height above floor: f = 365 mm. Distance between wall and appliance: 50 mm.

## Removing the transportation protection devices


## Caution! Damage to the appliance

- Before using the washer dryer for the first time, it is essential to remove all 4 transportation protection devices. Keep the transportation protection devices. The washer dryer is secured for transportation with transportation protection devices. Transportation protection devices which have not been removed may damage the drum, for example, while the washer dryer is running.
- To prevent damage in transit when transporting the appliance at a later date, always re-install the transportation protection devices prior to transportation → Page 43




Keep the screw and sleeve screwed together.

- 1. Take the hoses out of the holders.
- 2. Take hoses out of the elbow and remove the elbow.
- 3. Loosen and remove all 4 transportation lock screws.



**4.** Take the power cord out of the holders. Remove the sleeves.




Insert the covers. Lock firmly by pressing on the locking hook. Insert the hose holder.




### Hose and cable lengths

#### Connection on left side



0

### Connection on right side



**Note:** If the hose holders are used, the possible hose lengths are reduced!

## Available from dealer/customer service:

- Extension for Aqua-Stop or cold water inlet hose (approx. 2.50 m). Order no. WMZ 2380, WZ 10130, CZ 11350, Z 7070X0.
- Longer supply hose (approx. 2.20 m), for standard model.

## **Connecting the water**



Danger of death if live parts come into contact with water.

Do not immerse the Aqua-Stop safety device in water (it contains an electric valve).

### Caution! Water damage

The connection points for the water supply and water drainage hoses are under high pressure. To prevent leakage or water damage, always follow the instructions in this chapter!

#### **Notes**

- In addition to the safety information listed here, the local water and electricity supplier may have special requirements.
- Operate the washer dryer with cold drinking water only.
- Do not connect the washer dryer to the mixer tap of an unpressurised hot water boiler.
- Use only the inlet hose supplied or one purchased from an authorised specialist outlet. Never use an used one!
- If in doubt, have the appliance connected by a technician.


## Water supply

#### **Notes**

- Do not kink, crush, alter or cut through the water supply hose (otherwise, its strength can no longer be guaranteed).
- Only tighten the screw connections by hand. If the screw connections are tightened too tightly using a tool (pliers), the threads may be damaged.

## Optimum water pressure in the mains: 100–1000 kPa (1–10 bar)

- When the tap is turned on, the water flow is at least 8 l/min.
- If the water pressure is higher, install a pressure reducing valve.
- Connect the water supply hose to the tap (¾" = 26.4 mm) and to the appliance (except models with Aquastop):
  - Standard






Agua-Secure



Aqua-Stop



Carefully turn on the tap and check that the connection points are not leaking.



**Note:** The screw connection is under water pipe pressure.

## Water drainage

#### **Notes**

- Do not kink or overextend the water drainage hose.
- Height difference between the placement area and drainage point: Minimum 60 cm – maximum 100 cm

## Drainage into a wash basin

## 

When washing at high temperatures, you may be scalded if you touch the hot washing water (e.g. if draining hot washing water into a washbasin). Do not touch the hot washing water.

### Caution! Water damage

If the attached drainage hose slips out of the washbasin due to high water pressure when draining the appliance, leaking water may cause damage. Secure the drainage hose to prevent it from slipping out of the washbasin.

#### Caution!

### Damage to appliance/textiles

If the end of the drainage hose is immersed in the drained water, water may be drawn back into the appliance and damage the washer dryer and/or textiles.

#### Ensure that:

- the sealing plug does not block the outflow of the washbasin.
- the water drains quickly enough.
- the end of the drainage hose is not immersed in the drained water.

#### Installing the drainage hose:






## Drainage into a siphon

The connection point must be secured with a Ø 24–40 mm hose clip (specialist store).

#### Connecting



# Drainage into a plastic pipe with rubber sleeve or into a gully

### Connecting



## **Alignment**

height.

- Loosen the lock nut in a clockwise direction with a wrench.
- Check the alignment of the washer dryer with a spirit level and, if required, correct. Adjust the height by rotating the appliance foot.
   Note: All four appliance feet must be firmly on the floor.
   The washer dryer must not wobble!
- Tighten the lock nut against the housing.
   Grip the foot and do not adjust the

#### **Notes**

- The lock nuts on all four appliance feet must be screwed tightly against the housing!
- Any loud noises, intense vibrations or "wandering" may be due to incorrect alignment!

### **Electrical connection**

### **Electrical safety**

### 

Danger of death if live parts are touched.

- When disconnecting the main plug, always pull the plug itself and not the cable, otherwise the cable could be damaged.
- Never touch or hold the mains plug with wet hands.
- Never pull out the mains plug during operation.

- Only connect the washer dryer to an alternating current using a correctly installed earthed socket.
- The mains voltage must be the same as the voltage specifications on the washer dryer (appliance rating plate).
- The connected load and the required fuse are also indicated on the appliance rating plate.

#### Ensure that:

- The mains plug and socket match.
- The cable cross-section is adequate.
- The earthing system has been installed correctly.
- A damaged power cord is only replaced by an electrician.
   A replacement mains cable can be obtained from customer service.
- You do not use multiple plugs/ couplings or extension cables.
- The mains plug is always accessible.
- The power cord is not kinked, crushed, altered or severed and has not come into contact with any heat sources.

## Before washing/drying for the first time

The washer dryer was inspected thoroughly before leaving the factory. To remove any residual test water, run the **Drum Clean** ® programme the first time **without** laundry.

#### Note:

- The washer dryer must have been installed and connected properly.
   Installation and connection
   → Page 37
- Never switch on a damaged washer dryer. Inform your customer service. → Page 35

- 1. Insert mains plug.
- 2. Turn the tap on.
- 3. Switch on the appliance.
- Close the door. Do not load any laundry.
- Select the Drum Clean 40°C 

  programme.
- **6.** Open the detergent drawer.
- 7. Pour approx. 1 litre of water into dispenser II.
- 8. Add standard detergent to dispenser II according to manufacturer's instructions for light soiling.

**Note:** To prevent frothing, use only half the recommended amount of detergent. Do not use any woollens or mild detergents.

- 9. Close the detergent drawer.
- 10. Select DI Start/Reload.
- **11.** When the programme ends, switch off the appliance.

## Your washer dryer is now ready for use.


## **Transportation**

### **Preparatory work**

- 1. Turn off the tap.
- Release the water pressure in the supply hose.
   Filter in the water inlet hose blocked → Page 29
- Drain any residual washing water.
   Drain pump blocked → Page 28
- **4.** Disconnect the washer dryer from the power supply.
- 5. Remove the hoses.

## Installing transportation protection devices:

 Remove the covers and keep in a safe place.
 If required, use a screwdriver.



Insert all 4 sleeves. Clamp the mains cable on the holders. Insert and tighten the bolts.



#### Before switching on the appliance:

#### **Notes**

- Always remove the transportation protection devices!
- To prevent unused detergent from flowing into the outlet during the next wash: Pour 1 litre of water into dispenser II and start the Spin ⑤/ Drain ∜ programme.

#### Advice and repair order in the event of faults

GB 0844 892 8979 (Calls from a BT landline will be charged at up to 3 pence per minute. A call set-up fee of up 6 pence may apply.)
IE 01450 2655 (0.03 € per minute at peak. Off peak 0.0088 € per minute.)

You can find the contact information for all countries in the attached after-sales service directory.

Robert Bosch, Hausgeräte GmbH Carl-Wery-Straße 34 81739 München DEUTSCHLAND