

Your new washing machine

You have chosen a NEFF washing machine.

Please take a few minutes to read and become familiar with the advantages of your washing machine.

To meet the high quality demands required by NEFF, every washing machine that leaves our factory is carefully checked to ensure that it functions correctly and is in perfect condition.

For more information on our products, accessories, replacement parts and services, see our website www.neff-international.com or contact our aftersales service centres.

If the operating and installation instructions describe different models, any differences will be pointed out at the relevant points in the text.



Read these operating and installation instructions before switching on the washing machine.

Display rules

This combination of symbol and signal word indicates a possibly dangerous situation. Not heeding the warning can cause death or injuries.

Caution!

This signal word indicates a possibly dangerous situation. Not heeding the caution can cause property and/or environmental damage.

Note/tip

Information about the optimum use of the appliance/any other useful information.

1. 2. 3. / a) b) c)

The steps are represented by numbers or letters.

_ / -

Lists are represented by a small box or a dash.

Contents

Intended use4	Operating the appliance 17
Safety instructions 5 Electrical safety 5 Risk of injury 5 Safety for children 5	Preparing the washing machine
Environmental protection 6 Packaging/used appliance 6 Tips on economical use 6	Placing laundry into the drum 18 Measure and add detergent and care products
Washing machine	Childlock /operation lock
Laundry.12Prepare the laundry12Sorting laundry12Starching12	Removing laundry/switching off the appliance
Dyeing/bleaching	Intelligent dosing system in the detergent drawer
Correct selection of detergent13 Saving energy and detergent14	Basic settings
P+ Programme default settings	Appliance settings
P+ Additional programme settings 16 SpeedPerfect 16 EcoPerfect 16 Easy-Iron 16 Water&Rinse+ 17 Prewash 17	Exiting setting mode

Intended use en

Cleaning and maintenance 26 Machine housing/control panel 26 Drum
The drain pump is blocked, emergency draining
Filter in the water supply blocked 29
Faults and what to do about them.
Emergency release
After-sales service
Technical data
Positioning and connecting 35 Included with the appliance
Removing the transport locks
Stop Aqua-Stop warranty 41

Intended use

- For private domestic use only.
- The washing machine is suitable for washing machine-washable fabrics and hand-washable wool in detergent solution.
- To be operated with cold mains water and standard detergents and care products which are suitable for use in washing machines.
- When measuring out the amount of all detergents, additives, care products and cleaning agents, always follow the manufacturer's instructions.
- The washing machine may be used by children over the age of 8 years and by persons with reduced physical, sensory or mental capacity or by persons with a lack of experience or knowledge if they are supervised or have been instructed by a responsible person. Children must not carry out any cleaning or maintenance work without supervision.
- Keep children under the age of 3 years away from the washing machine.
- This appliance is intended for use up to a maximum height of 4000 metres above sea level.
- Keep pets away from the washing machine.

Before operating the appliance: Read the installation and operating instructions and all other information enclosed with the washing machine, and use the machine accordingly. Retain the documents for subsequent use or for subsequent owners.

Safety instructions

Electrical safety

There is a risk of electric shock if you touch live components.

- Never touch or hold the mains plug with wet hands.
- Only pull out the mains cable by the plug and never by the cable, as this could damage it.

Risk of injury

- If the washing machine is lifted by protruding components (e.g. the washing machine door), the components may break off and cause injuries. Do not lift the washing machine by protruding parts.
- If you climb onto the washing machine, the worktop may break and cause injuries. Do not climb onto the washing machine.
- If you lean/sit on the opened washing machine door, the washing machine may tip over and cause injuries. Do not lean on the washing machine door when it is open.

 Reaching into the drum while it is still turning may cause hand injuries.
 Do not reach into the drum when it is turning.
 Wait until the drum has stopped turning.

When you are washing at high temperatures, there is a risk of scalding if you come into contact with hot detergent solution (e.g. when draining hot detergent solution into a washbasin).

Do not reach into the hot detergent solution.

Safety for children

- There is a risk of death or injury if children play with the washing machine.
 - Do not leave children unattended near the washing machine.
 - Do not let children play with the washing machine.
- Children may lock themselves in appliances, putting their lives at risk.
 When appliances have reached the end of their service life:
 - Unplug the mains plug.
 - Cut through the mains cable and remove it, along with the plug.

Destroy the lock on the washing machine door.

Children may become wrapped in packaging/film or packing parts if allowed to play with them, or they may pull them over their heads and suffocate. Keep packaging, film and packaging parts out of the reach of children.

⚠ Warning Risk of poisoning!

Detergents and care products may be poisonous if consumed.

Keep detergents and care products out of the reach of children

Detergents and care products may cause irritation if they come into contact with the eyes or skin.

Keep detergents and care products out of the reach of children.

When you wash at high temperatures, the glass in the washing machine door becomes hot.

Do not let children touch the hot washing machine door.



Packaging/used appliance



Dispose of packaging in an environmentally-responsible manner.

This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the FU.

Tips on economical use

- Always utilise the maximum amount of washing for the particular programme.

 Overview of programmes
 Supplementary sheet for the operating and installation instructions.
- Wash normally soiled laundry without prewash.
- For light and normal soiling in laundry, you can save energy and detergent. → Page 14
- Dosing the detergent using the intelligent dosing system (i-DOS) helps to save both detergent and water.
- The selectable temperatures apply to the care labels on the textiles. The temperatures in the machine may deviate from this so that you get the optimum mix of energy-saving and washing results.

Information on energy and water consumption:

The displays provide information about the relative level of energy and water consumption in the selected programmes.

The more display segments are visible, the higher the respective consumption.

This enables you to compare the consumption levels of the different programmes when choosing your programme settings and decide on an energy- and water-saving programme setting.




- ₹ Energy consumption
- © Water consumption

- Energy-saving mode: The touch display lighting goes out after a few minutes, the DM button flashes. Touch the touch display to activate the lighting.
 - Energy-saving mode is not activated if a programme is running.
- Automatic switch off (only before the programme starts or after the programme ends) If the appliance is not operated for a prolonged period, it automatically switches off to save energy. Press the main switch again to switch on the appliance.
- If the washing will be dried in a dryer, select the spin speed according to the dryer manufacturer's instructions.


Getting to know the appliance

Washing machine



- Detergent drawer → Page 18
- Controls
- 3 Loading door with door handle
- 3**a** Open the loading door
- 3b Close the loading door
- Service flap

Controls



☐ Main switch

You can use the ① button to switch the appliance on and off.

2 Programme selector


You can turn the programme selector in both directions (clockwise and anti-clockwise).

Touch display

This shows you the programme information and selection options for settings, and you can select the settings by touching the framed or underlined areas.

en Getting to know the appliance

Content of the touch display



Display and control panels	Display for ad- justment values	Setting
90°, 60° , 40°, 30°, 20°, *		Temperature in °C; ‡ = cold
1400*, 1200, 800, 600, 400, Ø		Spin speed Ø = no spin
i-Dos O	°, °°, °°°, off	Dosage quantity for detergent
i-Dos ₩	°, °°, °°°, off	Dosage quantity for fabric softener
Speed		SpeedPerfect
Eco		EcoPerfect
*	+1, +2, +3, off	Water&Rinse+; + additional rinse cycles
<u>a</u>		Easy-Iron
		Prewash
c⇒ 3 sec		Childlock /control panel lock
☆		Memory programme
▷ 00		Start/Pause
B	Q d)) ·\$· &	Appliance settings: Information signal, operating signal, brightness of the touch display, memory function for drum care
+,-	Change the adjustment values Note: In the case of multi-level adjustment values, when you press and hold +, —, the adjustment values automatically run through to the end value. Then touch it again and you can change the adjustment values again.	
* Maximum spin speed depends	on the appliance	

Other displays	Information on
₹	Energy consumption
%	Water consumption
U # # 6	Programme status: Pre-wash, wash, rinse, spin
©	Door locked
	Detergent drawer open
Z-	Tap off/water pressure too low
~∞	Foam detected
88:88	Programme duration, e.g.1:51; Ready in, e.g. © 8.5 h; recommended load, e.g. 8.0 kg; programme status, e.g. End; base dosing quantity, e.g. 36 ml

Laundry


Prepare the laundry

Caution! Damage to the appliance/fabrics

Foreign objects (e.g. coins, paperclips, needles, nails) may damage the laundry or components in the washing machine.

You should therefore note the following tips when preparing your laundry:

Empty any pockets.



- Look out for metal items (paperclips, etc.) and remove them.
- Wash delicates in a laundry bag (tights, underwired bras, etc.).
- Close any zips; button up any cover buttons.
- Brush sand out of pockets and collars.
- Remove curtain fittings or place curtains in a laundry bag.

Sorting laundry

Sort your laundry according to the care instructions and manufacturer's information on the care labels, depending on:

- Type of fabric/fibre
- Colour

Note: Laundry can discolour or not be cleaned correctly. Wash white and coloured items separately. Wash new coloured items separately the first time you wash them.

 Soiling Wash laundry with the same level of soiling together. Some examples of soiling levels can be found on \rightarrow *Page 14*.

- Light: Do not prewash, select the Speed setting if necessary
- Normal
- Heavy: Load less laundry, select a program with prewash
- Stains: Remove/pretreat stains while they are fresh. Firstly, dab with soapy water; do not rub. Then wash the items of laundry with the appropriate program.
 Stubborn or dried-in stains can sometimes only be removed by washing several times.
- Symbols on the care labels
 Note: The numbers in the symbols indicate the maximum washing temperature that may be used.
 - Suitable for normal washing process;
 - e.g. Cottons program

 A gentle washing process is
 - A gentle washing process is required;
 e.g. Easy-Care program
 - An especially gentle washing process is required; e.g.
 Delicate/Silk program
 - Suitable for washing by hand; e.g. Wool program
 - Do not machine wash.

Starching

Note: Laundry should not be treated with fabric softener.

- 1. Switch on the appliance.
- 2. Select the **Rinse** programme.
- Manually add the dosage of liquid starch into the left-hand dispenser (if required, clean it beforehand) in accordance with the manufacturer's instructions.
- **4.** Touch the control panel **▷.**

Dyeing/bleaching

Dye should only be used in normal household quantities. Salt may damage stainless steel. Always follow the dye manufacturer's instructions.

Do **not** use the washing machine to bleach clothes.

Soaking

- 1. Switch on the appliance.
- 2. Select the Cottons 30 °C programme.
- Use i-DOS to dose your detergent or add it to the left-hand compartment in accordance with the manufacturer's instructions.
- **4.** Touch the control panel **DII**. The program starts.
- **5.** After approx. 10 minutes, press **DII** to pause the programme.
- 6. Leave the laundry to soak for as long as required, then either touch DIII again to continue the programme or change the programme.

Notes

- Load laundry of the same colour.
- No additional detergent is required; the soaking solution is used for washing.

Detergent

Correct selection of detergent

The care label is crucial for selecting the correct detergent, temperature and treatment of the laundry. → See also www.sartex.ch

If you visit www.cleanright.eu, you will find further information on detergents, care products and cleaning agents for domestic use.

Standard detergent with optical brighteners

Suitable for boil-washable white laundry made from linen or cotton Programme: Cottons/cold - max. 90 °C

Detergent for colours without bleach or optical brighteners Suitable for coloured laundry made from linen or cotton

Programme: Cottons/cold - max. 60 °C

Detergent for colours/delicates without optical brighteners Suitable for coloured laundry made from easy-care fibres, synthetic

fibres Programme: Easy-Care/ cold - max. 60 °C

Detergent for delicates

Suitable for delicate, fine fabrics, silk or viscose Programme: Delicate/Silk/

Programme: Delicate/Silk/cold - max. 40 °C

Detergent for woollens

Suitable for wool Wool programme/ cold - max. 40 °C

Saving energy and detergent

For light and normal soiling, you can save energy (lower washing temperature) and detergent.

Saving Soiling/note Reduced temper-Light ature and deter-No visible dirt or stains. Clothgent quantity as ing has taken on some body per the recomodour, e.g.: mended dosage Light summer/sports clothing (worn for a few hours) T-shirts, shirts, blouses (worn for up to one day) Guest bed linen and hand towels (used for one day) Normal Visible dirt or a few light stains, e.g.: T-shirts, shirts, blouses (sweat soaked, worn a few times) Towels, bedding (used for up to one week) Temperature as Heavy per the care label Dirt and/or stains clearly visiand detergent ble, e.g. tea towels, baby quantity as per items, work clothing the recommended dosage for heavy soiling

Note: When measuring the amount of all detergents/additives/care products and cleaning agents, please always check the manufacturer's instructions and information. \rightarrow *Page 18*

P+ Programme default settings

The programme default settings are displayed and can be changed in the touch display after the programme is selected.

You can find an overview of all possible program settings on the supplementary sheet for the installation and operating instructions.

Temperature

Depending on what stage the programme is in, you can change the set temperature before and during the programme.

The maximum temperature that can be set depends on the programme that has been selected.

Spin speed

Depending on what stage the programme is in, you can change the spin speed (in rpm; revolutions per minute) before and during the programme.

Setting Ø: No spin; the water is only drained. The laundry stays wet inside the drum, e.g. for items that should not be spun.

The maximum speed that can be set depends on the model and the programme that has been selected.

Ready in time

After selecting a programme, the programme duration is displayed, e.g. **1:51** (in h:min (hours:minutes)).

Before the programme starts, you can move the time at which the programme should be finished backwards, in increments of 30 minutes and up to a maximum of 24 h (h=hour).

After the programme starts, the selected time, e.g. **8.5 h** is displayed and counted down until the washing programme starts. The duration of the programme is then displayed.

Note: The programme duration is automatically adjusted when the programme is running. Changes to the programme default settings or programme settings, foam detection function, unbalanced load detection, the load or soiling may also change the programme duration.

After the programme starts, and while the selected time is counting down, you can change this as follows:

- Touch the control panel D.
- 2. Touch + or to change the time.
- 3. And touch DII again.

After starting the programme, while the programme is running, you can add or remove laundry if necessary.

 \rightarrow Page 19

i-DOS settings

Your washing machine has an intelligent dosing system for liquid detergent and fabric softener.

The washing machine doses your detergent and fabric softener automatically in most programmes.

The following have been preset at the factory:

- % i-DÓS: ∞ Fabric softener dosage for a medium level of softness

i-DOS O for detergent

Adjustment values for the dosage quantity

- Light: For lightly soiled laundry
- Medium:
 For normally soiled laundry
- Heavy: For particularly heavy soiling and/ or staining
- off Automatic dosing deselected, manual dosage \rightarrow Page 23

You can change the settings for automatic detergent dosing before the washing programme starts and during pre-wash (if selected). Touch the control panel i-DOS ⊙ for this.

You can find information on degrees of soiling on \rightarrow *Page 14*.

i-DOS % for fabric softener

Adjustment values for dosage quantities

Liaht:

For slightly soft laundry

Medium:

For laundry with a medium level of softness

Heavv:

For particularly soft laundry

off Automatic dosing deselected

Depending on what stage the programme is in, you can change the settings for automatic detergent dosage. Touch the control panel i-DOS & for this.

Memory programme



You can save a selected programme with your favourite settings here.

To store:

- 1. Switch on the appliance.
- 2. Select a programme.
- 3. Change the settings and/or select additional settings.
- **4.** Press and hold ☆ on the control panel for approx. three seconds.

The programme is saved if all of the settings flash briefly.

To use the saved programme, touch ☆ briefly after you switch on the appliance.

To change the saved programme, press and hold \(\pri \) again for approx, three seconds after selecting the new settings.

P+ Additional programme settings

You can find an overview of all of the additional settings that can be selected depending on the programme on the printed supplement to the installation and operating instructions.

SpeedPerfect

Speed

Washing in a shorter time while achieving a washing result that is consistent with, but uses more energy than, the selected programme, without the SpeedPerfect setting.

Note: Do not exceed the maximum load

EcoPerfect

Eco

Energy-optimised washing by reducing the temperature while achieving a washing result that is consistent with the selected programme, without the EcoPerfect setting.

Easy-Iron



Reduces creasing thanks to a special spin sequence followed by fluffing and reduced spin speed.

Note: The washing's residual moisture is increased.

Water&Rinse+



Adjustment values:

+1 + 1 rinse +2 + 2 rinses +3 + 3 rinses

off Setting deselected

Higher water level and additional rinse cycles depending on the programme, longer programme duration for particularly sensitive skin and/or for areas with very soft water.

Prewash



For heavily soiled laundry.

Notes


- If intelligent dosage is selected, the detergent will be dispensed automatically for the prewash and the main wash.
- For heavily soiled laundry, medium i-DOS dosing is usually sufficient when selecting a programme with pre-wash.
- If dosing manually, allocate detergent to the prewash and the main wash. Place detergent for the prewash in the drum and add washing powder for the main wash to the left-hand compartment.

Operating the appliance

Preparing the washing machine

Note: The washing machine **must be correctly installed** and **connected**. From → Page 35

- 1. Connect the mains plug.
- 2. Turn on the water tap.
- 3. Open the door.
- **4.** Check that the drum is completely drained. Drain if necessary.





Switching on the appliance/ selecting a programme

Press the ① button. The appliance is switched on.

The **Cottons** programme set at the factory is then always displayed.

The current settings and programme information light up at full brightness and the display \mathbb{N} flashes.

The settings that can be selected light up at half brightness.

Notes

- Temporary flashing of the display informs you to run the programme Drum Clean or any other programme soon at a washing temperature of at least 60 °C.
- If the

 3 sec display flashes, the childproof lock is active. You must deactivate this first before you can change settings or start the programme. → Page 19

In appliances with a drum light:

The drum is lit after switching on the appliance, after opening and closing the door and after starting a programme. The light switches off automatically.

You can:

- Use this programme and load laundry. → Page 18
- Or select another programme. You can find an overview of all programmes on the printed supplement for the installation and operating instructions.
- Or change the programme default settings. → Page 18
- And/or select additional programme settings. → Page 18

Change the programme default settings

To change the current settings, touch the required control panel; the relevant display switches to full brightness.

You can change Finished in-time by touching + or -.

Note: The i-DOS settings are saved until they are changed again, even if the washing machine is switched off.

Programme default settings

→ Page 14

Select additional programme settings

By selecting additional settings, you can better adapt the washing process to your items of laundry.

To do this, touch the required control panel; the relevant display switches to full brightness.

Additional programme settings → Page 16

Placing laundry into the drum

Items of laundry pretreated with cleaning agents that contain solvents, e.g. stain remover/cleaning solvent, may cause an explosion after being loaded into the washing machine. Hand-rinse items of laundry thoroughly beforehand.

Notes

- Mix items of laundry of varying sizes. Laundry items of different sizes distribute themselves better during the spin cycle. Individual items of laundry may lead to imbalances.
- Observe the specified maximum load. Overfilling has a negative impact on the washing result and promotes creasing.
- 1. Place presorted items of laundry unfolded in the washing drum.
- Make sure that no items of laundry are trapped between the washing machine door and the rubber seal, and close the door.





Measure and add detergent and care products

For the majority of programmes on your washing machine, detergent and fabric softener are dosed automatically; it is a factory setting for these programmes and can be changed.

In addition to intelligent dosing, you can add cleaning aids (e.g. softener, bleach or stain remover) to the left-hand compartment, if necessary.

For programmes without intelligent dosing, or as required (in which case, set intelligent dosing to "off"), detergent can be added manually to the left-hand compartment.

Start the programme

Touch the control panel DM.

The programme starts and the DIII display lights up permanently.

The door is locked and the corresponding display \mathfrak{O} lights up.

During the programme, the current programme information is displayed:

- Finished in-timeFinished in-time or, after the washing programme has started, the programme duration
- And the displays for the programme's progress light up.
 → Page 10

Information on the following programme steps and settings, which can be changed during the programme sequence, light up at half brightness.

Note: Foam detection

If the display also lights up, the washing machine has detected too much foam during the washing programme and automatically activated additional rinse cycles to remove the foam

Add less detergent to the next washing cycle with the same load.

If you want to lock the programme to prevent it from being inadvertently adjusted, you can select the childproof lock as follows.

Childlock /operation lock

~ 3 sec

You can lock the washing machine to prevent the functions you have set from

being changed inadvertently in the control panel.

To activate/deactivate the childproof lock, touch and hold the control panel \implies 3 sec for approx. three seconds. The display switches to full brightness.

If you turn the programme selector or touch the control panel while the childproof lock is active, the \simeq 3 sec indicator will flash briefly and a signal will sound. The programme runs through to the end unchanged.

Notes

- To remove the laundry at the end of the programme, deactivate the childproof lock.
- The childproof lock can be activated no matter what status the appliance is in.
- The childproof lock remains active, even once the washing machine has been switched off.
- If the appliance is switched off while the programme is running and childproof lock is activated, the programme continues when the appliance is switched back on.

Adding laundry

After starting the programme, you can add or remove laundry if necessary.

To do this, touch the control panel \mathbb{N} .

The indicator flashes. The machine is paused and checks whether a top-up is possible.

If the display **©** goes out, a top-up is possible. The door is then unlocked and can be opened.

To continue the programme. touch D again. The programme continues automatically.

en

Notes

- Do not leave the door open for too long when adding laundry as water from the laundry may leak out.
- For safety reasons, the door remains locked when the water level or temperature is high, or while the drum is turning, and it is not possible to add laundry during this time. Follow the information on the display panel.
- The load display is not active during reloading.

Changing the programme

If you have started the wrong programme by mistake, you can change the programme as follows:

- 1. Touch the control panel DW.
- 2. Select another programme.
- 3. And touch DM again. The new program starts from the beginning.

Cancel the programme

For programs at high temperature:

- 1. Touch the control panel DM.
- 2. To cool the laundry: Select Rinse.
- 3. And touch DM again.

For programmes at low temperatures:

- 1. Touch DW.
- 2. Select Spin or Drain/Empty.
- 3. And touch DII again.

Programme end

End lights up in the display panel and the \mathbb{DM} and \mathbb{C} displays are off.


Note: If the display flashes, this informs you to run the **Drum Clean** programme or any other programme at a washing temperature of at least 60 °C.

Removing laundry/switching off the appliance

- Open the loading door and remove the laundry.
- 2. Switch off the appliance.
- Turn off the tap.
 Note: Not required for AquaStop models.

Notes

- Do not leave any items of laundry in the drum. They may shrink in the next wash or discolour another item.
- Remove any foreign objects from the drum and the rubber seal – risk of rusting.
- Wipe the rubber gasket dry.



- Leave the washing machine door and detergent drawer open so that any residual water can dry away.
- Always wait for the end of the programme, otherwise the appliance may still be locked. Then switch on the appliance and wait for it to unlock.


Intelligent dosing system

Intelligent dosing system in the detergent drawer

i-DOS Intelligent Dosing system

Your washing machine has an intelligent dosing system for liquid detergent and fabric softener.

The i-DOS dispensers \otimes and \otimes in the detergent drawer are available for this purpose.



- ☐ Dispenser ♠ (1.3 I) for liquid detergent
- 2 Dispenser & (0.5 I) for fabric softener
- 3 Left-hand compartment for manual dosing → Page 23

Depending on the selected programme and settings, the optimum quantity of detergent and/or fabric softener is dosed by the i-DOS dispensers.

Initial use/filling the dispensers

Refer to the manufacturer's instructions when choosing your detergent and fabric softener. We recommend the use of standard, universal and colour liquid detergents for all machine-washable, coloured fabrics made of cotton or synthetic materials.


Notes

- Only use easy-pour liquid products that the manufacturer recommends adding to the detergent drawer.
- Do not mix different liquid detergents. If changing your liquid detergent (type, manufacturer, etc.), empty the dispenser completely and clean it. → Page 26
- Do not use products containing solvents, caustic agents or volatile substances (e.g. bleach).
- Do not mix detergent and fabric softener.
- Do not use products that have expired or are highly congealed.
- To prevent drying out, do not leave the dispenser lids open for a long period of time.

Filling the dispensers:

The dispenser covers in the detergent drawer are marked with the following symbols:

- Standard/universal detergent
- Second Fabric Softener
- 1. Open the detergent drawer.
- 2. Open the dispenser cover(s).
- **3.** Add detergent/fabric softener. Do not fill above the **max.** marking.




- 4. Close the cover(s).
- 5. Slowly push the detergent drawer in completely.

When the detergent drawer is fully pushed in, the display 🔁 goes out when the appliance is switched on.

Everyday use

Displays:



- The display lights upif intelligent dosage has been selected for the dispenser.
- The display for the adjustment values, e.g. **flashes** if the fill level for the dispenser is below the minimum level when intelligent dosing has been selected.

(De)selecting intelligent dosage and adjusting the dosage strength:

The intelligent dosages for detergent and fabric softener are set at the factory for all programmes in which intelligent dosing can be used.

You can find an overview of all possible programme settings on the supplementary sheet for the installation and operating instructions.

The dosage strength has been preset to ∘ (lightly soiled laundry) for detergent ○ and to ∘ (medium level of softness) for fabric softener ⊗. It can be changed individually for each programme.

→ Page 15

In addition to intelligent dosing, washing additives (e.g. stain remover) can be added manually via the left-hand compartment. \rightarrow Page 23

Note: The selection (on/off) and the selected dosage strength for i-DOS ⊗ and i-DOS ⊘ are saved for each programme until they are changed

again, even if the washing machine is switched off.

Topping up the detergent/ fabric softener:

If the display for the selected intelligent dosing flashes, this means that the amount of detergent or fabric softener in the dispenser is below the minimum fill level. The content is sufficient for approx. three washes.

The same detergent or fabric softener can be added at any time. If you change product/manufacturer, we recommend that you clean the dispensers first.

 \rightarrow Page 26

If required, adjust the basic dosage.

Basic settings

The basic dosages are:

- For detergents based on the manufacturer's recommendation for average soiling and the respective water hardness.
- F or fabric softeners based on the manufacturer's recommendation for a medium level of softness.

Refer to the packaging label on your detergent/fabric softener or ask the manufacturer directly for this information.

To find out the hardness of your water supply, use a test strip or check with your water supplier.

My water hardness:



Below is an example of detergent dosages on a packaging label:

Degree of soil- ing → Water hard- ness ↓	light	normal	heavy	very heavy
soft/medium	55 ml	75 ml	120 ml	160 ml
hard/very hard	75 ml	95 ml	150 ml	180 ml

The default setting for the basic dosage is set specifically according to the area in which you live (e.g. 75 ml for detergent and 36 ml for fabric softener).

Set the basic detergent dosage according to the detergent's packaging label. Take your water hardness into consideration when doing so.

Select the basic fabric softener dosage according to how soft you would like your laundry to be.

Changing one basic dosage affects all three dosage quantities in the same way.

Notes

- Reduce the basic dosage if using a very concentrated detergent.
- If large amounts of foam are repeatedly created during washing, please check your basic dosage and dosage quantity settings. Certain types of liquid detergent can also create excessive amounts of foam. If your basic dosage and dosage quantity settings are correct, we advise you to use a different detergent.

Changing the basic dosages:


- Press and hold the corresponding i-DOS control panel (○ or ※) for approx. three seconds. The preset base dosing quantity is displayed.
- Touch + or to set the required base dosing quantity. The setting is activated without needing to be confirmed.
- Touch the corresponding i-DOS control panel again to return to the initial status.

Note: The settings are saved until they are changed again, even if the machine is switched off.

Manual dosage

For programmes in which intelligent dosing is not possible or not requested (then set intelligent dosing to "off"), detergent is added to the left-hand compartment.

Cleaning aids such as water softener, bleach and stain remover can be added to this compartment in addition to the intelligent dosage.



Detergent and care products may spray out if the detergent drawer is opened while the machine is in operation. Open the drawer carefully.

Rinse eyes or skin thoroughly if they come into contact with detergent/care products.

If swallowed accidentally, seek medical advice.

Caution! Damage to the appliance

Cleaning agents and agents for pretreating laundry (e.g. stain removers, prewash sprays, etc.) may cause damage if they come into contact with the surfaces of the washing machine. Do not allow these agents to come into contact with the surfaces of the washing machine. If necessary, immediately wipe away spray residue and other residues/ droplets with a damp cloth.

Notes

- When dosing all detergents, cleaning aids and cleaning agents, always follow the manufacturer's instructions.
- If detergent is dosed manually, do not dose any additional detergent via intelligent dosing (then set intelligent dosing to "off"); this prevents overdosage and foaming.
- Dilute viscous fabric softener and fabric conditioner with water to prevent blockages.

Dosing and adding detergent:

1. Pull out the detergent drawer.



- 2. Add the dosage to the left-hand compartment depending on the followina:
 - Soiling
 - Water hardness (ask your water supply company)
 - The amount of laundry
 - The manufacturer's instructions
- 3. Close the detergent drawer.

翻 Appliance settings

You can change the following settings in the control and display panel:

- The volume of the information signal (e.g. at the end of the programme),
- The volume of the operating signals,
- The brightness of the operating and display field,
- Select/deselect the memory function for drum care.

You will need to activate the setting mode in order to change these settings.

Activating the setting mode

- 1. Switch on the appliance. The settings for the current programme are displayed.
- 2. Touch the control panel 3. The setting mode is activated and the displays for the information signals \Box and the preset volume light up.

You can now change the settings:

Changing the signal volume

To do this, touch + or - on the control panel until the required adjustment value for the volume of the information signals appears:

Adjustment values:

- 0 off
 - 1 auiet
 - 2 Medium
 - 3 loud
- 4 very loud

Exit setting mode or:

Touch A again. The display for the operating signals 4) and the preset volume light up.

Touch + or - to change the adjustment value (as above).

Exit setting mode or:

Changing the brightness of the touch display

Touch ₱ again. The display for the touch display's brightness ♣ and the preset brightness light up.

Change the adjustment value by touching + or -:

Adjustment values:

- 1 Not very bright
- 2 Normal level of brightness
- 3 Bright
- 4 Very bright

Exit setting mode or:

Select/deselect the memory function for drum care

Touch ₱ again. The display for the memory function for cleaning the drum ♥ lights up.

Touch + or - to select (on) or deselect (off) the memory function.

Exiting setting mode

To exit and save the settings:

- Wait for approx. 15 minutes or
- Touch one last time or
- Switch off the appliance. The selected settings will take effect the next time the washing machine is switched on.

Sensors

Automatic load sensing

The automatic load sensing function adapts the water consumption ideally to each programme depending on the type of fabric and the load.

Unbalanced load detection system

The automatic unbalanced load detection system detects imbalances and ensures even distribution of the laundry by repeatedly starting and stopping drum spinning.

If the laundry is extremely unevenly distributed, the speed is reduced or the spin cycle is not performed for safety reasons.

Note: Place large and small items of laundry evenly in the drum. \rightarrow *Page 32*

VoltCheck

depending on the model

The colon in the Finished in-time display:

- Flashes, if the voltage is currently too low.
- Pulses, if insufficient voltage was detected during the programme.



Note: Insufficient voltage may lead to programme extensions and/or a non-satisfactory spin result, for example.

Cleaning and maintenance

⚠ Warning

Danger of death!

There is a risk of electric shock if you touch live components.

Switch off the appliance and pull out the mains plug.

⚠ Warning Risk of poisoning!

Toxic vapours can be produced by cleaning agents that contain solvents, e.g. cleaning solvent.

Do not use cleaning agents that contain solvents.

Caution! Damage to the appliance

Cleaning agents that contain solvents, e.g. cleaning solvent, can damage surfaces and components in the machine.

Do not use cleaning agents that contain solvents.

Prevent detergent residue from building up and odours from forming by following these instructions:

Notes

- Ensure the room in which the washing machine is set up is well ventilated.
- Leave the door and detergent dispenser tray open slightly when the washing machine is not in use.
- Occasionally run a wash using the Cottons 60 °C programme and powder detergent.

Machine housing/control panel

- Wipe the housing and the control panel with a soft, damp cloth.
- Remove the detergent residue immediately.
- Do not clean with a water jet.

Drum

Use chlorine-free cleaning agents, do not use steel wool.

If there are odours in the washing machine, or to clean the drum, run the **Drum Clean 90 °C** programme without laundry. Add washing powder.

Descaling

Descaling should not be necessary if the detergent is measured out correctly. However, if it is required, follow the manufacturer's instructions for the descaling agent. Suitable descalers can be obtained via our website or from customer services. \rightarrow *Page 34*

i-DOS detergent draw and its housing


1. Emptying the dispensers:

The dispensers have emptying outlets with removable sealing plugs at the front. To empty the dispensers, first remove the drawer handle as shown below:

a) Pull out the detergent drawer.



b) Pull the catch (A) on the back of the drawer handle (in the centre at the bottom) slightly towards you. This unlocks the drawer handle (B), which you can then pull off by lifting it upwards.



 c) To empty the dispensers, carefully pull off each of the sealing plugs and empty the contents into a suitable container.



d) Then push the sealing plugs back in completely.


2. Cleaning the dispensers/detergent drawer:

The detergent drawer can be removed completely to allow you to clean to dispensers after you have emptied them.


a) Empty the dispensers before removing the drawer.

Note: Only put the drawer handle back on after you have finished cleaning.

- b) Pull out the drawer.
- c) Press the catch and remove the drawer completely.



d) Carefully remove the drawer cover.



Caution!

Risk of damage to the detergent drawer.

The detergent drawer contains electrical components. These may become damaged if they come into contact with water.


 Do not clean the cover in the dishwasher and do not immerse it in water.




 Protect the rear drawer connector against water, detergent or fabricsoftener residue; if necessary, clean the outer surfaces with a soft, damp cloth. Dry before putting back in.

en Cleaning and maintenance

e) Clean the drawer and the cover with a soft, damp cloth or a hand shower. Also clean the inner surfaces with a soft, damp cloth.



- f) Dry the drawer and the cover and put them back together.
- g) Push the drawer handle back in from above until you feel it click in place.
- h) Clean the inside of the detergent-drawer housing.
- i) Push the detergent drawer in completely.




The drain pump is blocked, emergency draining

When you wash at high temperatures, the water gets very hot. If you come into contact with the hot water, you may be scalded.

Allow the detergent solution to cool down.

- Turn off the water tap so that no more water can flow in and has to be drained via the drain pump.
- 2. Switch off the appliance. Pull out the mains plug.
- 3. Open and remove the service flap.



Take the auxilary drain hose out of the holder.

Remove the locking cap and drain off the water into a suitable container.

Replace the locking cap and place the drain hose back in the holder.



5. Carefully unscrew the pump cover; remaining water may leak out. Clean the interior, pump cover thread and pump housing. The impeller in the drain pump must be able to rotate.

Refit and screw on the pump cover. The handle must be in a vertical position.





Put the service flap back on, engage and close it.



Note: To prevent unused detergent from flowing straight into the drain during the next wash: Pour 1 litre of water into the left-hand compartment and start the programme **Drain/Empty**.

The drain hose at the siphon is blocked


- Switch off the appliance. Pull out the mains plug.
- Loosen the hose clamp. Carefully remove the drain hose; residual water may leak out.
- 3. Clean the drain hose and siphon connecting piece.




 Re-attach the drain hose and secure the connection point using the hose clamp.

Filter in the water supply blocked

- Release water pressure in the supply hose:
 - a) Turn off the tap.
 - b) Select any programme (except Rinse/Spin/Drain/Empty).
 - c) Start the programme and leave it to run for approx. 40 seconds.
 - d) Switch off the appliance.
 - e) Pull out the mains plug.
- 2. Clean the filters:
 - a) Disconnect the hose from the tap.
 Clean the filter with a small brush.



 b) For standard and Aqua-Secure models, clean the filter on the rear of the appliance:
 Disconnect the hose from the rear of the appliance.
 Use pliers to remove the filter and then clean it.



c) Connect the hose and check for leaks.



? Faults and what to do about them.

Emergency release

E.g. in the event of a power cut The programme continues when the power supply is restored.

However, if the laundry has to be removed, the washing machine door can be opened as follows:



Warning Risk of scalding!

When you are washing at high temperatures, there is a risk of scalding if you come into contact with hot water and laundry.

If possible, leave it to cool down first.

Warning Risk of injury!

You may injure your hands if you reach into the drum while it is turning. Do not reach into the drum when it is turnina.

Wait until the drum has stopped turning.

Caution! Water damage

Any escaping water may cause water damage.

Do not open the door if water can be seen through the glass.

- 1. Switch off the appliance. Pull out the mains plua.
- 2. Drain the water. \rightarrow Page 28
- 3. Pull the emergency release downwards with a tool and release. The door can then be opened.



Information on the display panel

Display	Cause/remedy	
© Off	The door is locked, at the end of the programme or when paused, if laundry can be added.	
C lights up	 During the programme. Door locked. Paused: Temperature too high. Wait until the temperature drops. Paused: Spin speed too high. Wait until the drum comes to a standstill. Paused: Water level too high. It is not possible to add laundry. Touch DID to continue the programme. 	
© flashes	 Slow: The door cannot currently be locked or unlocked. Waiting time required. Fast: Close the door because water can flow out from the laundry loads. 	
D 00 Off	At the end of the programme, while the door is open	
D II lights up	After the start of the programme	
D M flashes	Before the programme starts, paused	
i-DOS adjustment value, e.g. ∞ flashes	Minimum filling level detected in the corresponding dispenser, top up. \longrightarrow Page 22	

Display	Cause/remedy
□ lights up	Detergent drawer has been pulled out.
₽ lights up	Water pressure too low, may increase the programme duration.
≗ flashes	No water supply: ■ Turn the tap on fully, ■ Supply hose kinked/trapped, ■ If required, clean the filter. → Page 29
∽ 3 sec lights up	The childproof lock is activated – deactivate it. \longrightarrow Page 19
∽ 3 sec flashes	Childproof lock activated, programme selector turned or a control panel has been touched.
	Run the Drum Clean 90 °C programme or a 60 °C programme to clean and care for the drum and the outer tub. Notes Run the programme without laundry. Use washing powder or a detergent containing bleach. To prevent foaming, only use half the amount of detergent recommended by the detergent manufacturer. Do not use detergents designed for woollens or delicates. Switching the information signal on/off
lights up	Too much foam has been detected and an additional wash cycle has been activated. Add less detergent to the next washing cycle with the same load.
E:10 alternating with -00, -10 or -20	Error in the i-DOS system. The i-DOS function is automatically deactivated. The appliance can be used as normal with manual dosing. To repair the i-DOS system, please call after-sales service.
E:60 alternating with - 2b and End	At the end of the programme. Not an appliance fault – the unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed. Distribute small and large items of washing in the drum. If required, spin the laundry once more.
E:35 alternating with - 10	There is water in the base plate, the appliance is leaking. Turn off the tap. Call the after-sales service. \longrightarrow Page 34
E:36 alternating with - 10	 ■ The drain pump is blocked. Clean the drain pump. → Page 28 ■ The drain hose/drain pipe is blocked. Clean the drain hose at the siphon. → Page 29
Other displays	Switch off the appliance, wait for five seconds and then switch it on again. If the display appears again, call the after-sales service. \longrightarrow Page 34

Faults and what to do about them.

Faults	Cause/remedy
Water is running out.	 Attach the drain hose correctly or replace it. Tighten the threaded joint on the inlet hose.
Water not flowing in. Detergent is not being dispensed.	 ■ Programme does not start? ■ Is the tap turned on? ■ Could the filter be clogged? Clean the filter. → Page 29 ■ Is the inlet hose kinked or trapped?
The dispenser is empty and the fill level indicator is not flashing.	 ■ Is the drawer cover/connector dirty? Clean the detergent drawer. → Page 26 ■ Has the detergent drawer been pushed in correctly? → Page 22
The wrong detergent/fabric softener has been poured into the dispenser(s).	Dispenser(s): 4. Empty and clean. → Page 26 5. Refill.
Detergent/fabric softener has congealed in the dispensers.	Clean and refill the dispensers.
The door cannot be opened.	 The safety function is activated. Stop programme? → Page 20 Can the door only be opened by the emergency release? → Page 30
Programme does not start.	 Programme starts or Finished in-time selected? Is the door closed? Is the childproof lock activated? Deactivate. → Page 19 Is lights up. the detergent drawer has not been pushed in completely. Push the detergent drawer in correctly.
The drum briefly jerks or judders after the programme has started.	Not a fault – the internal motor test may cause the drum to jerk or judder briefly when the wash programme starts.
The water is not draining.	 ■ Clean the drain pump. → Page 28 ■ Clean the drain pipe and/or the drain hose.
Water is not visible in the drum.	Not a fault – the water is below the visible area.
The spin result is not satisfactory. Laundry wet/too damp.	 Not a fault – the unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed. Distribute small and large items of washing in the drum. Easy-Iron selected? → Page 16 Is the selected speed too low?
The spin cycle runs several times.	Not a fault – the unbalanced load detection system is adjusting an imbalance.
The programme is taking longer than usual.	 Not a fault – the unbalanced load detection system is adjusting an imbalance by repeatedly distributing the laundry. Not a fault – the foam detection is system active – a rinse cycle has been switched on.

Faults	Cause/remedy	
The length of the programme changes during the wash cycle.	Not a fault – the programme sequence is optimised for the specific washing process. This may change the length of the programme shown on the display panel.	
Residual water in the left- hand compartment for the care product.	■ Not a fault – the effectiveness of the care product is not affected.	
Odours in the washing machine.	Run the Drum Clean or Cottons 90 °C programme without laundry. Add washing powder or a detergent containing bleach.	
	Note: To prevent foaming, only use half the amount of detergent recommended by the detergent manufacturer. Do not use detergents designed for woollens or delicates.	
The display lights up	Have you used too much detergent?	
in the touch display. Foam may also be leaking from the detergent drawer.	Mix one tablespoon of fabric softener with 1/2 litre of water and pour it into the left-hand compartment (not suitable for outdoor clothing, sportswear or items made with down).	
	Use less detergent in the next washing cycle.	
Repeated, intensive foaming.	Check your basic dosage and dosage strength settings.If required, use a different liquid detergent.	
Detergent/fabric softener drips off the seal and collects on the door or in the seal fold.	There is too much detergent/fabric softener in the dispensers. Do not fill above the max. mark in the dispensers.	
Loud noises, vibrations and machine "movement" during the spin cycle.	 ■ Appliance aligned? Align the appliance. → Page 39 ■ Are the appliance feet secured? Secure the appliance's feet. → Page 39 ■ Have the transport braces been removed? Removing the transportation bolts. → Page 36 	
The touch display does not work while the appliance is running.	 Power failure? Have the fuses blown? Switch on/replace the fuses. If the fault occurs repeatedly, call the after-sales service. 	
There is detergent residue on the laundry.	 Some phosphate-free detergents contain water-insoluble residue. Select Rinse or brush the laundry after washing. 	
When the appliance is paused, D𝔰 flashes and 𝒪 lights up.	 The water level is too high. It is not possible to add laundry. Close the door immediately, if necessary. Touch DII to continue the programme. 	
DII flashes when the appliance is paused and $\mathbf{\mathfrak{C}}$ is off.	The door is unlocked. It is possible to add laundry.	
If you cannot rectify a fault yourself (after switching the machine off and on again) or a repair is required:		

If you cannot rectify a fault yourself (after switching the machine off and on again) or a repair is required:

- Switch off the appliance and pull out the mains plug.
- Turn off the tap and call the after-sales service.



After-sales service

If you cannot rectify a fault yourself, contact customer services. → Cover page

We will always find an appropriate solution in order to avoid unnecessary visits by engineers.

Please give customer services the product number (E no.) and the production number (FD) of the appliance.

E-Nr	FD

F no. Product number FD Production number

You can find this information *depending on the model:

On the inside of the door*/in the opened service flap* and on the rear of the appliance.

Trust the expertise of the manufacturer.

Contact us for assistance. By doing so, you will ensure that the repairs are carried out by trained service personnel using genuine spare parts.



Technical data

Dimensions:

850 x 600 x 590 mm (height x width x depth)

Weight:

70 - 85 kg (depending on model)

Mains connection:

Mains voltage 220 - 240 V, 50 Hz

Nominal current 10 A

Nominal power 1900 - 2300 W

Water pressure:

100 - 1000 kPa (1 - 10 bar)

Power consumption when switched off:

0,12 W


Power consumption when left on:

0,43 W

Positioning and connecting

Included with the appliance

Note: Check the machine for transport damage. Never use a damaged machine. If you have a complaint, please contact the retailer from whom you purchased the appliance, or our after-sales service.



Mains cable

2 Bag:

- Installation and operating instructions
- After-sales service location directory*
- Warrantv*
- Cover caps for openings left after removing the transport locks
- Wrench*
- 3 Water supply hose on Aqua-Stop models
- 4 Water drain hose
- 5 Elbow for securing the water drain hose*

6 Water supply hose on standard/Aqua-Secure models

*depending on the model

In addition, a hose clamp (24 - 40 mm diameter, available from specialist dealers) is required to connect the water drain hose to a siphon.

Useful tools

- Spirit level for levelling
- Wrench with:
 - WAF 13 for loosening the transport locks, and
 - WAF 17 for aligning the appliance feet

Safety instructions

- The washing machine is very heavy.
 Be careful when lifting/transporting the washing machine.
- When the washing machine is lifted by its protruding parts (e.g. the washing machine door), the components may break off and cause injuries. Do not lift the washing machine by
- protruding parts.
 If the hose and mains cables are not routed properly, there is a risk of tripping and injury.
 Lay hoses and cables in such a way that there is no risk of tripping.

Caution!

Damage to the appliance

Frozen hoses may rip/burst. Do not install the washing machine in areas exposed to frost or outdoors.

Caution! Water damage

The connection points for the water supply hose and water drain hose are under high water pressure. To prevent

en

leaks and water damage, you must follow the instructions in this section.

Notes

- In addition to the safety information listed here, the local water and electricity supplier may have special requirements.
- If in doubt, have the appliance connected by a specialist.

Installation surface

Note: The washing machine be stable so that it does not move around.

- The installation surface must be firm and level.
- Soft floors/floor coverings are not suitable

Installation on a base or a wooden joist floor

Caution! Damage to the appliance

The washing machine may "wander" and tip/topple from the base when spinning.

The feet of the appliance must be secured with holding brackets. Order no. WMZ 2200, WX 9756, 7 7080X0

Note: On wooden joist floors, install the washing machine:

- In a corner, if possible,
- On a water-resistant wooden board (min. 30 mm thick) which is screwed tightly to the floor.

Installation on a platform with drawer

Platform order no.: WMZ 20490, WZ 20490, WZ 20510, WZ 20520

Installing the appliance in a kitchenette

M Warning Danger of death!

There is a risk of electric shock if you touch live components.

Do not remove the appliance covering plate.

Notes

- Recess width of 60 cm required.
- Only install the washing machine underneath a continuous worktop that is securely connected to adjacent cabinets.


Removing the transport locks

Caution!


Damage to the appliance

- The machine is secured for transportation using transport locks. If the transport locks are not removed, the drum, for example, may become damaged when the machine is operated. Before using the appliance for the first time, make sure that you completely remove all four transport locks. Keep the locks in a safe place.
- To prevent transport damage from occurring if the appliance is moved at a later date, you must refit the transport locks before transporting the appliance.


Note: Keep the screws and sleeves in a safe place.



1. Take the hoses out of the holders.



 Unscrew and remove all four transport brace screws.
 Remove the sleeves. To do this, remove the mains cable from the holders.




Fit the covers. Lock the covers firmly in place by applying pressure to the snap-in hooks.




Hose and cable lengths

Left-hand connection



Right-hand connection



Tip: The following are available from specialist dealers/the after-sales service:

- An extension for Aqua-Stop or cold water supply hose (approx. 2.50 m); order no. WMZ2380, WZ10130, CZ11350, Z7070X0
- A longer supply hose (approx. 2.20 m) for standard model

Water inlet

There is a risk of electric shock if you touch live components.

Do not immerse the Aqua-Stop safety valve in water (it contains an electric valve).

Observe the following when connecting the machine:

Notes

- Only operate the washing machine using cold mains water.
- Do not connect the machine to the mixer tap of an unpressurised hotwater boiler.
- Do not use a used supply hose. Only use the supply hose supplied or one that was purchased from an authorised specialist retailer.

en Positioning and connecting

- Do not bend, squash, modify or cut through the water supply hose (otherwise its strength is no longer guaranteed).
- Only tighten the screw connections by hand. If the screw connections are tightened too much with a tool (pliers), the thread may be damaged.

Optimum water pressure in the supply network

At least 100 kPa (1 bar)

Maximum 1000 kPa (10 bar)


When the tap is open, the water flow is at least 8 l/min.

If the water pressure is higher than this, a pressure-reducing valve must be installed.

Connection


Connect the water supply hose to the water tap (3/4" = 26.4 mm) and to the appliance (not necessary for Aqua-Stop models as this is permanently installed):

Model: Standard






Model: Aqua-Secure



Model: Aqua-Stop



Note: Open the water tap carefully, checking the leak tightness of the connection points. The screw connection is under mains water pressure.

Water outlet

When you are washing at high temperatures, there is a risk of scalding if you come into contact with hot water (e.g. when draining hot water into a washbasin).

Do not reach into the hot water.

Caution! Water damage

If the drain hose slips out of the washbasin or the connection point during draining due to high water pressure, any escaping water may cause water damage.

Secure the drain hose so that it cannot slip out.

Caution! Damage to the appliance/fabrics

If the end of the drain hose is immersed in the drained water, water may be sucked back into the appliance and may damage the appliance/fabrics. Make sure that:

- The plug does not block drainage from the washbasin.
- The end of the drain hose is not immersed in the drained water.
- The water drains away quickly enough.

Note: Do not kink the water drain hose or put strain on it lengthways.


Connection

Drainage into a washbasin





Drainage into a siphon The connection point must be secured using a hose clamp with a diameter of 24 - 40 mm (available from specialist dealers).



 Drainage into a plastic pipe with rubber bushing or into a drainage pit



Levelling

Level the appliance using a spirit level. Incorrect levelling may result in intense noise, vibrations and "wandering".

 Loosen the lock nuts using a wrench, by turning it in a clockwise direction.

- Check the alignment of the washing machine with a spirit level, and adjust it if necessary. Change the height by turning the appliance feet. All four appliance feet must stand firmly on the ground.
- 3. Tighten the lock nut against the housing.
 In doing so, hold the foot tight and do not adjust its height.
 The lock nuts on all four appliance feet must be screwed tightly against the housing.



Electrical connection

There is a risk of electric shock if you touch live components.

- Never touch or hold the mains plug with wet hands.
- Only pull out the mains cable by the plug and never by the cable, as this could damage it.
- Never unplug the mains plug during operation.

Observe the following information and ensure that:

Notes

- The mains voltage and voltage indicated on the washing machine (rating plate) are the same.
 The connected load and fuse required are specified on the rating plate.
- The washing machine is only connected to an alternating current via a properly installed earthed socket.

- The mains plug fits the socket.
- The cable cross-section is adequate.
- The earthing system is properly installed.
- The mains cable is only replaced by a qualified electrician (if this is necessary). Replacement mains cables are available from the aftersales service.
- No multiple plugs/couplings or extension cables are used.
- The mains plug can be accessed at all times.
- The mains cable is not bent, squashed, modified, cut through, or in contact with heat sources.

Before washing for the first time

The washing machine was thoroughly tested before leaving the factory. To remove any water that may be left over from the test, run the first wash cycle **without** any laundry.

Notes

- The washing machine must be correctly installed and connected. (from → Page 35)
- Never use a damaged machine. Inform the after-sales service.

Preparatory work:

- 1. Check the machine.
- 2. Fill the dispenser ® and 8.
 - → Page 21
- **3.** Remove the protective film from the control panel.
- 4. Plug into the mains.
- 5. Turn on the tap.

Run the programme without laundry.

1. Switch on the appliance.

- 2. Close the door (do not load any laundry).
- 3. Set the Drum Clean 90 °C programme.
- 4. Open the detergent drawer.
- **5.** Pour approx. 1 litre of water into the left-hand compartment.
- Pour standard detergent into the lefthand compartment.
 - **Note:** To prevent foaming, only use half of the amount of detergent recommended by the detergent manufacturer. Do not use detergents designed for woollens or delicates.
- 7. Close the detergent drawer.
- 8. Start the programme.
- 9. Switch off the appliance at the end of the programme.

Your washing machine is now ready to use.

Transportation

E.g. when moving house

Caution!

Risk of damage to the appliance caused by detergent/fabric softener leaking from the dispensers.

Leaking detergent/fabric softener can prevent the appliance from working correctly, e.g. due to damage to the electronics.

Empty the dispensers before transporting the appliance.


Preparatory work:

- 1. Turn off the tap.
- Reduce the water pressure in the supply hose: → Page 29; cleaning and maintenance – filter in the water supply clogged
- 3. Disconnect the washing machine from the mains.
- Drain any residual water:
 → Page 28; cleaning and
 maintenance drain pump blocked,
 emergency draining
- 5. Remove the hoses.
- **6.** Empty the dispensers. \rightarrow Page 26


Fitting the transportation securing means:

1. Remove the covers and keep them in a safe place.

If required, use a screwdriver.



2. Insert all four sleeves. Clip the mains cable securely in the holders. Insert the transportation securing bolts and tighten them with a wrench (WAF 13).



Before switching on the appliance again:

Notes

- The transport braces **must** be removed.
- To prevent unused detergent from flowing straight into the drain during the next wash: Pour approx. 1 litre of water into the left-hand compartment II, select programme **Drain/Empty** and start.



Aqua Stop warranty

Only for appliances with Agua-Stop

In addition to warranty claims against the vendor based on the purchase agreement and to our appliance warranty, we will provide compensation under the following conditions:

- 1. If water damage is caused due to a fault in our Aqua-Stop system, we will compensate domestic customers for the damage caused.
- 2. The liability guarantee is valid for the service life of the appliance.
- 3. It is a prerequisite of all warranty claims that the appliance with Aqua-Stop must have been installed and connected correctly in accordance with our instructions; this also includes a correctly fitted Aqua-Stop extension (genuine accessories). Our warranty does not cover defective feed lines or fittings leading to the Agua-Stop connection at the tap.
- need to be supervised during operation, nor secured afterwards by turning off the tap. The tap only needs to be turned off if you are away from home for a long period, e.g. for several weeks'

holiday.

4. Appliances with Aqua-Stop do not

Aqua-Stop warranty

Only for appliances with Aqua-Stop

In addition to warranty claims against the vendor based on the purchase agreement and to our appliance warranty, we will provide compensation under the following conditions:

- If water damage is caused due to a fault in our Aqua-Stop system, we will compensate domestic customers for the damage caused.
- 2. The liability guarantee is valid for the service life of the appliance.
- 3. It is a prerequisite of all warranty claims that the appliance with Aqua-Stop must have been installed and connected correctly in accordance with our instructions; this also includes a correctly fitted Aqua-Stop extension (genuine accessories). Our warranty does not cover defective feed lines or fittings leading to the Aqua-Stop connection at the tap.
- 4. Appliances with Aqua-Stop do not need to be supervised during operation, nor secured afterwards by turning off the tap. The tap only needs to be turned off if you are away from home for a long period, e.g. for several weeks' holiday.





Constructa Neff Vertriebs-GmbH Carl-Wery-Straße 34 D-81739 München

Repair order and advice in the event of faults

GB 0344 892 8989 Calls charged at local or mobile rate.

IE 01450 2655 0.03 € per minute at peak. Off peak 0.0088 € per minute.

You can find the contact information for all countries in the attached after-sales service directory:





9001174391 9702