

User Manual

# GETTING STARTED? EASY.



ZDT26030FA

EN User Manual  
Dishwasher

# ZANUSSI

## SAFETY INFORMATION

---

Before the installation and use of the appliance, carefully read the supplied instructions. The manufacturer is not responsible for any injuries or damages that are the result of incorrect installation or usage. Always keep the instructions in a safe and accessible location for future reference.

### **CHILDREN AND VULNERABLE PEOPLE SAFETY**

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.
- Do not let children play with the appliance.
- Keep detergents away from children.
- Keep children and pets away from the appliance when the door is open.
- Children shall not carry out cleaning and user maintenance of the appliance without supervision.

### **GENERAL SAFETY**

- This appliance is intended to be used in household and similar applications such as:
  - farm houses; staff kitchen areas in shops, offices and other working environments;
  - by clients in hotels, motels, bed & breakfast and other residential type environments.
- Do not change the specification of this appliance.
- The operating water pressure (minimum and maximum) must be between 0.5 (0.05) / 8 (0.8) bar (MPa)
- Obey the maximum number of 13 place settings.
- If the supply cord is damaged, it must be replaced by the manufacturer, its Authorised Service Centre or similarly qualified persons in order to avoid a hazard.

- Put the cutlery in the cutlery basket with the sharp ends pointing down or put them in the cutlery drawer in a horizontal position with the sharp edges down.
- Do not leave the appliance with the open door unattended to avoid stepping accidentally onto it.
- Before any maintenance operation, deactivate the appliance and disconnect the mains plug from the socket.
- Do not use high pressure water sprays and/or steam to clean the appliance.
- If the appliance has ventilation openings in the base, they must not be covered e.g. by a carpet.
- The appliance is to be connected to the water mains using the new supplied hose-sets. Old hose sets must not be reused.

## SAFETY INSTRUCTIONS

### INSTALLATION



**WARNING!** Only a qualified person must install this appliance.

- Remove all the packaging.
- Do not install or use a damaged appliance.
- Do not install or use the appliance where the temperature is less than 0 °C.
- Follow the installation instruction supplied with the appliance.
- Always take care when moving the appliance as it is heavy. Always use safety gloves and enclosed footwear.
- Make sure that the appliance is installed below and adjacent to safe structures.

### ELECTRICAL CONNECTION




**WARNING!** Risk of fire and electrical shock.

- The appliance must be earthed.
- Make sure that the parameters on the rating plate are compatible with the electrical ratings of the mains power supply.
- Always use a correctly installed shockproof socket.
- Do not use multi-plug adapters and extension cables.
- Make sure not to cause damage to the mains plug and to the mains cable. Should the mains cable need to be replaced, this must be carried out by our Authorised Service Centre.

- Connect the mains plug to the mains socket only at the end of the installation. Make sure that there is access to the mains plug after the installation.
- Do not pull the mains cable to disconnect the appliance. Always pull the mains plug.
- This appliance complies with the E.E.C. Directives.
- Only for UK and Ireland. The appliance has a 13 amp mains plug. If it is necessary to change the fuse in the mains plug, use fuse: 13 amp ASTA (BS 1362).

### WATER CONNECTION

- Do not cause damage to the water hoses.
- Before connection to new pipes, pipes not used for a long time, where repair work has been carried out or new devices fitted (water meters, etc.), let the water flow until it is clean and clear.
- Ensure that there are no visible water leaks during and after the first use of the appliance.
- The water inlet hose has a safety valve and a sheath with an inner mains cable.





**WARNING!** Dangerous voltage.

- If the water inlet hose is damaged, immediately close the water tap and disconnect the mains plug from the mains socket. Contact the Authorised Service Centre to replace the water inlet hose.

## USE

- Do not sit or stand on the open door.
- Dishwasher detergents are dangerous. Obey the safety instructions on the detergent packaging.
- Do not drink and play with the water in the appliance.
- Do not remove the dishes from the appliance until the programme is complete. Some detergent may remain on the dishes.
- The appliance can release hot steam if you open the door while a programme operates.
- Do not put flammable products or items that are wet with flammable products in, near or on the appliance.

## SERVICE

- Contact the Authorised Service Centre to repair the appliance. We recommend only the use of original spare parts.
- When you contact the Authorised Service Centre, ensure that you have the following information that is available on the rating plate.  
Model :  
PNC :  
Serial Number :


## DISPOSAL



**WARNING!** Risk of injury or suffocation.

- Disconnect the appliance from the mains supply.
- Cut off the mains cable and discard it.
- Remove the door catch to prevent children and pets to get closed in the appliance.

# EASY START



- 1** On/off button
- 2** Display
- 3** Programme button (up)
- 4** Programme button (down)
- 5** **TimeManager** button
- 6** **XtraDry** button
- 7** Delay button
- 8** **CANCEL** button
- 9** Indicators

## INDICATORS

- | End indicator.
- ⊞ Salt indicator. It is always off while the programme operates.
- ☼ Rinse aid indicator. It is always off while the programme operates.

## BEAM-ON-FLOOR

The Beam-on-Floor is a light that shows on the kitchen floor below the appliance door.

- When the programme starts, a red light comes on and stays on for all the duration of the programme.
- When the programme is completed, a green light comes on.
- When the appliance has a malfunction, the red light flashes.



The Beam-on-Floor goes off when the appliance is deactivated.

## PROGRAMMES

Programme	Degree of soil Type of load	Programme phases	Consumption values 1)		
			Duration (min)	Energy (kWh)	Water (l)
P1 Eco 2)	Normal soil Crockery and cutlery	<ul style="list-style-type: none"> <li>▪ Pre-wash</li> <li>▪ Wash 50 °C</li> <li>▪ Rinses</li> <li>▪ Dry</li> </ul>	240	0.921	9.9

Programme	Degree of soil Type of load	Programme phases	Consumption values 1)		
			Duration (min)	Energy (kWh)	Water (l)
P2 AUTOMATIC <sup>3)</sup>	All Crockery, cut- lery, pots and pans	<ul style="list-style-type: none"> <li>▪ Pre-wash</li> <li>▪ Wash from 45 °C to 70 °C</li> <li>▪ Rinses</li> <li>▪ Dry</li> </ul>	45 - 160	0.7 - 1.5	7 - 12
P3 Intensive	Heavy soil Crockery, cut- lery, pots and pans	<ul style="list-style-type: none"> <li>▪ Pre-wash</li> <li>▪ Wash 70 °C</li> <li>▪ Rinses</li> <li>▪ Dry</li> </ul>	140 - 160	1.4 - 1.6	13-15
P4 Quick 30Min <sup>4)</sup>	Fresh soil Crockery and cutlery	<ul style="list-style-type: none"> <li>▪ Wash 60 °C or 65 °C</li> <li>▪ Rinses</li> </ul>	30	0.8	9
P5 Delicate	Normal or light soil Delicate crock- ery and glass- ware	<ul style="list-style-type: none"> <li>▪ Wash 45 °C</li> <li>▪ Rinses</li> <li>▪ Dry</li> </ul>	70 - 85	0.9 - 1.1	13 - 14
P6 Rinse and Hold <sup>5)</sup>	All	<ul style="list-style-type: none"> <li>▪ Pre-wash</li> </ul>	14	0.1	4

1) The pressure and the temperature of the water, the variations of the mains supply, the options and the quantity of dishes can change the values.

2) With this programme you have the most efficient use of water and energy consumption for crockery and cutlery with normal soil. (Also, it is a standard programme for test institutes).

3) The appliance senses the degree of soil and the quantity of items in the baskets to adjust the temperature and the quantity of the water and to control the energy consumption and the programme duration.

4) With this programme you can wash a load with fresh soil. It gives good washing results in a short period of time.

5) Use this programme to quickly rinse the dishes and to prevent the food remains from drying out on the dishes and to reduce bad odour coming out from the appliance. Do not use detergent with this programme.

## SETTINGS

### PROGRAMME SELECTION MODE

In the programme selection mode, it is possible to set a washing programme and to enter the user mode to change the appliance settings.

To enter the programme selection mode:

Press on/off button.

- The display shows the number of the programme Eco.

- After a few seconds the display shows the programme duration.

If the control panel does not indicate that the appliance is in the programme selection mode, follow the CANCEL procedure.

### CANCEL PROCEDURE

Use CANCEL to:

- Cancel a currently running programme.

- Stop the countdown of Delay option.
- Bring the appliance back to the programme selection mode.

To CANCEL:

Press and hold CANCEL until the control panel indicates the appliance is in the programme selection mode.

## USER MODE

### Settings available in the user mode:

- The level of the water softener according to the water hardness.
- Activation or deactivation of the rinse aid empty notification.
- Activation or deactivation of the acoustic signal indicating the end of a programme.
- Activation or deactivation of AirDry.

Before entering the user mode, make sure the appliance is in the programme selection mode.

To enter the user mode:

Press and hold simultaneously  and  for at least 3 seconds.

The indicators: , , , and  start flashing.

As the appliance stores the saved settings, there is no need to configure it before every cycle.

## ADJUSTING THE WATER SOFTENER

Make sure the appliance is in user mode.

1. Press .
  - The indicators ,  and  are off.
  - The indicator  still flashes.
  - The display shows the current setting: e.g.  = level 5.
2. Press  to change the setting. Each pressing of the button  increases the level number by one. After reaching level 10, the count starts from level 1
3. Press the on/off button to confirm the setting.



If you use multi-tablets containing salt and the hardness of your water is lower than 21°dH, you can set the lowest water softener level. It deactivates the salt refill indicator. If you use standard detergent or multitablets without salt, set the proper water hardness level to keep the salt refill indicator active.

## THE WATER HARDNESS TABLE

German degrees (°dH)	French degrees (°fH)	mmol/l	Clarke degrees	Water softener level
47 - 50	84 - 90	8.4 - 9.0	58 - 63	10
43 - 46	76 - 83	7.6 - 8.3	53 - 57	9
37 - 42	65 - 75	6.5 - 7.5	46 - 52	8
29 - 36	51 - 64	5.1 - 6.4	36 - 45	7
23 - 28	40 - 50	4.0 - 5.0	28 - 35	6
19 - 22	33 - 39	3.3 - 3.9	23 - 27	5 1)
15 - 18	26 - 32	2.6 - 3.2	18 - 22	4
11 - 14	19 - 25	1.9 - 2.5	13 - 17	3
4 - 10	7 - 18	0.7 - 1.8	5 - 12	2
<4	<7	<0.7	< 5	1 2)

1) Factory setting

2) Do not use salt at this level.

## DEACTIVATING THE RINSE AID EMPTY NOTIFICATION

Make sure the appliance is in user mode.

1. Press .
  - The indicators ,  and  are off.
  - The indicator  still flashes.
  - The display shows the current setting:
    -  = rinse aid empty notification activated.
    -  = rinse aid empty notification deactivated.
2. Press  to change the setting.
3. Press on/off button to confirm the setting.



When rinse aid chamber is empty, the rinse aid indicator is turned on notifying to refill rinse aid. If the drying results are satisfactory while using multi-tablets only, it is possible to deactivate the notification for refilling rinse aid. However, for the best drying performance, always use rinse aid. If standard detergent or multi-tablets without rinse aid are used, activate the notification to keep the rinse aid refill indicator active.

## ACTIVATING THE ACOUSTIC SIGNAL FOR THE END OF PROGRAMME

Make sure the appliance is in user mode.

1. Press .
  - The indicators ,  and  are off.
  - The indicator  still flashes.
  - The display shows the current setting:
    -  = acoustic signal deactivated.
    -  = acoustic signal activated.


## BEFORE FIRST USE

1. **Make sure that the current level of the water softener agrees with the hardness of the water supply. If not, adjust the level of the water softener. Contact your local water authority to know the water hardness in your area.**
2. Fill the salt container with special salt for dishwasher.
3. Fill the rinse aid dispenser with special rinse aid for dishwasher.
4. Open the water tap.

2. Press  to change the setting.
3. Press the on/off button to confirm the setting.

## HOW TO DEACTIVATE AIRDRY

AirDry improves the drying results with less energy consumption.



While the drying phase operates, the device opens the appliance door. The door is then kept ajar.

By default, AirDry is activated with all programmes excluding Rinse and Hold (if applicable), but it is possible to deactivate it.

Make sure the appliance is in user mode.

1. Press .

The indicators: , ,  are off. The indicator  still flashes.

The display shows the current setting:  = AirDry activated.

2. Press  to change the setting:  = AirDry deactivated.
3. Press on/off to confirm and save the setting.



**CAUTION!** If children have access to the appliance, it is advised to deactivate AirDry as opening the door may pose a danger.

5. Start a programme to remove any processing residuals that can still be inside the appliance. Do not use detergent and do not load the baskets.


## THE SALT CONTAINER



**CAUTION!** Use rough salt designed for dishwashers only. Fine salt increases the risk of corrosion.

The salt is used to recharge the resin in the water softener and to assure good washing results in daily use.

### Adding salt




Before the first use, put one litre of water in the salt container.



**CAUTION!** Water and salt can come out of the salt container during filling. To prevent corrosion, start a programme immediately after filling the salt container.

### ADDING RINSE AID



The rinse aid helps to dry the dishes without streaks and stains. It is automatically released during the hot rinse phase.


## DAILY USE

1. Open the water tap.
  2. Press the on/off button to activate the appliance.
- Make sure that the appliance is in programme selection mode.

- If the salt indicator is on, fill the salt container.


- If the rinse aid indicator is on, fill the rinse aid dispenser.
3. Load the baskets.
  4. Add the detergent.
  5. Set and start the correct programme for the type of load and the degree of soil.

## ADDING DETERGENT



If the programme has a prewash phase, put a small quantity of detergent also in compartment **B**.

## ADDING MULTI-TABLETS



- Adjust the water softener to the lowest level.

## SETTING AND STARTING A PROGRAMME

### The AUTO OFF function

This function decreases energy consumption by deactivating automatically the appliance when it is not operating.

The function comes into operation:

- 5 minutes after the completion of the programme.
- After 5 minutes if the programme has not started.

### Starting a programme

1. Keep the appliance door ajar.
2. Press the on/off button to activate the appliance. Make sure that the appliance is in programme selection mode.
3. Press one of the programme buttons until the display shows the number of the desired programme. The display shows the programme duration after some seconds.
4. Set the applicable options.
5. Close the appliance door to start the programme.

### Option Delay

1. Set a programme.
2. Press  until the display shows the delay time you want to set (1-24h).

The delay time flashes in the display.

3. Close the appliance door. The countdown starts to decrease by 1 hour.

When the countdown is complete the programme starts.

### Option XtraDry

Activate this option to boost the drying performance. With XtraDry on, the duration of some programmes, water consumption and the last rinse temperature can be affected.

XtraDry is a permanent option for all programmes other than Eco and need not to be selected at every cycle.

In the other programmes the setting of XtraDry is permanent and it is automatically used in next cycles. This configuration can be changed at any time

This option is not available with Rinse and Hold.

### Option TimeManager

This option increases the pressure and the temperature of the water. The washing and the drying phases are shorter.

The total programme duration decreases by approximately 50%.

The washing results are the same as with the normal programme duration. The drying results can decrease.

If the option is not applicable to the programme, the related indicator does not turn on or it flashes quickly for a few seconds and then turns off.

### Opening the door while the appliance operates

Opening the door while a programme is running stops the appliance. It may affect the energy consumption and the programme duration. After closing the door, the appliance continues from the point of interruption.

 If the door is opened during the drying phase, before AirDry automatically opens it, the programme ends after 30 seconds.

 If the door is closed after it is opened automatically by AirDry in the drying phase, the programme ends after 3 minutes.

 Do not try to close the appliance door within 2 minutes after AirDry automatically opens it, as this may cause damage to the appliance.

### End of the programme

When the programme is completed the display shows 0:00 and the end indicator is on.

All buttons are inactive except for the on/off button.

1. Press the on/off button or wait for the AUTO OFF function to automatically deactivate the appliance.

If you open the door before the activation of AUTO OFF, the appliance is automatically deactivated.

2. Close the water tap.

## HINTS AND TIPS

---

### GENERAL

The following hints will ensure optimal cleaning and drying results in daily use and also help to protect the environment.

- Remove larger residues of food from the dishes into the waste bin.
- Do not pre-rinse dishes by hand. When needed, use the prewash programme (if available) or select a programme with a prewash phase.
- Always use the whole space of the baskets.
- When loading the appliance, make sure that the dishes can be completely reached and washed by the water released from the spray arm nozzles. Make sure that items do not touch or cover each other.
- You can use dishwasher detergent, rinse aid and salt separately or you can use the multi-tablets (e.g. "3in1", "4in1", "All in 1"). Follow the instructions written on the packaging.
- Select the programme according to the type of load and degree of soil. With the ECO programme you have the most efficient use of water and energy consumption for crockery and cutlery with normal soil.

### THE WATER SOFTENER

The water softener removes minerals from the water supply, which would have a detrimental effect on the washing results and on the appliance.

The higher the content of these minerals, the harder your water is. Water hardness is measured in equivalent scales.

The water softener should be adjusted according to the hardness of the water in your area. Your local water authority can advise you on the hardness of the water in your area. It is important to set the right level of the water softener to assure good washing results.

### USING SALT, RINSE AID AND DETERGENT

- Only use salt, rinse aid and detergent for dishwasher. Other products can cause damage to the appliance.
- In areas with hard and very hard water we recommend to use plain dishwasher detergent (powder, gel, tablets containing no additional agents), rinse aid and salt separately for optimal cleaning and drying results.
- At least once a month run the appliance with the use of appliance cleaner which is particularly suitable for this purpose.
- Detergent tablets do not fully dissolve with short programmes. To prevent detergent residues on the tableware, we recommend that you use the tablets with long programmes.
- Do not use more than the correct quantity of detergent. Refer to the instructions on the detergent packaging.

## WHAT TO DO IF YOU WANT TO STOP USING MULTI-TABLETS

Before you start to use separately detergent, salt and rinse aid do the following procedure.

1. Set the highest level of the water softener.
2. Make sure that the salt and rinse aid containers are full.
3. Start the shortest programme with a rinsing phase. Do not add detergent and do not load the baskets.
4. When the programme is completed, adjust the water softener according to the water hardness in your area.
5. Adjust the released quantity of rinse aid.
6. Activate the rinse aid empty notification.

## LOADING THE BASKETS

- Only use the appliance to wash items that are dishwasher-safe.
- Do not put in the appliance items made of wood, horn, aluminium, pewter and copper.
- Do not put in the appliance items that can absorb water (sponges, household cloths).
- Remove remaining food from the items.
- Make soft the remaining burned food on the items.
- Put hollow items (cups, glasses and pans) with the opening down.
- Make sure that cutlery and dishes do not bond together. Mix spoons with other cutlery.
- Make sure that glasses do not touch other glasses.

- Put small items in the cutlery basket.
- Put light items in the upper basket. Make sure that the items do not move.
- Make sure that the spray arm can move freely before you start a programme.

## BEFORE STARTING A PROGRAMME

Make sure that:

- The filters are clean and correctly installed.
- The cap of the salt container is tight.
- The spray arms are not clogged.
- There is dishwasher salt and rinse aid (unless you use multi- tablets).
- The position of the items in the baskets is correct.
- The programme is applicable for the type of load and for the degree of soil.
- The correct quantity of detergent is used.

## UNLOADING THE BASKETS

1. Let the tableware cool down before you remove it from the appliance. Hot items can be easily damaged.
2. First remove items from the lower basket, then from the upper basket.



At the end of the program water can still remain on the sides and on the door of the appliance.

## CARE AND CLEANING








**WARNING!** Before maintenance, deactivate the appliance and disconnect the mains plug from the main socket.



Dirty filters and clogged spray arms decrease the washing results. Make a check regularly and, if necessary, clean them.

## CLEANING THE FILTERS





- Make sure that there are no residues of food or soil in or around the edge of the sump.
- Put back in place the flat filter (C). Make sure that it is correctly positioned under the 2 guides.
- Reassemble the filters (A) and (B).
- Put back the filter (A) in the flat filter (C). Turn it clockwise until it locks.

**i** An incorrect position of the filters can cause bad washing results and damage to the appliance

### CLEANING THE SPRAY ARMS

Do not remove the spray arms. If the holes in the spray arms are clogged, remove remaining parts of soil with a thin pointed object.

### EXTERNAL CLEANING

- Clean the appliance with a moist soft cloth.
- Only use neutral detergents.
- Do not use abrasive products, abrasive cleaning pads or solvents.

- If you regularly use short duration programmes, these can leave deposits of grease and limescale inside the appliance. To prevent this, we recommend to run long duration programmes at least 2 times per month.
- To maintain the performance of your appliance at its best, we recommend to use monthly a specific cleaning product for dishwashers. Follow carefully the instructions on the packaging of the product.

### INTERNAL CLEANING

- Carefully clean the appliance, including the rubber gasket of the door, with a soft damp cloth.

## TROUBLESHOOTING

If the appliance does not start or it stops during operation, first check if you can solve the problem by yourself with the help of the information in the table or contact an Authorised Service Centre.

**With some problems, the display shows an alarm code.**

**The majority of problems that can occur can be solved without the need to contact an Authorised Service Centre.**

**!** **WARNING!** Repairs not properly done may result in serious risk to the safety of the user. Any repairs must be performed by qualified personnel.

Problem and alarm code	Possible cause and solution
You cannot activate the appliance.	<ul style="list-style-type: none"> <li>▪ Make sure that the mains plug is connected to the mains socket.</li> <li>▪ Make sure that there is no damaged fuse in the fuse box.</li> </ul>

Problem and alarm code	Possible cause and solution
The program does not start.	<ul style="list-style-type: none"> <li>▪ Make sure that the appliance door is closed.</li> <li>▪ If the delay start is set, cancel the setting or wait for the end of the countdown.</li> <li>▪ The appliance has started the procedure to recharge the resin inside the water softener. The duration of the procedure is approximately 5 minutes.</li> </ul>
<p>The appliance does not fill with water.</p> <p>The display shows <i>10</i> or <i>11</i>.</p>	<ul style="list-style-type: none"> <li>▪ Make sure that the water tap is open.</li> <li>▪ Make sure that the pressure of the water supply is not too low. For this information, contact your local water authority.</li> <li>▪ Make sure that the water tap is not clogged.</li> <li>▪ Make sure that the filter in the inlet hose is not clogged.</li> <li>▪ Make sure that the inlet hose has no kinks or bends.</li> </ul>
<p>The appliance does not drain the water.</p> <p>The display shows <i>20</i>.</p>	<ul style="list-style-type: none"> <li>▪ Make sure that the sink spigot is not clogged.</li> <li>▪ Make sure that the filter in the outlet hose is not clogged.</li> <li>▪ Make sure that the interior filter system is not clogged.</li> <li>▪ Make sure that the drain hose has no kinks or bends.</li> </ul>
<p>The anti-flood device is on.</p> <p>The display shows <i>30</i>.</p>	<ul style="list-style-type: none"> <li>▪ Close the water tap and contact an Authorised Service Centre.</li> </ul>
The appliance stops and starts more times during operation.	<ul style="list-style-type: none"> <li>▪ It is normal. It provides optimal cleaning results and energy savings.</li> </ul>
The program lasts too long.	<ul style="list-style-type: none"> <li>▪ Select the TimeManager option to shorten the program time.</li> <li>▪ If the delayed start option is set, cancel the delay setting or wait for the end of the countdown.</li> </ul>
The remaining time in the display increases and skips nearly to the end of program time.	<ul style="list-style-type: none"> <li>▪ This is not a defect. The appliance is working correctly.</li> </ul>
Small leak from the appliance door.	<ul style="list-style-type: none"> <li>▪ The appliance is not levelled. Loosen or tighten the adjustable feet (if applicable).</li> <li>▪ The appliance door is not centred on the tub. Adjust the rear foot (if applicable).</li> </ul>
The appliance door is difficult to close.	<ul style="list-style-type: none"> <li>▪ The appliance is not levelled. Loosen or tighten the adjustable feet (if applicable).</li> <li>▪ Parts of the tableware are protruding from the baskets.</li> </ul>
Rattling/knocking sounds from inside the appliance.	<ul style="list-style-type: none"> <li>▪ The tableware is not properly arranged in the baskets. Refer to basket loading leaflet.</li> <li>▪ Make sure that the spray arms can rotate freely.</li> </ul>
The appliance trips the circuit-breaker.	<ul style="list-style-type: none"> <li>▪ The amperage is insufficient to supply simultaneously all the appliances in use. Check the socket amperage and the capacity of the meter or turn off one of the appliances in use.</li> <li>▪ Internal electrical fault of the appliance. Contact an Authorised Service Centre.</li> </ul>



Refer to "**Before first use**", "**Daily use**", or "**Hints and tips**" for other possible causes.

For alarm codes not described in the table, contact an Authorised Service Centre.

Once you have checked the appliance, deactivate and activate the appliance. If the problem occurs again, contact an Authorised Service Centre.

## THE WASHING AND DRYING RESULTS ARE NOT SATISFACTORY

Problem	Possible cause and solution
Poor washing results.	<ul style="list-style-type: none"><li>Refer to "<b>Daily use</b>", "<b>Hints and tips</b>" and basket loading leaflet.</li><li>Use more intensive washing programmes.</li><li>Clean spray arm jets and filter. Refer to "<b>Care and Cleaning</b>".</li></ul>
Poor drying results.	<ul style="list-style-type: none"><li>Tableware has been left for too long inside a closed appliance.</li><li>There is no rinse aid or the dosage of rinse aid is not enough. Set the rinse aid dispenser to a higher level.</li><li>Plastic items may need to be towel dried.</li><li>For the best drying performance activate the option XtraDry and set AirDry.</li><li>We recommend to always use rinse aid, even in combination with multi-tablets.</li></ul>
There are whitish streaks or bluish layers on glasses and dishes.	<ul style="list-style-type: none"><li>The release quantity of rinse aid is too much. Adjust the rinse aid level to a lower level.</li><li>The quantity of detergent is too much.</li></ul>
There are stains and dry water drops on glasses and dishes.	<ul style="list-style-type: none"><li>The released quantity of rinse aid is not sufficient. Adjust the rinse aid level to a higher level.</li><li>The quality of the rinse aid can be the cause.</li></ul>
The dishes are wet.	<ul style="list-style-type: none"><li>For the best drying performance activate the option XtraDry and set AirDry .</li><li>The programme does not have a drying phase or has a drying phase with low temperature.</li><li>The rinse aid dispenser is empty.</li><li>The quality of the rinse aid can be the cause.</li><li>The quality of the multi-tablets can be the cause. Try a different brand or activate the rinse aid dispenser and use rinse aid and multi-tablets together.</li></ul>
The interior of the appliance is wet.	<ul style="list-style-type: none"><li>This is not a defect of the appliance, it is caused by the humidity in the air that condenses on the walls.</li></ul>
Unusual foam during washing.	<ul style="list-style-type: none"><li>Use the detergent for dishwashers only.</li><li>There is a leak in the rinse aid dispenser. Contact an Authorised Service Centre.</li></ul>
Traces of rust on cutlery.	<ul style="list-style-type: none"><li>There is too much salt in the water used for washing. Refer to "<b>The water softener</b>".</li><li>Silver and stainless steel cutlery were placed together. Avoid to put silver and stainless steel items close together.</li></ul>

Problem	Possible cause and solution
There are residues of detergent in the dispenser at the end of the programme.	<ul style="list-style-type: none"> <li>▪ The detergent tablet got stuck in the dispenser and therefore was not completely washed away by water.</li> <li>▪ Water cannot wash away the detergent from the dispenser. Make sure that the spray arm is not blocked or clogged.</li> <li>▪ Make sure that items in the baskets do not impede the lid of the detergent dispenser from opening.</li> </ul>
Odours inside the appliance.	<ul style="list-style-type: none"> <li>▪ Refer to "<b>Internal cleaning</b>".</li> </ul>
Limescale deposits on the tableware, on the tub and on the inside of the door.	<ul style="list-style-type: none"> <li>▪ The level of salt is low, check the refill indicator.</li> <li>▪ The cap of the salt container is loose.</li> <li>▪ Your tap water is hard. Refer to "<b>The water softener</b>".</li> <li>▪ Even using multi-functional tabs use salt and set regeneration of the water softener. Refer to "<b>The water softener</b>".</li> <li>▪ If lime scale deposits still remain, clean the appliance with appliance cleaners which are particularly suitable for this purpose.</li> <li>▪ Try different detergent.</li> <li>▪ Contact the detergent manufacturer.</li> </ul>
Dull, discoloured or chipped tableware.	<ul style="list-style-type: none"> <li>▪ Make sure that only dishwasher-safe items are washed in the appliance.</li> <li>▪ Load and unload the basket carefully. Refer to basket loading leaflet.</li> <li>▪ Place delicate items in the upper basket.</li> </ul>



Refer to "**Before first use**", "**Daily use**" or "**Hints and tips**" for other possible causes.


## TECHNICAL INFORMATION

Dimensions	Width / height / depth (mm)	596 / 818 - 898 / 550
Electrical connection <sup>1)</sup>	Voltage (V)	220 - 240
	Frequency (Hz)	50
Water supply pressure	Min. / max. bar (MPa)	0.5 (0.05) / 8 (0.8)
Water supply	Cold water or hot water <sup>2)</sup>	max 60 °C
Capacity	Place settings	13
Power consumption	Left-on mode (W)	5.0
Power consumption	Off-mode (W)	0.50

**1)** Refer to the rating plate for other values.

**2)** If the hot water comes from alternative source of energy, (e.g. solar panels, aeolian energy), use the hot water supply to decrease energy consumption.

## RATING PLATE



## INFORMATION FOR TEST INSTITUTES

For all the necessary information for test performance, send an email to:

**[info.test@dishwasher-production.com](mailto:info.test@dishwasher-production.com)**

Write down the product number (PNC) that is on the rating plate.

## ENVIRONMENTAL CONCERNS

---

Recycle the materials with the symbol . Put the packaging in applicable containers to recycle it. Help protect the environment and human health and to recycle waste of electrical and electronic appliances. Do not dispose appliances marked with

the symbol  with the household waste. Return the product to your local recycling facility or contact your municipal office.





[WWW.ZANUSSI.COM/SHOP](http://WWW.ZANUSSI.COM/SHOP)



CE

156915480-A-092017