

# GETTING STARTED?



ZOPNA7K1 ZOPNA7X1

EN User Manual Oven

ZANUSSI

## **VISIT OUR WEBSITE FOR:**



Get usage advice, brochures, trouble shooter, service and repair information:

www.zanussi.com/support

## **↑ SAFETY INFORMATION**

Before the installation and use of the appliance, carefully read the supplied instructions. The manufacturer is not responsible for any injuries or damage that are the result of incorrect installation or usage. Always keep the instructions in a safe and accessible location for future reference.

## CHILDREN AND VULNERABLE PEOPLE SAFETY

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.
- Children between 3 and 8 years of age and persons with very extensive and complex disabilities shall be kept away from the appliance unless continuously supervised.
- Children of less than 3 years of age should be kept away from the appliance unless continuously supervised.
- Do not let children play with the appliance.
- Keep all packaging away from children and dispose of it appropriately.
- Keep children and pets away from the appliance when it operates or when it cools down. Accessible parts become hot during use.
- If the appliance has a child safety device, it should be activated.
- Children shall not carry out cleaning and user maintenance of the appliance without supervision.

## **GENERAL SAFETY**

Only a qualified person must install this appliance and replace the cable.

- WARNING: The appliance and its accessible parts become hot during use. Care should be taken to avoid touching heating elements.
- Always use oven gloves to remove or put in accessories or ovenware.
- Before carrying out any maintenance, disconnect the appliance from the power supply.
- WARNING: Ensure that the appliance is switched off before replacing the lamp to avoid the possibility of electric shock.
- Do not use the appliance before installing it in the built-in structure.
- Do not use a steam cleaner to clean the appliance.
- Do not use harsh abrasive cleaners or sharp metal scrapers to clean the glass door since they can scratch the surface, which may result in shattering of the glass.
- If the mains power supply cable is damaged, it must be replaced by the manufacturer, its Authorised Service Centre or similarly qualified persons to avoid an electrical hazard.
- Excessive spillage must be removed before the pyrolytic cleaning. Remove all parts from the oven.
- To remove the shelf supports first pull the front of the shelf support and then the rear end away from the side walls. Install the shelf supports in the opposite sequence.
- The means for disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.

## SAFETY INSTRUCTIONS

#### INSTALLATION



**WARNING!** Only a qualified person must install this appliance.

- Remove all the packaging.
- Do not install or use a damaged appliance.
- Follow the installation instructions supplied with the appliance.
- Always take care when moving the appliance as it is heavy. Always use safety gloves and enclosed footwear.
- Do not pull the appliance by the handle.
- Install the appliance in a safe and suitable place that meets installation requirements.

- Keep the minimum distance from other appliances and units.
- Before mounting the appliance, check if the oven door opens without restraint.
- The appliance is equipped with an electric cooling system. It must be operated with the electric power supply.

Cabinet minimum height (Cabinet under the worktop minimum height)	580 (600) mm
Cabinet width	560 mm

Cabinet depth	550 (550) mm
Height of the front of the appliance	589 mm
Height of the back of the appliance	571 mm
Width of the front of the appliance	595 mm
Width of the back of the appliance	559 mm
Depth of the appliance	569 mm
Built in depth of the appliance	548 mm
Depth with open door	1022 mm
Ventilation opening minimum size. Opening placed on the bottom rear side	560x20 mm
Mounting screws	4x25 mm

#### **ELECTRICAL CONNECTION**



**WARNING!** Risk of fire and electric shock.

- All electrical connections should be made by a qualified electrician.
- The appliance must be earthed.
- Make sure that the parameters on the rating plate are compatible with the electrical ratings of the mains power supply.
- Always use a correctly installed shockproof socket.
- Do not use multi-plug adapters and extension cables.
- Make sure not to cause damage to the mains plug and to the mains cable. Should the mains cable need to be replaced, this must be carried out by our Authorised Service Centre.
- Do not let mains cables touch or come near the appliance door or the niche below the appliance, especially when it operates or the door is hot.
- The shock protection of live and insulated parts must be fastened in such a way that it cannot be removed without tools.
- Connect the mains plug to the mains socket only at the end of the installation. Make sure that there is access to the mains plug after the installation.
- If the mains socket is loose, do not connect the mains plug.

- Do not pull the mains cable to disconnect the appliance. Always pull the mains plug.
- Use only correct isolation devices: line protecting cut-outs, fuses (screw type fuses removed from the holder), earth leakage trips and contactors.
- The electrical installation must have an isolation device which lets you disconnect the appliance from the mains at all poles. The isolation device must have a contact opening width of minimum 3 mm.
- Fully close the appliance door before you connect the mains plug to the mains socket.
- This appliance is supplied without a main plug and a main cable.

# Cable types applicable for installation or replacement for Europe:

H07 RN-F, H05 RN-F, H05 RRF, H05 VV-F, H05 V2V2-F (T90), H05 BB-F

For the section of the cable refer to the total power on the rating plate. You can also refer to the table:

Total power (W)	Section of the cable (mm²)
maximum 1380	3 x 0.75
maximum 2300	3 x 1
maximum 3680	3 x 1.5

The earth cord (green / yellow cable) must be 2 cm longer than phase and neutral cables (blue and brown cables).

# Cable types applicable for installation or replacement for UK only

Connection via	Min. size ca- ble / flex	Cable / flex type / Fuse
Oven Control Circuit	2,5 mm²	PVC / PVC twin and earth / 15 A min. PVC / PVC twin and earth / 20 A max.



#### USE



**WARNING!** Risk of injury, burns and electric shock or explosion.

- This appliance is for household use only.
- Do not change the specification of this appliance.
- Make sure that the ventilation openings are not blocked.
- Do not let the appliance stay unattended during operation.
- Deactivate the appliance after each use.
- Be careful when you open the appliance door while the appliance is in operation. Hot air can release.
- Do not operate the appliance with wet hands or when it has contact with water.
- Do not apply pressure on the open door.
- Do not use the appliance as a work surface or as a storage surface.
- Open the appliance door carefully. The use of ingredients with alcohol can cause a mixture of alcohol and air.
- Do not let sparks or open flames to come in contact with the appliance when you open the door.
- Do not put flammable products or items that are wet with flammable products in, near or on the appliance.



**WARNING!** Risk of damage to the appliance.

- To prevent damage or discoloration to the enamel:
  - do not put ovenware or other objects in the appliance directly on the bottom.
  - do not put aluminium foil directly on the bottom of cavity of the appliance.
  - do not put water directly into the hot appliance.
  - do not keep moist dishes and food in the appliance after you finish the cooking.
  - be careful when you remove or install the accessories.
- Discoloration of the enamel or stainless steel has no effect on the performance of the appliance.
- Use a deep pan for moist cakes. Fruit juices cause stains that can be permanent.
- This appliance is for cooking purposes only. It must not be used for other purposes, for example room heating.
- Always cook with the oven door closed.
- If the appliance is installed behind a furniture panel (e.g. a door) make sure the door is never closed when the appliance operates. Heat and

moisture can build up behind a closed furniture panel and cause subsequent damage to the appliance, the housing unit or the floor. Do not close the furniture panel until the appliance has cooled down completely after use.

#### **CARE AND CLEANING**



**WARNING!** Risk of injury, fire, or damage to the appliance.

- Before maintenance, deactivate the appliance and disconnect the mains plug from the mains socket.
- Make sure the appliance is cold. There is the risk that the glass panels can break.
- Replace immediately the door glass panels when they are damaged. Contact the Authorised Service Centre.
- Be careful when you remove the door from the appliance. The door is heavy!
- Clean regularly the appliance to prevent the deterioration of the surface material.
- Clean the appliance with a moist soft cloth. Use only neutral detergents. Do not use abrasive products, abrasive cleaning pads, solvents or metal objects.
- If you use an oven spray, follow the safety instructions on its packaging.

#### **PYROLYTIC CLEANING**



**WARNING!** Risk of Injury / Fires / Chemical Emissions (Fumes) in Pyrolytic Mode.

- Before carrying out a Pyrolitic self-cleaning function or the First Use please remove from the oven cavity:
  - any excess food residues, oil or grease spills / deposits.
  - any removable objects (including shelves, side rails etc., provided with the product) particularly any non-stick pots, pans, trays, utensils etc.
- Read carefully all the instructions for Pyrolytic cleaning.
- Keep children away from the appliance while the Pyrolytic cleaning operates.
   The appliance becomes very hot and hot air is released from the front cooling vents.
- Pyrolytic cleaning is a high temperature operation that can release fumes from cooking residues and construction materials, as such consumers are strongly advised to:
  - provide good ventilation during and after each Pyrolytic cleaning.

- provide good ventilation during and after the first use at maximum temperature operation.
- Unlike all humans, some birds and reptiles can be extremely sensitive to potential fumes emitted during the cleaning process of all Pyrolytic Ovens.
  - Remove any pets (especially birds) from the vicinity of the appliance location during and after the Pyrolytic cleaning and first use maximum temperature operation to a well ventilated area.
- Small pets can also be highly sensitive to the localized temperature changes in the vicinity of all Pyrolytic Ovens when the Pyrolytic self cleaning program is in operation.
- Non-stick surfaces on pots, pans, trays, utensils etc., can be damaged by the high temperature Pyrolytic cleaning operation of all Pyrolytic Ovens and can be also a source for low level harmful fumes.
- Fumes released from all Pyrolytic Ovens / Cooking Residues as described are not harmful to humans, including children, or persons with medical conditions.

- The type of light bulb or halogen lamp used for this appliance is for household appliances only.
   Do not use it for house lighting.
- Before replacing the lamp, disconnect the appliance from the power supply.
- Use only lamps with the same specifications.

#### **SERVICE**

- To repair the appliance contact the Authorised Service Centre.
- Use original spare parts only.

#### **DISPOSAL**



**WARNING!** Risk of injury or suffocation.

- Disconnect the appliance from the mains supply.
- Cut off the mains electrical cable close to the appliance and dispose of it.
- Remove the door catch to prevent children or pets from becoming trapped in the appliance.

#### INTERNAL LIGHTING




WARNING! Risk of electric shock.


## INSTALLATION




**WARNING!** Refer to Safety chapters.

#### **BUILDING IN**






#### **SECURING THE OVEN TO THE CABINET**



## PRODUCT DESCRIPTION

#### **GENERAL OVERVIEW**



- 1 Control panel
- 2 Knob for the heating functions
- 3 Display
- 4 Control knob (for the temperature)
- 5 Heating element
- 6 Lamp
- 7 Fan
- 8 Shelf support, removable
- 9 Shelf positions

#### **ACCESSORIES**

- Wire shelf
  - For cookware, cake tins, roasts.
- Grill- / Roasting pan

To bake and roast or as pan to collect fat.

AirFry

To fry food with less oil or without baking paper.

#### Trivet

For roasting and grilling.



Use the trivet only with the Grill- / roasting pan.

## **CONTROL PANEL**

#### **BUTTONS**

Sensor field / Button	Description
	To set the MINUTE MINDER. Hold it for more than 3 seconds to turn on or turn off the oven lamp.
<u> </u>	To set a clock function.
°C	To check the oven temperature or the temperature of the core temperature sensor (if applicable). Use only while a heating function operates.

#### **DISPLAY**



- A. Timer / Temperature
- B. Heat-up and residual heat indicator
- C. Food Sensor (selected models only)
- D. Door lock (selected models only)
- E. Hours / minutes
- F. Demo Mode
- G. Clock functions

## **BEFORE FIRST USE**



WARNING! Refer to Safety chapters.

Set the time before you use the oven.

#### **INITIAL CLEANING**

Step 1	Step 2	Step 3
Remove all accessories and removable shelf supports from the oven.	Clean the oven and the accessories with a soft cloth, warm water and a mild detergent.	Place the accessories and the removable shelf supports in the oven.

#### **INITIAL PREHEATING**

#### Preheat the empty oven before the first use.

Step 1	Remove all accessories and removable shelf supports from the oven.
Step 2	Set the maximum temperature for the function: .  Let the oven operate for 1 h.
Step 3	Set the maximum temperature for the function:  .  Let the oven operate for 15 min.

<sup>(</sup>i) The oven can emit an odour and smoke during preheating. Make sure that the room is ventilated.

## **DAILY USE**



WARNING! Refer to Safety chapters.

#### **RETRACTABLE KNOBS**

To use the appliance press the knob. The knob comes out.

#### **HEATING FUNCTIONS**

Oven function	Application
0	The oven is off.
Off position	

Oven function	Application
True Fan Cooking	To bake on up to three shelf positions at the same time and to dry food. Set the temperature 20 - 40 °C lower than for Conventional Cooking.
Conventional Cooking	To bake and roast food on one shelf position.

Oven function	Application
Moist Fan Bak- ing	This function is designed to save energy during cooking. When you use this function, the temperature in the cavity may differ from the set temperature. The residual heat is used. The heating power may be reduced. For more information refer to "Daily Use" chapter, Notes on: Moist Fan Baking.
Fast Grilling	To grill thin pieces of food in large quantities and to toast bread.
Turbo Grilling	To roast large meat joints or poultry with bones on one shelf position. To make gratins and to brown.
Pizza Function / AirFry	To bake pizza. To make intensive browning and a crispy bottom.  To fry food with less oil or without baking paper. For dishes like french fries or pizza.
Meat	To prepare very tender and juicy roasts.
Keep Warm	To keep food warm.
Defrost	To defrost food (vegetables and fruit). The defrosting time depends on the amount and size of the frozen food.

Oven function	Application
Pyrolysis	To turn on the pyrolytic cleaning of the oven. This function burns off residual dirt in the oven.

#### NOTES ON: MOIST FAN BAKING

This function was used to comply with the energy efficiency class and ecodesign requirements according to EU 65/2014 and EU 66/2014. Tests according to EN 60350-1.

The oven door should be closed during cooking so that the function is not interrupted and the oven operates with the highest energy efficiency possible.

When you use this function the lamp automatically turns off after 30 sec.



For the cooking instructions refer to "Hints and tips" chapter, Moist Fan Baking. For general energy saving recommendations refer to "Energy Efficiency" chapter, Energy Saving.

#### **HOW TO SET: HEATING FUNCTION**

Step 1	Turn the knob for the heating functions to select a heating function.
Step 2	Turn the control knob to select the temperature.
Step 3	When the cooking ends, turn the knob for the heating functions to the off position to turn off the oven.

#### **HEAT-UP INDICATOR**

When the oven function operates, the bars in the display  $\stackrel{\clubsuit}{=}$  appear one by one when the temperature in the oven increases, and disappear when it decreases.

## **CLOCK FUNCTIONS**

#### **CLOCK FUNCTIONS TABLE**

Clock function	Application
Time of Day	To show or change the time of day. You can change the time of day only when the oven is off.
→  Duration	To set the length of cooking. Use only when a heating function is set.
→  End Time	To set the oven turn-off time. Use only when a heating function is set.
→ →  Time Delay	Combination of functions: Duration, End Time.
Minute Minder	To set a countdown time. This function has no effect on the operation of the oven.  Minute Minder - can be set at any time, also if the oven is off.

#### **HOW TO SET: TIME OF DAY**

After the first connection to the mains, wait until the display shows: hr, 12:00. 12 - flashes.

Step 1	Turn the knob for the temperature to set the hour.
Step 2	- press to confirm. The display shows the set hour and: <b>min</b> . <b>00</b> - flashes.
Step 3	Turn the knob for the temperature to set the minutes.
Step 4	- press to confirm. The display shows the set time.
① - pres	s repeatedly to change the time of day. O - flashes in the display.

#### **HOW TO SET FUNCTION: DURATION**

Step 1	Set a heating function.
Step 2	① - press repeatedly. → I - starts to flash.
Step 3	Turn the control knob to set the minutes. $igodot$ - press to confirm.
Step 4	Turn the knob for the temperature to set the hour.  - press to confirm. When the set time ends the signal sounds for 2 min. Time setting flashes in the display. The oven turns off automatically.
Step 5	Press any button to stop the signal.
Step 6	Turn the knob for the heating functions to the off position.

#### **HOW TO SET FUNCTION: END TIME**

Step 1	Set a heating function.
Step 2	① - press repeatedly. → - starts to flash.
Step 3	Turn the knob for the temperature to set the hour. ① - press to confirm.
Step 4	Turn the knob for the temperature to set the minutes.  - press to confirm.  At the set end time the signal sounds for 2 min. The time setting flashes in the display.  The oven turns off automatically.
Step 5	Press any button to stop the signal.
Step 6	Turn the knob for the heating functions to the off position.

#### **HOW TO SET FUNCTION: TIME DELAY**

Step 1	Set a heating function.
Step 2	① - press repeatedly. → I - starts to flash.
Step 3	Turn the knob for the temperature to set the minutes for the function: Duration. Press: ①.
Step 4	Turn the knob for the temperature to set the hour for the function: Duration.  Press: ①.  The display shows: → I.
Step 5	Turn the knob for the temperature to set the hour for the function: End Time.  Press: ①.
Step 6	Turn the knob for the temperature to set the minutes for the function: End Time.  Press: ①.

The display shows: the set temperature,  $| \rightarrow |$ ,  $\rightarrow |$ . Oven turns on automatically later on, works for the set Duration time and stops at the set End Time. At the set End Time the signal sounds for 2 min. The time setting flashes in the display. The oven turns

off.

Step 7 Press any button to stop the signal.

Turn the knob for the heating functions to the off position.

#### **HOW TO SET FUNCTION: MINUTE MINDER**

Minute minder can be both set when the oven is turned on and off.

Step 1	$\bigcap_{-\stackrel{\frown}{N}^{-3s}}$ - press repeatedly. $\bigcap_{-\stackrel{\frown}{N}}$ , <b>00</b> - flash.
Step 2	Turn the knob for the temperature to set the seconds and then the minutes. When the time you set is longer than 60 min, <b>hr</b> flashes in the display.

Step 8

Step 3	Set the hours.  Minute Minder - starts automatically after 5 sec.  After 90% of the set time the signal sounds.
Step 4	When the set time ends the signal sounds for 2 min. <b>00:00</b> , $\triangle$ - flash in the display. Press any button to stop the signal.

## **USING THE ACCESSORIES**



WARNING! Refer to Safety chapters.


around the shelf prevents cookware from slipping of the shelf.

#### **INSERTING ACCESSORIES**

A small indentation at the top increases safety. The indentations are also anti-tip devices. The high rim


#### Wire shelf:

Push the shelf between the guide bars of the shelf support and make sure that the feet point down.




#### Deep pan:

Push the Deep pan between the guide bars of the shelf support.




#### Wire shelf, Deep pan:

Push the Deep panDeep pan between the guide bars of the shelf support and the wire shelf on the guide bars above.



#### AirFry:

Place the tray on the third shelf position. Place the baking tray on the first shelf position.




#### TRIVET AND GRILL- / ROASTING PAN

Step 1	Put the trivet into a deep pan.
Step 2	Put the deep pan on the recommended shelf position.


# Roasting larger pieces of meat or poultry on one shelf position.

Make sure the supports of the wire shelf point up.



# Grilling and toasting thin pieces of food in large quantities.

Make sure the supports of the wire shelf point down.



## **ADDITIONAL FUNCTIONS**

#### **USING CHILD LOCK**

When the Child lock is on the oven cannot be turned on accidentally.

- **1.** Ensure the knob for the heating functions is in the off position.
- 2. O, oC press and hold at the same time for 2 seconds.

The signal sounds. SAFE, 🖸 - appear on the display. The door is locked.



the symbol appear on the display also when Pyrolysis function operates.

To turn off the Child Lock, repeat the step 2.

#### **USING FUNCTION LOCK**

You can turn on the Function Lock function only when the oven works.

When the Function lock is on the temperature and time settings cannot be changed accidentally.

- **1.** Select an oven function and set it according your preferences.
- 2. Press and hold  $\bigcirc$  and  $^{\mathbf{o}}\mathbf{C}$  at the same time for 2 seconds.

The signal sounds. **Loc** appears on the display for 5 seconds.



**Loc** appears on the display when you turn the knob for the temperature or press any button when the Function lock is on.

When you turn the knob for the oven functions, the oven stops.

When you turn off the oven while the Function Lock is on, the Function Lock switches automatically to the Child Lock. Refer to "Additional functions" chapter, Using the Child Lock.




If the Pyrolysis function operates, the door is locked and appears on the display.

To turn off the Function Lock, repeat step 2.

#### **RESIDUAL HEAT INDICATOR**

#### **AUTOMATIC SWITCH-OFF**

For safety reasons the oven turns off after some time, if a heating function works and you do not change any settings.



(°c)	(h)
120 - 195	8.5
200 - 245	5.5
250 - maximum	3

After an automatic switch-off, turn the knobs to the off position.

The Automatic switch-off does not work with the functions: Light, Duration, End Time.

#### **COOLING FAN**

When the oven operates, the cooling fan turns on automatically to keep the surfaces of the oven cool. If you turn off the oven, the cooling fan can continue to operate until the oven cools down.

#### **SAFETY THERMOSTAT**

Incorrect operation of the oven or defective components can cause dangerous overheating. To prevent this, the oven has a safety thermostat which interrupts the power supply. The oven turns on again automatically when the temperature drops.

## HINTS AND TIPS



**WARNING!** Refer to Safety chapters.

#### COOKING RECOMMENDATIONS

The oven has five shelf positions.

Count the shelf positions from the bottom of the oven floor.

Your oven may bake or roast differently to the oven you had before. The below tables provide you with the standard settings for temperature, cooking time and shelf position.

If you cannot find the settings for a special recipe, look for the similar one.

The oven has a special system which circulates the air and constantly recycles the steam. With this system you can cook in a steamy environment and keep the food soft inside and crusty outside. It decreases the cooking time and energy consumption.

#### **Baking cakes**

Do not open the oven door before 3/4 of the set cooking time is up.

If you use two baking trays at the same time, keep one empty level between them.

#### Cooking meat and fish

Use a deep pan for very fatty food to prevent the oven from stains that can be permanent.

Leave the meat for approximately 15 minutes before carving so that the juice does not seep out.

To prevent too much smoke in the oven during roasting, add some water into the deep pan. To prevent the smoke condensation, add water each time after it dries up.

#### Cooking times

Cooking times depend on the type of food, its consistency, and volume.

Initially, monitor the performance when you cook. Find the best settings (heat setting, cooking time,

## **BAKING AND ROASTING**



	Conventional Cooking		True Fan Cooking			
*	(°C)	<u>}</u>	(°C)	<u>}</u>	(min)	(0° 0°)
Whisked recipes	170	2	160	3 (2 and 4)	45 - 60	Cake mould
Shortbread dough	170	2	160	3 (2 and 4)	20 - 30	Cake mould
Buttermilk cheesecake	170	1	165	2	80 - 100	Cake mould, Ø 26 cm
Strudel	175	3	150	2	60 - 80	Baking tray
Jam tart	170	2	165	2	30 - 40	Cake mould, Ø 26 cm
Sponge cake	170	2	150	2	40 - 50	Cake mould, Ø 26 cm
Christmas cake, preheat the empty oven	160	2	150	2	90 - 120	Cake mould, Ø 20 cm
Plum cake, preheat the empty oven	175	1	160	2	50 - 60	Bread tin
Muffins, pre- heat the emp- ty oven	170	3	150 - 160	3	20 - 30	Baking tray
Muffins, two levels, pre- heat the emp- ty oven	-	-	140 - 150	2 and 4	25 - 35	Baking tray
Muffins, three levels, pre- heat the emp- ty oven	-	-	140 - 150	1, 3 and 5	30 - 45	Baking tray



	Conventional Cooking		True Fan Cooking			
*	(°C)	] <u>←</u>	(°C)	<u>_</u>	(min)	(°)
Biscuits	140	3	140 - 150	3	25 - 45	Baking tray
Biscuits, two levels	-	-	140 - 150	2 and 4	35 - 40	Baking tray
Biscuits, three levels	-	-	140 - 150	1, 3 and 5	35 - 45	Baking tray
Meringues	120	3	120	3	80 - 100	Baking tray
Meringues, two levels, preheat the empty oven	-	-	120	2 and 4	80 - 100	Baking tray
Buns, preheat the empty oven	190	3	190	3	12 - 20	Baking tray
Eclairs	190	3	170	3	25 - 35	Baking tray
Eclairs, two levels	-	-	170	2 and 4	35 - 45	Baking tray
Plate tarts	180	2	170	2	45 - 70	Cake mould, Ø 20 cm
Rich fruit cake	160	1	150	2	110 - 120	Cake mould, Ø 24 cm

Preheat the empty oven.



	Conventional Cooking		True Fan Cooking			
*	(°C)	<u>_</u>	(°C)	<u>_</u>	(min)	i
White bread, 1 - 2 pieces, 0.5 kg each	190	1	190	1	60 - 70	-
Rye bread, preheating is not needed	190	1	180	1	30 - 45	Bread tin
Bread rolls, 6 - 8 rolls	190	2	180	2 (2 and 4)	25 - 40	Baking tray
Pizza	230 - 250	1	230 - 250	1	10 - 20	Baking tray / Deep pan
Scones	200	3	190	3	10 - 20	Baking tray

Preheat the empty oven.

Use the cake mould.



	Conventio	onal Cooking	True Fan Cooking			
*	(°C)	<u>_</u>	(°C)	<u>_</u>	(min)	
Pasta flan, preheating is not needed	200	2	180	2	40 - 50	
Vegetable flan, pre- heating is not needed	200	2	175	2	45 - 60	
Quiches	180	1	180	1	50 - 60	
Lasagne	180 - 190	2	180 - 190	2	25 - 40	



	Convention	Conventional Cooking True Fan		Cooking	
*	(°C)	<u>_</u>	(°C)	<u>_</u>	(min)
Cannelloni	180 - 190	2	180 - 190	2	25 - 40

Use the second shelf position.

Use the wire shelf.



*	Conventional Cooking	True Fan Cooking	(min)
Beef	200	190	50 - 70
Pork	180	180	90 - 120
Veal	190	175	90 - 120
English roast beef, rare	210	200	50 - 60
English roast beef, medium	210	200	60 - 70
English roast beef, well done	210	200	70 - 75



	Convention	nal Cooking	True Fan Cooking		
*	(°C)	<u></u>	(°C)	<u>_</u>	(min)
Pork shoulder, with rind	180	2	170	2	120 - 150
Pork shin, 2 pieces	180	2	160	2	100 - 120
Leg of lamb	190	2	175	2	110 - 130
Whole chicken	220	2	200	2	70 - 85
Whole turkey	180	2	160	2	210 - 240
Whole duck	175	2	220	2	120 - 150
Whole goose	175	2	160	1	150 - 200
Rabbit, cut in pieces	190	2	175	2	60 - 80
Hare, cut in pieces	190	2	175	2	150 - 200
Whole pheasant	190	2	175	2	90 - 120

Use the second shelf position.



	Conventional Cooking	True Fan Cooking	
*	(°C)	(°C)	(min)
Trout / Sea bream, 3 - 4 fish	190	175	40 - 55
Tuna / Salmon, 4 - 6 fillets	190	175	35 - 60

#### **GRILL**

Preheat the empty oven.

Use the fourth shelf position.

Grill with the maximum temperature setting.

GRILL	(kg)	(min) 1st side	(min) 2nd side
Fillet steaks, 4 pieces	0.8	12 - 15	12 - 14
Beef steak, 4 pieces	0.6	10 - 12	6 - 8
Sausages, 8	-	12 - 15	10 - 12
Pork chops, 4 pieces	0.6	12 - 16	12 - 14
Chicken, half, 2	1	30 - 35	25 - 30
Kebabs, 4	-	10 - 15	10 - 12
Chicken breast, 4 pieces	0.4	12 - 15	12 - 14
Burgers, 6	0.6	20 - 30	-
Fish fillet, 4 pieces	0.4	12 - 14	10 - 12
Toasted sandwiches, 4 - 6	-	5 - 7	-
Toast, 4 - 6	-	2 - 4	2 - 3

#### **TURBO GRILLING**

Preheat the empty oven.

Use the first or the second shelf position.

To calculate the roasting time multiple the time given in the table below by the centimetres of thickness of the fillet.

© <sub>BEEF</sub>	(°C)	(min)
Roast beef or fillet, rare	190 - 200	5 - 6
Roast beef or fillet, medium	180 - 190	6 - 8
Roast beef or fillet, well done	170 - 180	8 - 10
PORK	(°C)	(min)
Shoulder / Neck / Ham joint, 1 - 1.5 kg	160 - 180	90 - 120
Chops / Spare rib, 1 - 1.5 kg	170 - 180	60 - 90
Meatloaf, 0.75 - 1 kg	160 - 170	50 - 60
Pork knuckle, pre- cooked, 0.75 - 1 kg	150 - 170	90 - 120
O <sub>VEAL</sub>	(°C)	(min)
Roast veal, 1 kg	160 - 180	90 - 120
Veal knuckle, 1.5 - 2 kg	160 - 180	120 - 150
	(°C)	(min)
Lamb leg / Roast lamb, 1 - 1.5 kg	150 - 170	100 - 120

	(°C)	(min)
Lamb saddle, 1 - 1.5 kg	160 - 180	40 - 60
POULTRY	(°C)	(min)
Poultry, portions, 0.2 - 0.25 kg each	200 - 220	30 - 50
Chicken, half, 0.4 - 0.5 kg each	190 - 210	35 - 50
Chicken, poulard, 1 - 1.5 kg	190 - 210	50 - 70
Duck, 1.5 - 2 kg	180 - 200	80 - 100
Goose, 3.5 - 5 kg	160 - 180	120 - 180
Turkey, 2.5 - 3.5 kg	160 - 180	120 - 150
Turkey, 4 - 6 kg	140 - 160	150 - 240
FISH (STEAMED)	(°C)	(min)
Whole fish, 1 - 1.5 kg	210 - 220	40 - 60

#### **AIRFRY**

Put the food directly on the tray.
Set the temperature to 180 - 220°C.
Use the function: Pizza Function / AirFry.
The food does not have to be turned during cooking.

*	i
French fries, frozen	-
French fries, fresh	Apply 1 tablespoon of oil.
Potato wedges, fro- zen	-
Potato wedges, fresh	Apply 1 tablespoon of oil.

*	(i)
Potato patties	-
Croquettes	-
Spring rolls, frozen	-
Roasted vegetables, fresh	Apply 1 tablespoon of oil.

#### **DEFROST**

*	(kg)	Defrosting time (min)	Further defrosting time (min)	i
Chicken	1	100 - 140	20 - 30	Place chicken on an upturned saucer placed on a large plate. Turn halfway through.
Meat	1	100 - 140	20 - 30	Turn halfway through.
	0.5	90 - 120		
Cream	2 x 0.2	80 - 100	10 - 15	Cream can also be whipped when still slightly frozen in pla- ces.
Trout	0.15	25 - 35	10 - 15	-
Strawberries	0.3	30 - 40	10 - 20	-
Butter	0.25	30 - 40	10 - 15	-
Gateau	1.4	60	60	-

#### **DEHYDRATING - TRUE FAN COOKING**

Cover trays with grease proof paper or baking parchment.

For a better result, stop the oven halfway through the drying time, open the door and let it cool down for one night to complete the drying.

For 1 tray use the third shelf position.

For 2 trays use the first and fourth shelf position.

VEGETABLES	(°C)	(h)
Beans	60 - 70	6 - 8
Peppers	60 - 70	5 - 6

VEGETABLES	(°C)	(h)
Vegetables for soup	60 - 70	5 - 6
Mushrooms	50 - 60	6 - 8
Herbs	40 - 50	2 - 3


Set the temperature to 60 - 70 °C	Set the te	mperature	to 60	- 7	'0°	C.
-----------------------------------	------------	-----------	-------	-----	-----	----

FRUIT	(h)
Plums	8 - 10

S FRUIT	(h)
Apricots	8 - 10
Apple slices	6 - 8
Pears	6 - 9

## MOIST FAN BAKING - RECOMMENDED ACCESSORIES

Use the dark and non-reflective tins and containers. They have better heat absorption than the light colour and reflective dishes.




Dark, non-reflective 28 cm diameter



Dark, non-reflective 26 cm diameter



Ceramic 8 cm diameter, 5 cm height



Dark, non-reflective 28 cm diameter

#### **MOIST FAN BAKING**

For the best results follow suggestions listed in the table below.

*	))}	(°C)	] <u>←</u>	(min)
Sweet rolls, 16 pieces	baking tray or dripping pan	180	2	20 - 30
Rolls, 9 pieces	baking tray or dripping pan	180	2	30 - 40
Pizza, frozen, 0.35 kg	wire shelf	220	2	10 - 15
Swiss roll	baking tray or dripping pan	170	2	25 - 35

*	))}{	(°C)	<u>_</u>	(min)
Brownie	baking tray or dripping pan	175	3	25 - 30
Soufflè, 6 pieces	ceramic ramekins on wire shelf	200	3	25 - 30
Sponge flan base	flan base tin on wire shelf	180	2	15 - 25
Victoria sandwich	baking dish on wire shelf	170	2	40 - 50
Poached fish, 0.3 kg	baking tray or dripping pan	180	3	20 - 25
Whole fish, 0.2 kg	baking tray or dripping pan	180	3	25 - 35
Fish fillet, 0.3 kg	pizza pan on wire shelf	180	3	25 - 30
Poached meat, 0.25 kg	baking tray or dripping pan	200	3	35 - 45
Shashlik, 0.5 kg	baking tray or dripping pan	200	3	25 - 30
Cookies, 16 pieces	baking tray or dripping pan	180	2	20 - 30
Macaroons, 24 pieces	baking tray or dripping pan	180	2	25 - 35
Muffins, 12 pieces	baking tray or dripping pan	170	2	30 - 40
Savory pastry, 20 pieces	baking tray or dripping pan	180	2	25 - 30
Short crust bis- cuits, 20 pieces	baking tray or dripping pan	150	2	25 - 35
Tartlets, 8 pieces	baking tray or dripping pan	170	2	20 - 30
Vegetables, poached, 0.4 kg	baking tray or dripping pan	180	3	35 - 45
Vegetarian ome- lette	pizza pan on wire shelf	200	3	25 - 30
Mediterranean vegetables, 0.7 kg	baking tray or dripping pan	180	4	25 - 30

## **INFORMATION FOR TEST INSTITUTES**

Tests according to IEC 60350-1.

						1
*		))};	<u>}</u>	(°C)	(min)	i
Small cakes, 20 per tray	Convention- al Cooking	Baking tray	3	170	20 - 30	-
Small cakes, 20 per tray	True Fan Cooking	Baking tray	3	150 - 160	20 - 35	-
Small cakes, 20 per tray	True Fan Cooking	Baking tray	2 and 4	150 - 160	20 - 35	-
Apple pie, 2 tins Ø20 cm	Convention- al Cooking	Wire shelf	2	180	70 - 90	-
Apple pie, 2 tins Ø20 cm	True Fan Cooking	Wire shelf	2	160	70 - 90	-
Sponge cake, cake mould Ø26 cm	Convention- al Cooking	Wire shelf	2	170	40 - 50	Preheat the oven for 10 minutes.
Sponge cake, cake mould Ø26 cm	True Fan Cooking	Wire shelf	2	160	40 - 50	Preheat the oven for 10 minutes.
Sponge cake, cake mould Ø26 cm	True Fan Cooking	Wire shelf	2 and 4	160	40 - 60	Preheat the oven for 10 minutes.
Short bread	True Fan Cooking	Baking tray	3	140 - 150	20 - 40	-
Short bread	True Fan Cooking	Baking tray	2 and 4	140 - 150	25 - 45	-
Short bread	Convention- al Cooking	Baking tray	3	140 - 150	25 - 45	-

*		));;	<u>_</u>	(°C)	(min)	<b>i</b>
Toast, 4 - 6 pieces	Grill	Wire shelf	4	max.	2 - 3 minutes first side; 2 - 3 minutes sec- ond side	Preheat the oven for 3 minutes.
Beef burger, 6 pieces, 0.6 kg	Grill	Wire shelf and dripping pan	4	max.	20 - 30	Put the wire shelf on the fourth level and the dripping pan on the third level of the oven. Turn the food half- way through the cooking time. Preheat the oven for 3 minutes.

## CARE AND CLEANING



WARNING! Refer to Safety chapters.

#### NOTES ON CLEANING



Clean the front of the oven with a soft cloth with warm water and a mild detergent.

Use a cleaning solution to clean metal surfaces.

Clean stains with a mild detergent.



Everyday Use Clean the cavity after each use. Fat accumulation or other residue may cause fire.

Moisture can condense in the oven or on the door glass panels. To decrease the condensation, let the oven work for 10 minutes before cooking. Dry the cavity with a soft cloth after each use.



Accessories


Clean all accessories after each use and let them dry. Use a soft cloth with warm water and a mild detergent. Do not clean the accessories in a dishwasher.


Do not clean the non-stick accessories using abrasive cleaner or sharp-edged objects.

#### **HOW TO REMOVE: SHELF SUPPORTS**

Remove the shelf supports to clean the oven.

Step 1	Turn off the oven and wait until it is cold.
Step 2	Pull the front of the shelf support away from the side wall.
Step 3	Pull the rear end of the shelf support away from the side wall and remove it.
Step 4	Install the shelf supports in the opposite sequence.





#### HOW TO USE: PYROLYTIC CLEANING

Clean the oven with pyrolytic cleaning.



WARNING! There is a risk of burns.



**CAUTION!** If there are other appliances installed in the same cabinet, do not use them at the same time as this function. It can cause damage to the oven.

#### Before the pyrolytic cleaning:

Turn off the oven and wait until it is cold.		Remove all accessories.	Clean the oven floor and the inner door glass with warm water, a soft cloth and a mild detergent.
Step 1	Set the function	ı:	
Step 2	Turn the control	knob (for the temperature) to set the	e cleaning mode.
Option		Cleaning mode	Duration
	P1	Light cleaning	1 h 30 min
	P2 Normal cleaning		2 h 30 min
Step 3	O - press to st	art the cleaning.	'
Step 4	After cleaning, t	urn the knob for the heating function	s to the off position.

i During the cleaning the oven lamp is off. The oven door stays locked. When the oven is cold, the door unlocks.

When the oven is at the set temperature, the door locks. Until the door unlocks the display shows: the bars of the heat indicator, . To stop cleaning before it is completed, turn the knob for the oven functions to the off position.

#### When the cleaning ends:

Turn off the oven and wait until it is cold.

Clean the cavity with a soft cloth.

Remove the residue from the bottom of the cavity.

#### **CLEANING REMINDER**

The oven reminds you when to clean the oven with: pyrolytic cleaning.

PYR - flashes in the display for 10 sec after each activation and deactivation of the oven.

-\$\sigma\_3s\$, °C - press at the same time to turn off the reminder.

#### REMOVING AND INSTALLING DOOR

The oven door has three glass panels. You can remove the oven door and the internal glass panels to clean them. Read the whole "Removing and installing door" instruction before you remove the glass panels.




The oven door may close if you try to remove the glass panels before you remove the oven door.




**CAUTION!** Do not use the oven without the glass panels.


1. Open the door fully and hold both hinges.




2. Lift and turn the levers fully on both hinges.




Close the oven door halfway to the first opening position. Then lift and pull forward and remove the door from its seat.



- 4. Put the door on a soft cloth on a stable surface.
- 5. Hold the door trim (B) on the top edge of the door at the two sides and push inwards to release the clip seal.



- 6. Pull the door trim to the front to remove it.
- Hold the door glass panels by their top edge and carefully pull them out one by one. Start from the top panel. Make sure the glass slides out of the supports completely.




8. Clean the glass panels with water and soap.

Dry the glass panels carefully. Do not clean the glass panels in the dishwasher.

When the cleaning is completed, install the glass panels and the oven door.

Make sure that you put the glass panels (A and B) back in the correct sequence. Check for the symbol / printing on the side of the glass panel, each of the glass panels looks different to make the disassembly and assembly easier.

When installed correctly the door trim clicks.



Make sure that you install the middle panel of glass in the seats correctly.



#### **HOW TO REPLACE: LAMP**



**WARNING!** Risk of electric shock. The lamp can be hot.

Always hold the halogen lamp with a cloth to prevent grease residue from burning on the lamp.

#### Before you replace the lamp:

Step 1	Step 2	Step 3
Turn off the oven. Wait until the oven is cold.	Disconnect the oven from the mains.	Put a cloth on the bottom of the cavity.

#### **Back lamp**

Step 1	Turn the glass cover to remove it.
Step 2	Clean the glass cover.
Step 3	Replace the lamp with a suitable 300 °C heat-resistant lamp.
Step 4	Install the glass cover.

## **TROUBLESHOOTING**



WARNING! Refer to Safety chapters.

#### WHAT TO DO IF...

#### The oven does not turn on or does not heat up

Possible cause	Remedy
The oven is not connected to an electrical supply or it is connected incorrectly.	Check if the oven is correctly connected to the electrical supply (refer to the connection diagram if available).
The oven is deactivated.	Activate the oven.

## The oven does not turn on or does not heat up

Possible cause	Remedy
The clock is not set.	Set the clock.
The necessary settings are not set.	Make sure that the settings are correct.
The automatic switch-off is activated.	Refer to "Automatic switch-off".
The door is not closed correctly.	Fully close the door.
The fuse is blown.	Make sure that the fuse is the cause of the mal- function. If the fuse is blown again and again, contact a qualified electrician.
The oven Child Lock is on.	Refer to "Using the Child Lock".

## **Problems with components**

Description	Possible cause	Remedy
The lamp does not operate.	The lamp is defective.	Replace the lamp.

## Display shows:

Description	Possible cause	Remedy
The display shows "C3".	The cleaning function does not operate. You did not fully close the door, or the door lock is defective.	Fully close the door.
The display shows "F102".	<ul> <li>You did not fully close the door.</li> <li>The door lock is defective.</li> </ul>	<ul> <li>Fully close the door.</li> <li>Deactivate the oven with the house fuse or the safety switch in the fuse box and activate it again.</li> <li>If the display shows "F102" again, contact the Customer Care Department.</li> </ul>

## Display shows:

Description	Possible cause	Remedy
The display shows an error code that is not in this table.	There is an electrical fault.	Deactivate the oven with the house fuse or the safety switch in the fuse box and activate it again. If the display shows the error code again, contact the Customer Care Department.
The display shows "12.00".	There was a power cut.	Set the clock.

## Problems with cleaning procedure

Description	Possible cause	Remedy
Steam and condensation settle on the food and in the cavity of the oven.	You left the dish in the oven for too long.	Do not leave the dishes in the oven for longer than 15 - 20 minutes after the cooking process ends.

## Other problems

Description	Possible cause	Remedy
The appliance is activated and does not heat up. The fan does not operate. The display shows " <b>Demo</b> ".	The demo mode is activated.	<ol> <li>Deactivate the oven.</li> <li>Press and hold at the         same time</li></ol>

#### **SERVICE DATA**

If you cannot find a solution to the problem yourself, contact your dealer or an Authorised Service Centre.

The necessary data for the service centre is on the rating plate. The rating plate is on the front frame of

the oven cavity. Do not remove the rating plate from the oven cavity.

#### We recommend that you write the data here:

Model (MOD.)	
Product number (PNC)	
Serial number (S.N.)	

## **ENERGY EFFICIENCY**

#### PRODUCT INFORMATION AND PRODUCT INFORMATION SHEET\*

Supplier's name	Zanussi	
Model identification	ZOPNA7K1 949498119 ZOPNA7X1 949498118	
Energy Efficiency Index	81.2	
Energy efficiency class	A+	
Energy consumption with a standard load, conventional mode	0.93 kWh/cycle	
Energy consumption with a standard load, fan-forced mode	0.69 kWh/cycle	
Number of cavities	1	
Heat source	Electricity	
Volume	72	
Type of oven	Built-In Oven	
Mass	ZOPNA7K1 31.3 kg	
ividos	ZOPNA7X1 31.3 kg	

<sup>\*</sup> For European Union according to EU Regulations 65/2014 and 66/2014.

For Republic of Belarus according to STB 2478-2017, Appendix G; STB 2477-2017, Annexes A and B.

For Ukraine according to 568/32020.

Energy efficiency class is not applicable for Russia.

EN 60350-1 - Household electric cooking appliances - Part 1: Ranges, ovens, steam ovens and grills - Methods for measuring performance.

#### **ENERGY SAVING**



The oven contains features which help you save energy during everyday cooking.

Make sure that the oven door is closed properly when the oven operates. Do not open the door too often during cooking. Keep the door gasket clean and make sure it is well fixed in its position.

Use metal cookware to improve energy saving. When possible, do not preheat the oven before cooking.

Keep breaks between baking as short as possible when you prepare a few dishes at one time.

#### Cooking with fan

When possible, use the cooking functions with fan to save energy.

#### Residual heat

If a programme with the Duration or End Time selection is activated and the cooking time is longer than 30 minutes, the heating elements automatically turn off earlier in some oven functions.

The fan and lamp continue to operate. When you turn off the oven, the display shows the residual heat. You can use that heat to keep the food warm.

When the cooking duration is longer than 30 minutes, reduce the oven temperature to minimum 3 - 10 minutes before the end of cooking. The residual heat inside the oven will continue to cook. Use the residual heat to warm up other dishes.

#### Keep food warm

Choose the lowest possible temperature setting to use residual heat and keep a meal warm. The residual heat indicator or temperature appears on the display.

#### Cooking with the lamp off

Turn off the lamp during cooking. Turn it on only when you need it.

#### **Moist Fan Baking**

Function designed to save energy during cooking. When you use this function the lamp automatically turns off after 30 seconds. You may turn on the lamp again but this action will reduce the expected energy savings.

## **ENVIRONMENTAL CONCERNS**

Recycle materials with the symbol 🖒 Put the packaging in relevant containers to recycle it. Help protect the environment and human health by recycling waste of electrical and electronic appliances. Do not dispose of appliances marked

with the symbol with the household waste. Return the product to your local recycling facility or contact your municipal office.

# WWW.ZANUSSI.COM/SHOP













867359280-B-082020