

Please Note**Electrical connection**

The oven is fitted with a plug and must be only connected to a properly installed earthed socket. In accordance with the appropriate regulations, the socket must only be installed and the connecting cable must only be replaced by a qualified electrician.


If the plug is no longer accessible following installation and all-pole isolating switch must be present on the installation side with a contact gap at least 3mm.

A. Built-in furniture


The built-in cabinet shall not have a rear wall behind the appliance.

Minimum installation height is 85cm.


Do not cover ventilation slots and air intake points.




-  Screw
-  Bracket
-  Trim-kit plastic cover



B. Prepare the Cabinet.




1. Put the **BOTTOM CABINET TEMPLATE** on the bottom plane of cabinet.
And make the center line of the template coincides with the bottom of cabinet.




2. Fix the **BOTTOM BRACKET** with two **SCREW**.
And remove the **BOTTOM CABINET TEMPLATE**.


C. Install the oven.



3. Install the oven into the cabinet.
- Do not trap or kink the power cord.



4. Bottom Bracket is just installed against the back shell of the oven.



5. Open the door; fix the oven to the cabinet with SCREW at the INSTALLATION HOLE of TRIM KIT. Then fix the TRIM-KIT PLASTIC COVER to the INSTALLATION HOLE.