


JVC

Unpacking Guide

LT-40C880




TV




Accessories Pack






TV Stand Neck



TV Stand Base



2 people are required when unpacking your TV.



Don't lift the TV from the top

Fitting the Stand Neck and Base Together


1. Fit the neck onto the base.
2. Using 4 of the supplied screws, screw the neck to the base.

Fitting the Stand to the TV

3. Ensure the TV is switched off and not connected to the mains power supply.
4. Keep the protective bag on your TV, it will help to protect the TV. Lay the TV down on a flat surface ideally on the edge of a table so the base of the TV slightly overhangs the edge of the table, with the back side facing up. Please make sure a soft cushioned material (such as a dry bath towel or thick piece of foam) is placed beneath the screen.
5. Slide the stand under the lip, the neck will fit snugly over the screw holes. Then screw the stand to the TV using the 4 screws supplied.




- Keep the protective bag on your TV until you have attached the stand and positioned the TV.
- The LCD display is very fragile, and must be protected at all times when installing and removing the base stand. Be sure that no hard or sharp object, or anything that could scratch or damage the LCD display, comes into contact with it. DO NOT exert pressure on the front of the TV at any time because the screen could crack.




If you don't have a table big enough, you can use the TV box. Lie the box flat, make sure you place the polystyrene back in the box first to give the box some rigidity and strength.

Protective Bag




Cushioned material

Table



Slide under the lip

Remove the Protective Bag



Mounting the TV to a Wall




Remove the stand assembly before mounting the TV onto the wall.

- 1. Remove the 4 screws from the neck of the stand and detach the stand.



If you don't have a table big enough, you can use the TV box. Make sure you place the polystyrene back in the box first to give the box some rigidity and strength.




- 2. This TV is designed to be wall-mounted with a standard 200 mm x 200 mm mounting kit (sold separately) designed for flat-panel TVs. Mount this TV according to the instructions included in the mounting kit. Due to space restrictions, we recommend that you make all connections i.e aerial/HDMI before mounting on to the wall. Do not connect the power until all connections are made and the TV is correctly wall mounted.


TV Weight
LT-40C880 - 8.2kg



Always check the specification of your wall mount bracket to make sure its suitable for the weight of your TV.



- If you are wall mounting your TV you may wish to buy a 90° HDMI adapter. This will help with your cable management.
- If you require additional assistance please call our Call Centre on (UK) **0344 561 1234** or (Ireland) **1 890 818 575**. Our Customer Contact Centre is open Monday-Saturday 8am-8pm or Sunday 8am-6pm.



- 2 people are required when wall mounting large TVs.
- Make sure you hold the TV on the sides do not hold the screen, you may damage the screen.