1 Electrolux

This is clarification of the operation of the grill elements in the main and secondary ovens:

Main Oven



Full grill setting – Both elements are in operation, the inner element will glow brighter than the outer. The heat out put may be controlled by changing the temperature setting.



Economy grill / Half Grill – Inner element only in operation. The heat output may be controlled by changing the temperature setting

Secondary Oven - Conventional Thermostat



Full grill setting – Both elements are in operation, the inner element will glow brighter than the outer. The heat out put may be controlled by changing the temperature setting.



Economy grill / Half Grill – Inner element only in operation. The heat output may be controlled by changing the temperature setting

Secondary Oven - Electronic Temperature Control



Full grill setting – Both elements are in operation at full power, the inner element will glow brighter than the outer. The heat out put may be controlled by changing the temperature setting.



Economy grill / Half Grill – Both elements are in operation at reduced power, the elements will not be glowing as brightly. The outer element will glow brighter that the inner element. The heat output may be controlled by changing the temperature setting.