

DF614PTX

60cm Freestanding Dishwasher, Finger Friendly Stainless Steel A++A Rated

EAN13: 8017709226619



























- 10 programmes: Soak, Crystal, ECO, Quick 27 min, ECO Quick, Delicate and Quick, Normal Quick, Auto 45-65, Ultraclean, Super Quick
- 5 temperatures (38° 45° 50° 65° 70°)
- Energy saving option Enersave
- Delay timer up to 24hrs
- 1/2 load FlexiZone option (No restrictions on where items are placed)
- Option for FlexiTabs

Planetarium wash system

- Quick Time option
- Total Aquastop
- Concealed heating element
- Adjustable water softener
- Self-balancing door hinges
- St/steel filter
- Aquatest
- · Third cutlery basket Flexi Duo
- Upper Basket: With central fixed racks
- Height adjustment of the upper basket: On three horizontal levels
- Lower Basket: With foldable racks and glass holder
- Maximum plate diameter 30cm
- Average wash time approximately 100 mins, but Quick Time can reduce this by up to 55%
- Consumption (based on 280 cycles):
- Water: 2520 litres per annum/ 9 litres per cycle
- Energy: 261 kW/year/ 0.92 kWh/cycle
- Noise level: 43 dB (A) RE 1 Pw
- Reference Programme: ECO
- Total cycle time of ECO programme: 165 minutes

Energy consumption:

- Stand by off mode: 0.02W/ Stand by on mode: 0.80W
- Duration of stand by mode: 5 minutes
- Energy Efficiency class: A++
- Cleaning performance: A
- Drying performance: A

Functions






















DF614PTX









Soak programme:

The soak programme provides a rinse to prevent dirt from drying.





CRYSTAL:

The crystal cycle is a particular programme designed especially for delicate dishes with light dirt.





Eco:

Eco, this economic wash programme uses a low amount of water and energy in order to provide the most environmentally friendly cleaning option.





RAPID 27 MINS:

A new quick programme which takes just 27 minutes, suitable for a lightly soiled load.







Eco, this economic wash programme uses a low amount of water and energy in order to provide the most environmentally friendly cleaning option.





Delicate Quick:

A quick programme ideal for delicate loads.





Normal Quick:

A quick programme ideal for loads without stubborn dirt or dried on residue.





Auto 45°- 65°:

The auto programme regulates the length of a cycle depending on the need for a pre-wash and the number of rinses required.





When the HYCLEAN option (or Ultracleanse programme) is selected, the dishwasher performs a final 10 minute rinse at a high temperature of 70°C, eliminating virtually all bacteria to achieve the highest possible standards of cleanliness. The Hyclean option can be selected with almost all cycles at temperatures above 50°C.



Super Quick:

The super Quick programme is suitable for removing stubborn dirt fast.

DF614PTX





