





**A+++:**

Product energy rating, measured from A+++ to D / G depending on the product family.




**A:**

Product drying performance, measured from A+++ to D / G depending on the product family

**Planetarium wash system:**



The Planetarium wash system has an innovative double simultaneous motion of the spray arm which ensures maximum wash coverage within the dishwasher. The rotation speed is approximately 65rpm, giving the best wash results available.



**FlexiDuo:**



The FlexiDuo 3rd cutlery basket allows you to arrange cutlery or small cups, ladles, or bulky utensils however you like: it consists of two separate and moveable modules.



**13 plate settings:**



The symbols show the number of plate settings of the dishwasher.



**TOTAL AQUASTOP:**



In addition to the partial Aquastop protection present in all Smeg dishwashers, some models have an electronic device fitted to the water intake hose, which monitors water levels in the machine, detects leaks in the hose and switches off the water supply immediately when necessary.



**DELAY TIMER:**



A delay timer can postpone the start of the programme by up to 24 hours, for convenience and also to take advantage of off-peak energy periods



**FlexiZone:**



The new 1/2 load FlexiZone allows you to wash a reduced load saving energy, water and time and there are no restrictions on where the items are placed. Traditional half loads allow only one of the baskets to be used. Flexi-Zone can be found on most dishwashers, as either an option or a programme depending on the model.



**AQUATEST:**



An electronic infrared sensor measures the clarity of the water during an Auto programme, and automatically ensures the minimum consumption of water and energy during the load. Models with Aquatest will have at least one Auto programme.



**QUICK TIME:**



The Quick Time option can be selected in conjunction with all programmes except the pre-wash in order to reduce the length of the wash cycle up to 55%. By using higher temperatures and an intense mechanical spray action, Quick Time is able to save valuable time.



**FLEXITABS:**



Regardless of the type of detergent used, the wash cycle adjusts to give the best possible results every time.



**Soak programme:**



The soak programme provides a rinse to prevent dirt from drying.

**CRYSTAL:**

The crystal cycle is a particular programme designed especially for delicate dishes with light dirt.

**Eco:**

Eco, this economic wash programme uses a low amount of water and energy in order to provide the most environmentally friendly cleaning option.

**RAPID 27 MINS:**

A new quick programme which takes just 27 minutes, suitable for a lightly soiled load.

**Eco:**

Eco, this economic wash programme uses a low amount of water and energy in order to provide the most environmentally friendly cleaning option.

**Delicate Quick:**

A quick programme ideal for delicate loads.

**Normal Quick:**

A quick programme ideal for loads without stubborn dirt or dried on residue.

**Auto 45° - 65°:**

The auto programme regulates the length of a cycle depending on the need for a pre-wash and the number of rinses required.

**HYCLEAN:**

When the HYCLEAN option (or Ultracleanse programme) is selected, the dishwasher performs a final 10 minute rinse at a high temperature of 70°C, eliminating virtually all bacteria to achieve the highest possible standards of cleanliness. The Hyclean option can be selected with almost all cycles at temperatures above 50°C.

**Super Quick:**

The super Quick programme is suitable for removing stubborn dirt fast.




## DF6FABCR

50's Retro style

free standing  
60 cm  
cream

Planetarium wash system  
energy rating A+++A



Smeg (UK) Ltd  
The Magna Building, Wyndyke Furlong, Abingdon  
OX14 1DZ  
Tel. +44 (0)844 557 9907  
Fax +44 (0)844 557 9337