

DI613P

60cm fully integrated Dishwasher
A+++A Rated

EAN13: 8017709226312

- 13 place settings
- 10 programmes: Soak, Crystal, Normal, ECO, Rapid 27 min, ECO Quick, Delicate and Quick, Normal Quick, Super, Super Quick
- 5 washing temperatures (38°C, 45°C, 50°C, 65°C, 70°C)


Planetarium wash system

- Energy saving option Enersave: A+++
- Delay timer upto 24hrs
- Varied distribution ½ load option FlexiZone 1/2
- Quick Time option
- Third cutlery basket – Flexi Duo
- Active Light
- Total Aquastop
- Concealed heating element
- Adjustable water softener
- Self balancing door hinges
- St/steel filter
- Upper Basket: With central fixed racks
- Height adjustment of the upper basket: On three levels
- Lower Basket: With double foldable rack
- Back feet adjustable from the front

Consumption:

- Water: 2520 litres per year/9 litres per cycle
- Energy: 230 litres per year/0.81 kWh per cycle
- Noise level: 43 dB (A) re 1 Pw
- Energy class: A+++
- Cleaning performance: A
- Drying performance: A

Functions






A+++ A+++:
Product energy rating, measured from A+++ to D / G depending on the product family.

A A:
Product drying performance, measured from A+++ to D / G depending on the product family



13 plate settings:
The symbols show the number of plate settings of the dishwasher.

Planetarium wash system:

 The Planetarium wash system has an innovative double simultaneous motion of the spray arm which ensures maximum wash coverage within the dishwasher. The rotation speed is approximately 65rpm, giving the best wash results available.



ENERSAVE:
At the end of the drying cycle a special device slowly automatically opens the door a few centimeters which ensures perfect drying and can save up to 20% of energy on some models.



DELAY TIMER:
A delay timer can postpone the start of the programme by up to 24 hours, for convenience and also to take advantage of off-peak energy periods



TOTAL AQUASTOP:
In addition to the partial Aquastop protection present in all Smeg dishwashers, some models have an electronic device fitted to the water intake hose, which monitors water levels in the machine, detects leaks in the hose and switches off the water supply immediately when necessary.




FlexiZone:
The new 1/2 load FlexiZone allows you to wash a reduced load saving energy, water and time and there are no restrictions on where the items are placed. Traditional half loads allow only one of the baskets to be used. Flexi-Zone can be found on most dishwashers, as either an option or a programme depending on the model.



QUICK TIME:
The Quick Time option can be selected in conjunction with all programmes except the pre-wash in order to reduce the length of the wash cycle up to 55%. By using higher temperatures and an intense mechanical spray action, Quick Time is able to save valuable time.



ACTIVELIGHT:
A number of built-in models include ActiveLight, a red LED light which projects a red spot onto the floor beneath the dishwasher door when the appliance is in use. This makes it immediately obvious that the appliance is running, just by glancing at the light on the floor, so that the door is not accidentally opened before the wash phase has finished.



FlexiDuo:
The FlexiDuo 3rd cutlery basket allows you to arrange cutlery or small cups, ladles, or bulky utensils however you like: it consists of two separate and moveable modules.



Soak programme:
The soak programme provides a rinse to prevent dirt from drying.

**CRYSTAL:**

The crystal cycle is a particular programme designed especially for delicate dishes with light dirt.

**Normal programme:**

The normal programme is suitable for normal degrees of dirt for everyday use.

**Eco:**

Eco, this economic wash programme uses a low amount of water and energy in order to provide the most environmentally friendly cleaning option.

**RAPID 27 MINS:**

A new quick programme which takes just 27 minutes, suitable for a lightly soiled load.

**Eco:**

Eco, this economic wash programme uses a low amount of water and energy in order to provide the most environmentally friendly cleaning option.

**Delicate Quick:**

A quick programme ideal for delicate loads.

**Normal Quick:**

A quick programme ideal for loads without stubborn dirt or dried on residue.

**Super:**

The super programme is suitable for removing stubborn dirt.

**Super Quick:**

The super Quick programme is suitable for removing stubborn dirt fast.

