


Installation Manual




Apply for following models:

BeBa_25560


Please keep these instructions for future reference.



Tools required for installations(Tools not provided)




Spirit Level




hammer



Pencil




screw driver



electric driver














drill bit




tape






Package in carton box


A ø7x38mm  Cam screw(8pcs)	B ø8x30mm  Wood dowel(12pcs)	C ø15x11mm  Cam lock(8pcs)	D  Plastic foot(4pcs)	E  Hinge(2pcs)	F  (1pc)
G  Decorative stopper(6pcs)	H  Handle(1pc)	I  (1pc)	J  Crash pad(2pcs)	K  (4pcs)	









1 helper for some tasks












screw driver


C $\phi 15 \times 11 \text{mm}$

Cam lock(4pcs)





screw driver

C $\phi 15 \times 11 \text{mm}$

Cam lock(4pcs)








screw driver


E

Hinge(2pcs)





electric driver




screw driver



drill bit(M5)

H



Handle(1pc)

G


Decorative
stopper(6pcs)

J















Crash pad(2pcs)

F








(1pc)




 screw driver	 hammer	 Spirit Level	 Pencil
	 electric driver	 drill bit	 tape


Please note - wall fixings
are not supplied , These can
be purchased from a local DIY store







- Clean with a soft cloth & warm soapy water only
- Do not use abrasive cleaning agents
- Dry unit with a cloth after use



Important information Read carefully. Keep this information for further reference.

Serious or fatal crushing injuries can occur from furniture tip-over. To prevent this furniture from tipping over it must be permanently fixed to the wall.

Fixing devices for the wall are not included since different wall materials require different types of fixing devices .

Use fixing devices suitable for the walls in your home. For advice on suitable fixing systems, contact your local dealer.

