

Operating Instructions for myPRO^{XL} Dryers

Control panel



Instruction

1



Open the door and
load the machine

2



Choose
program

3



Push the ► button
to start programme

4



Drying is complete
when acoustic
signal sounds

Programs



High Temp* 60°C - Best for hygiene cycles



Med Temp 40°C



Low Temp 20°C



Non Heated Tumble

Find out more about
the advantages of myPRO
www.electroluxprofessional.com